Project	IEEE 802.16 Broadband Wireless Acc	cess Working Group <http: 16="" ieee802.org=""></http:>
Title	Proposal for Radio Conformance Tes	t Specification for P1802.16.3
Date	2003-05-08	
Submitted		
Source(s)	Lars Lindh	Voice: +358 50 483 6671
	Nokia Research Center	Fax: +358 7180 36851
	P.O Box 407	mailto:lars.e.lindh@nokia.com
	FIN-00045 Nokia Group	
Re:	Re: 1802.16.3-03/01 Call for Contributi	ons on Project 1802.16.3 (03/04/02)
Abstract	This document contains test procedures	for the 802.16 physical layer
Purpose	To aid TGC in developing the RCT doc	ument
Notice	This document has been prepared to assist IEEE	E 802.16. It is offered as a basis for discussion and is not binding on
	the contributing individual(s) or organization(s)	. The material in this document is subject to change in form and
	content after further study. The contributor(s) re	serve(s) the right to add, amend or withdraw material contained
	herein.	
Release	The contributor grants a free, irrevocable license	e to the IEEE to incorporate material contained in this contribution,
	and any modifications thereof, in the creation of an IEEE Standards publication; to copyright in the IEEE's name any	
	IEEE Standards publication even though it may include portions of this contribution; and at the IEEE's sole	
	discretion to permit others to reproduce in whole or in part the resulting IEEE Standards publication. The contributor	
	also acknowledges and accepts that this contribu	ition may be made public by IEEE 802.16.
Patent	The contributor is familiar with the IEEE 802.10	b Patent Policy and Procedures http://leee802.org/16/1pr/patents/
Policy and	policy.html>, including the statement "IEEE standards may include the known use of patent(s), including patent	
Procedures	applications, provided the IEEE receives assurance from the patent holder or applicant with respect to patents	
	essential for compliance with both mandatory and optional portions of the standard." Early disclosure to the Working	
	Group of patent information that might be relev	ant to the standard is essential to reduce the possibility for delays in
	the development process and increase the likelih	nood that the draft publication will be approved for publication.
	Please notify the Chair <mailto:chair@wireless< th=""><th>man.org> as early as possible, in written or electronic form, if</th></mailto:chair@wireless<>	man.org> as early as possible, in written or electronic form, if
	patented technology (or technology under paten	t application) might be incorporated into a draft standard being
	developed within the IEEE 802.16 Working Gro	up. The Chair will disclose this notification via the IEEE 802.16 web
	site <http: 16="" ieee802.org="" ipr="" notices="" patents="">.</http:>	

Contents

oomento		
1. Introduction		
2. Scope		
3. Purpose		
4. References		
5 Definitions abh	eviations	
5.1 Definition		•••
5.2 Acronyms		••••
6 Overview		••••
6.1 General R	viliramante	•••
6.2 Test Cond	tions	•••
7 Environmental	uons anto	•••
7. Environmental	equirements	•••
8. Required Tests		•••
9. Test Procedures		•••
9.1 Tests for th	e Subscriber Station	•••
9.1.1 RS	outer code t = $10 / BCC$ - frame control	•••
9.1.1.1	Test setup	•••
9.1.1.2	Test procedure	•••
9.1.2 RS	outer code other bursts	••
9.1.2.1	Test setup	•••
9.1.2.2	Test procedure	•••
9.1.3 Fix	ed codeword operation	••
9.1.3.1	Test setup	•••
9.1.3.2	Test procedure	•••
9.1.4 She	rtened last codeword operation	•••
9.1.4.1	Test setup	
9.1.4.2	Test procedure	
9.1.5 Bu	st preamble	
9.1.5.1	Test setup	
9.1.5.2	Test procedure	
9.1.6 Mc	dulation	
9.1.6.1	Test setup	
9162	Test procedure	•••
917 RS	outer code - Information Block Length	•••
9171	Test setun	••
0172	Test procedure	•••
9.1.7.2 0.1.9 Pa	demization with programmable seed	•••
9.1.0 Ka	Test setur	••
9.1.0.1	Test procedure	•••
9.1.8.2	Test procedure	•••
9.1.9 KS	outer coder - Initial ranging	•••
9.1.9.1	Test setup	•••
9.1.9.2	1 est procedure	•••
9.1.10 RS	outer code other bursts	•••
9.1.10.1	Test setup	•••
9.1.10.2	Test procedure	•••
9.1.11 Fix	ed codeword operation	••
9.1.11.1	Test setup	•••
9.1.11.2	Test procedure	•••
9112 Sh	rtened last codeword operation	••
7.1.12 SI		
9.1.12.1	Test setup	•••
9.1.12 Sh 9.1.12.1 9.1.12.2	Test procedure	•••

1	9.1.13.1	Test setup	. 19
2	9.1.13.2	Test procedure	. 19
3	9.1.14 Burs	t preamble	. 20
4	9.1.14.1	Test setup	. 20
6	9.1.14.2	Test procedure	. 20
7	9.1.15 Mod	ulation	. 21
8	9.1.15.1	Test setup	21
9	91152	Test procedure	21
10	9116 RS c	uter code - Information Block Length	22
11	91161	Test setun	22
12	9.1.10.1	Test procedure	. 22 22
13	9.1.10.2	Test procedure	. 22
15	9.1.17 Cital		. 23
16	9.1.17.1	Test setup	. 23
17	9.1.17.2	I est procedure	. 23
18	9.1.18 Tx L	Dynamic range	. 24
19	9.1.18.1	Test setup	. 24
20	9.1.18.2	Test procedure	. 24
22	9.1.19 Rx I	Dynamic range	. 25
23	9.1.19.1	Test setup	. 25
24	9.1.19.2	Test procedure	. 25
25	9.1.20 Tx P	ower level at maximum power level setting	. 26
26	9.1.20.1	Test setup	. 26
27	9.1.20.2	Test procedure	. 26
28	9.1.21 Tx P	ower level adjustment step accuracy	. 27
30	9.1.21.1	Test setup	. 27
31	9.1.21.2	Test procedure	. 27
32	9.1.22 Svm	bol timing accuracy	. 28
33	9.1.22.1	Test setup	. 28
34	91222	Test procedure	28
35	9123 Ty F	lurst timing	20
30	91231	Test setun	20
38	0.1.23.1	Test procedure	20
39	9.1.23.2 0.1.24 Corr	ier frequency	20
40	9.1.24 Call	Test satur	20
41	9.1.24.1	1 est setup	. 30
42	9.1.24.2	I est procedure	. 30
43	9.1.25 Spec	tral mask	. 31
44	9.1.25.1	Test setup	. 31
46	9.1.25.2	Test procedure	. 31
47	9.1.26 Ram	p up / down time	. 32
48	9.1.26.1	Test setup	. 32
49	9.1.26.2	Test procedure	. 32
50	9.1.27 Outp	out noise power spectral density when Tx is not transmitting	. 33
51	9.1.27.1	Test setup	. 33
53	9.1.27.2	Test procedure	. 33
54	9.1.28 Mod	ulation accuracy	. 34
55	9.1.28.1	Test setup	. 34
56	9.1.28.2	Test procedure	. 34
57	9.1.29 BER	performance threshold	. 35
58	9.1.29.1	Test setup	35
59 60	91292	Test procedure	35
61	9130 Tran	sition time from Tx to Rx and from Rx to Tx	36
62	91301	Test setun	36
63	0 1 20 2	Test procedure	36
64	7.1.3U.2	diagont abannal interforence	. 50
65	9.1.31 Ist a	ajacent channel interierence	. 51

1	9.1.31.1	Test setup	37
2	9.1.31.2	Test procedure	37
3	9.1.32 2nd	adjacent channel interference	39
4 5	9.1.32.1	Test setup	39
6	9.1.32.2	Test procedure	39
7	9.1.33 Tx I	Power level absolute accuracy	41
8	9.1.33.1	Test setup	. 41
9	91332	Test procedure	41
10	0.2 Tests for th	a Basa Station	+1
11	9.2 resis for the	outer add $t = 10 / PCC$ from control	+2
12	9.2.1 KS	Test setue	42
13	9.2.1.1	Test setup	42
15	9.2.1.2	lest procedure	42
16	9.2.2 KS	outer code other bursts	43
17	9.2.2.1	Test setup	43
18	9.2.2.2	Test procedure	43
19	9.2.3 Fixe	ed codeword operation	44
20	9.2.3.1	Test setup	44
21	9.2.3.2	Test procedure	44
23	9.2.4 Sho	rtened last codeword operation	45
24	9.2.4.1	Test setup	45
25	9.2.4.2	Test procedure	45
26	9.2.5 Bur	st preamble	46
27	9.2.5.1	Test setup	46
28	9.2.5.2	Test procedure	46
30	9.2.6 Mod	dulation	47
31	9261	Test setun	47
32	9262	Test procedure	47
	- / / - / /		·· · · /
33	9.2.0.2 0.2.7 PS	outer code Information Block Length	18
33 34	9.2.7 RS	outer code - Information Block Length	48
33 34 35	9.2.7 RS (9.2.7.1	outer code - Information Block Length Test setup	48
33 34 35 36	9.2.7 RS (9.2.7.1 9.2.7.2	Test procedure	48 48 48
33 34 35 36 37 38	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran	Test procedure	48 48 48 49
33 34 35 36 37 38 39	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1	Test procedure Test setup Test procedure domization with programmable seed Test setup	48 48 48 49 49
33 34 35 36 37 38 39 40	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2	Test procedure Test setup Test procedure domization with programmable seed Test setup Test setup Test procedure	48 48 48 49 49 49
33 34 35 36 37 38 39 40 41	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS	Test procedure	48 48 48 49 49 49 50
33 34 35 36 37 38 39 40 41 42	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1	Test procedure	48 48 48 49 49 49 50 50
33 34 35 36 37 38 39 40 41 42 43	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9.1 9.2.9.2	Test procedure outer code - Information Block Length Test setup Test procedure idomization with programmable seed Test setup Test setup Test procedure outer code - Initial ranging Test setup Test setup Test setup Test procedure outer code - Initial ranging Test procedure Test procedure	48 48 48 49 49 49 50 50 50
33 34 35 36 37 38 39 40 41 42 43 44	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.9.2 9.2.10 RS	Test procedure outer code - Information Block Length Test setup Test procedure domization with programmable seed Test setup Test setup Test procedure outer code - Initial ranging Test setup Test setup Outer code - Initial ranging Test procedure outer code other bursts	48 48 49 49 49 49 50 50 51
33 34 35 36 37 38 39 40 41 42 43 44 45 46	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1	Test procedure outer code - Information Block Length Test setup Test procedure idomization with programmable seed Test setup Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code - Initial ranging Test procedure outer code other bursts Test setup	48 48 49 49 49 49 50 50 51 51
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2	Test procedure outer code - Information Block Length Test setup Test procedure idomization with programmable seed Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code - Initial ranging Test procedure outer code other bursts Test setup Test setup Test procedure outer code other bursts Test setup Test setup Test procedure	48 48 48 49 49 49 50 50 51 51 51
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe	Test procedure outer code - Information Block Length Test setup Test procedure domization with programmable seed Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code other bursts Test setup Test setup Outer code other bursts Test procedure Codeword operation	48 48 49 49 49 50 50 51 51 51 52
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1	Test procedure outer code - Information Block Length Test setup Test procedure idomization with programmable seed Test setup Test procedure outer code - Initial ranging Test setup Test setup Test setup Test setup Test setup Test setup Test procedure outer code other bursts Test setup Test setup Test procedure outer code other bursts Test procedure outer code other bursts Test procedure outer code other bursts Test setup Test procedure outer code other bursts Test procedure <	48 48 48 49 49 49 50 50 51 51 51 52 52
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.11.2	Test procedure outer code - Information Block Length Test setup Test procedure idomization with programmable seed Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code other bursts Test setup Test procedure ed codeword operation Test setup Test procedure	48 48 48 49 49 50 50 51 51 51 52 52 52 52
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.11.2 9.2.12 Sho	Test procedure outer code - Information Block Length Test setup Test procedure idomization with programmable seed Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code other bursts Test setup Test procedure outer code other bursts Test procedure codeword operation Test setup Test procedure rest setup Test procedure rest setup Test procedure rest setup Test setup Test setup Test procedure rest setup Test setup Test setup Test setup Test procedure rest setup Test procedure rest setup Test procedure rest procedure Test procedure Test procedure	48 48 48 49 49 49 50 50 50 51 51 51 52 52 52 53
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.11.2 9.2.12 Sho 9.2.12.1	Test procedure outer code - Information Block Length Test setup Test procedure idomization with programmable seed Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code other bursts Test setup Test setup Test procedure outer code other bursts Test procedure codeword operation Test setup Test procedure rest procedure rest setup Test procedure rest setup Test procedure rest procedure	48 48 48 49 49 49 50 50 50 51 51 51 52 52 52 53 53 53
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.11.2 9.2.12 Sho 9.2.12.1 9.2.12.2	Test procedure outer code - Information Block Length Test setup Test procedure idomization with programmable seed Test setup Test procedure outer code - Initial ranging Test setup Test setup Test setup Test procedure outer code - Initial ranging Test setup Test procedure outer code other bursts Test setup Test setup Test procedure outer code other bursts Test procedure codeword operation Test setup Test procedure rest procedure rest procedure rest procedure rest procedure Test procedure	48 48 49 49 49 50 50 50 51 51 51 52 52 52 53 53 53 53
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55	9.2.7 RS 9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.2 9.2.12 Sho 9.2.12.1 9.2.12.2 9.2.13 RC	Test procedure outer code - Information Block Length Test setup Test procedure domization with programmable seed Test setup Test procedure outer code - Initial ranging Test setup Test setup Test setup Test setup Test setup Test setup Test procedure outer code other bursts Test setup Test setup Test procedure outer code other bursts Test procedure outer code other bursts Test procedure outer code other bursts Test procedure ed codeword operation Test setup Test procedure rest procedure rest procedure Test procedure Test setup Test setup Test procedure Codeword operation Test setup Test procedure Codeword operation Test setup Test procedure Codeword	48 48 48 49 49 50 50 50 51 51 51 52 52 52 53 53 53 54
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.11.2 9.2.12 Sho 9.2.12.1 9.2.12.2 9.2.13 BCO 9.2.13 1	Test procedure outer code - Initial ranging Test setup Test procedure outer code other bursts Test setup Test procedure outer code other bursts Test procedure ed codeword operation Test setup Test procedure rest setup Test procedure ed codeword operation Test setup Test procedure rest setup Test procedure rest setup Test procedure Cinner code Test setup	48 48 48 49 49 50 50 50 51 51 51 52 52 53 53 54 54
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57	9.2.7 RS 9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.11.2 9.2.12 Sho 9.2.12.1 9.2.12.2 9.2.13 BCC 9.2.13.1 9.2.13.2	Test procedure. Test setup Test procedure. idomization with programmable seed Test setup Test setup Test procedure. outer code - Initial ranging. Test setup Test setup Test setup Test setup Test setup Test procedure. outer code other bursts Test setup Test procedure. outer code other bursts Test procedure. outer code other bursts Test procedure. ed codeword operation Test setup Test procedure. rest procedure. rest setup Test procedure. codeword operation Test procedure. C inner code. Test setup Test setup Test procedure. C inner code. Test procedure. <td> 48 48 48 49 49 50 50 51 51 51 52 52 53 53 54 54 54</td>	48 48 48 49 49 50 50 51 51 51 52 52 53 53 54 54 54
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58	9.2.7 RS 9 9.2.7 RS 9 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9 9.2.9.1 9.2.9.2 9.2.10 RS 9 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.11.2 9.2.12 Sho 9.2.12.1 9.2.12.2 9.2.13 BCO 9.2.13.1 9.2.13.2 9.2.14 Pure	Test procedure. Test setup Test procedure. idomization with programmable seed Test setup Test setup Test procedure. outer code - Initial ranging. Test setup Test setup Test setup Test setup Test setup Test setup Test procedure. outer code other bursts Test setup Test procedure. outer code other bursts Test procedure. code word operation Test setup Test procedure. rest setup Test procedure. rest setup Test procedure. rest setup Test procedure. rest setup Test setup Test procedure. C inner code. Test procedure. Test procedure. C inner code. Test procedure. Test procedure. Test procedure. Test procedure. Test procedure.	48 48 48 49 49 50 50 51 51 51 51 52 53 53 53 54 54 54
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59	9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.12 9.2.12 Sho 9.2.12.1 9.2.12 Sho 9.2.13 BCC 9.2.13.1 9.2.13.2 9.2.14 Bur	Test procedure	48 48 48 49 49 50 50 51 51 51 51 52 52 53 53 54 54 55 55
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61	9.2.7 RS 9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.12 9.2.12 Sho 9.2.12.1 9.2.12 Sho 9.2.13 BCC 9.2.13 BCC 9.2.13.1 9.2.13.2 9.2.14 Bur 9.2.14.1	Test procedure	48 48 48 49 49 49 50 50 50 51 51 51 51 52 52 53 53 54 54 55
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62	9.2.7 RS 9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.12.2 9.2.12 Sho 9.2.13 BCC 9.2.13.1 9.2.13.2 9.2.14 Bur 9.2.14.1 9.2.14.2	Test procedure	48 48 48 49 49 50 50 50 50 51 51 51 52 52 53 53 54 55 55
33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63	9.2.7 RS 9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.12.2 9.2.12 Sho 9.2.12.1 9.2.13 BCC 9.2.13.1 9.2.13.2 9.2.14 Bur 9.2.14.1 9.2.14.2 9.2.15 Moo	rest procedure	48 48 48 49 49 50 50 50 51 51 51 52 52 53 53 53 54 55 55 55
$\begin{array}{c} 33\\ 34\\ 35\\ 36\\ 37\\ 38\\ 39\\ 40\\ 41\\ 42\\ 43\\ 44\\ 45\\ 46\\ 47\\ 48\\ 49\\ 50\\ 51\\ 52\\ 53\\ 54\\ 55\\ 56\\ 57\\ 58\\ 59\\ 60\\ 61\\ 62\\ 63\\ 64 \end{array}$	9.2.7 RS 9.2.7 RS 9.2.7 RS 9.2.7.1 9.2.7.2 9.2.8 Ran 9.2.8.1 9.2.8.2 9.2.9 RS 9.2.9 RS 9.2.9.1 9.2.9.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.10 RS 9.2.10.1 9.2.10.2 9.2.11 Fixe 9.2.11.1 9.2.12 Sho 9.2.12.1 9.2.13 BCC 9.2.13.1 9.2.13.2 9.2.14 Bur 9.2.14.1 9.2.14.2 9.2.15 Moo 9.2.15.1	rest procedure	48 48 48 49 49 50 50 51 51 51 51 52 53 53 53 54 55 55 56 56

1	9.2.16 RS outer code - Information Block Length	
2	9.2.16.1 Test setup	
3	9.2.16.2 Test procedure	
4	9.2.17 Channel allocation	
5	9.2.17.1 Test setup	
7	9.2.17.2 Test procedure	58
8	9.2.18 Symbol timing accuracy	59
9	0.2.18 Test setup	59
10	0.2.18.2 Test precedure	
11	9.2.10.2 Test procedure	
12	9.2.19 Carrier nequency	
13	9.2.19.1 Test setup	
14	9.2.19.2 Test procedure	
16	9.2.20 Spectral mask	61
17	9.2.20.1 Test setup	61
18	9.2.20.2 Test procedure	
19	9.2.21 Spurious	
20	9.2.21.1 Test setup	
21	9.2.21.2 Test procedure	
22	9.2.22 Tx RMS Power level	
23 24	9.2.22.1 Test setup	
25	9.2.22.2 Test procedure	
26	9 2 23 Ramp up / down time	64
27	9 2 23 1 Test setun	64
28	0.2.23.1 Tost setup	
29	0.2.24 Modulation accuracy	
30 31	0.2.24 Modulation accuracy	
32	9.2.24.1 Test setup	
33	9.2.24.2 Test procedure	
34	9.2.25 Rx Dynamic range	
35	9.2.25.1 Test setup	
36	9.2.25.2 Test procedure	
37	9.2.26 BER performance threshold	
38	9.2.26.1 Test setup	67
39 40	9.2.26.2 Test procedure	
40	9.2.27 1st adjacent channel interference	
42	9.2.27.1 Test setup	
43	9.2.27.2 Test procedure	
44	9.2.28 2nd adjacent channel interference	
45	9.2.28.1 Test setup	
46	9.2.28.2 Test procedure	70
47 18	10 Annex A	71
40 49	10.1 Requirements for the test laboratories	
50	10.1 Text equipment	
51	12. Conoral test plotform	
52	12. Octicial lest platform	
53	15. Carrier frequencies	

Proposal for Radio Conformance Test specification for P1802.16.3

Lars Lindh

Nokia

1. Introduction

To evaluate conformance of a particular implementation of a radio interface, it is necessary to have a common radio testing document with common radio test procedures as outlined in the Test Suite Structure and Test Purposes (TSS&TP) document. The Radio Conformance Test (RCT) specification document serves this purpose.

2. Scope

This document is a specification for the radio conformance test of the 802.16 PHY layer.

The scope of the document is as follows:

It specifies the test procedures and the test conditions in order to ensure the interoperability between equipment developed by different manufacturers. This is achieved by testing the baseband and RF signal processing functionalities in the transmitter and the receiver. The specification covers basic RF aspects, including the radio frequency channel plans and those other parameters necessary for radio regulatory coexistence purposes.

The tests correspond to the requirements in the Test Purposes in the IEEE 802.16 10–66 GHz conformance testing. Sub-part 2: "Test Suite Structure and Test Purposes (TSS & TP) Specification". The requirements are given in conjunction with the tests.

Requirements for the test laboratories are given in Annex A

3. Purpose

In order to ensure interoperability between the equipment built by different manufacturers from the PHYperspective and compliance with IEEE Std 802.16-200: "Local and Metropolitan Area Networks – Part 16: Standard Air Interface for Fixed Wireless Access Systems", standardized conformance test procedures for the PHY specifications are specified. However, for supporting these test procedure some basic functionalities from the MAC layer are required.

In order to perform these tests some dedicated test equipment and testing capabilities are required by the test laboratories.

4. References

The following documents contain provisions, which, through reference in this text, constitute provisions of the present document.

References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific. For a specific reference, subsequent revisions do not apply.

For non-specific references, the latest versions apply.

- [1] IEEE Std 802.16-200: "Local and Metropolitan Area Networks Part 16: Standard Air Interfacefor Fixed Wireless Access Systems"
- [2] ISO/IEC 9646-1: "Information technology Open Systems Interconnection Conformance testing methodologyand framework Part 1: General concepts"
- [3] ISO/IEC 9646-7: "Information technology Open Systems Interconnection Conformance testing methodologyand framework Part 6: Protocol profile test specification"
- [4] ISO/IEC 9646-7: "Information technology Open Systems Interconnection Conformance testing methodologyand framework Part 7: Implementation Conformance Statements"
- [5] IEEE 802.16c-2002: "Amendment to IEEE Standard for Local and Metropolitan Area Networks Part 16:Air Interface for Broadband Fixed Wireless Access Systems – Detailed System profiles for 10-66 GHz"
- [6] IEEE P1802.16.1/D1-2002: "Protocol Implementation Conformance Statements for 10-66 GHz Wireless-MAN–SC Air Interface"
- [7] IEEE 802.16 10–66 GHz conformance testing. Sub-part 2: "Test Suite Structure and Test Purposes (TSS & TP) Specification"

5. Definitions abbreviations

5.1 Definitions

For the purposes of this document, the terms defined in [1], as amended by [5], [6], and [7] apply.

5.2 Acronyms

For the purposes of this document, the acronyms defined in [1], as amended by [5], [6], and [7] apply.

6. Overview

The IEEE 802.16 Part 16: "Air Interface for Fixed Broadband Wireless Access Systems" specifies the 802.16 transmission scheme in order to guarantee interoperability between equipment developed by different manufacturers. This is achieved by describing all signal processing structures and all protocol issues.

The 802.16 Radio Conformance Testing specification (RCT) is intended to specify the conformance testing procedures and requirements (in both directions for both the BS and SS) of all parameters specified in the physical layer. The test requirements are defined in IEEE 802.16 10–66 GHz conformance testing. Sub-part 2: "Test Suite Structure and Test Purposes (TSS & TP) Specification" and are also described in conjunction with the test procedures.

2003-05-08

In addition to the main requirements of the 802.16 RCT, Test Laboratory equipment requirements are described in Annex A.

The general block diagram of the 802.16 downlink and uplink system is illustrated in Figure 1.



Figure 1—PHY layer conceptual block diagram

6.1 General Requirements

The general block-diagram with naming of test interfaces is given in Figure 2. The block diagram describes only conceptually the main system components and interfaces, and does not dictate any implementation. The manufacturer shall during the testing occasion make the signals in the listed interfaces available for measurements.

The following abbreviations have been used:

- A: Antenna interface
- M: MAC interface
- SC: Symbol Clock interface



Figure 2—General block diagram

6.2 Test Conditions

7. Environmental requirements

8. Required Tests

The required tests are described in the IEEE 802.16 10–66 GHz conformance testing. Sub-part 2: "Test Suite Structure and Test Purposes (TSS & TP) Specification" [7] and listed in table 1.Test Procedures

	Mandatory	Optional
Parameters for the Subscriber Station		
Downlink		
RS outer code $t = 10 / BCC$ - frame control	М	
RS outer code other bursts	М	
Fixed codeword operation	М	
Shortened last codeword operation	М	
Burst preamble	М	
Modulation	М	
RS outer code - information block length	М	
Uplink		
Randomization with programmable seed	М	
RS outer coder - initial ranging	М	
RS outer code other bursts	М	
Fixed codeword operation	М	
Shortened last codeword operation	М	
BCC inner code	М	
Burst preamble	М	
Modulation	М	
RS outer code - information block length	М	
Minimum performance		
Channel allocation	М	
Transmitter dynamic range	М	
Receiver dynamic range	М	
Transmitter RMS power level at maximum power level setting	М	

Table 1—Required tests

Transmitter power level adjustment step accuracy	М	
Symbol timing accuracy	М	
Transmitter burst timing	М	
Carrier frequency	М	
Spectral mask	М	
Ramp up / ramp down	М	
Output noise power spectral density	М	
Modulation accuracy	М	
BER performance threshold	М	
Transition time from Tx to Rx and from Rx to Tx	М	
1st adjacent channel interference	М	
2nd adjacent channel interference	М	
Parameters for the Base Station		
Downlink		
BS outer code $t = 10 / BCC$ - frame control	М	
RS outer code other bursts	M	
Fixed codeword operation	M	
Shortened last codeword operation	M	
Burst preamble	M	
Modulation	M	
RS outer code - information block length	M	
Unlink	111	
Pandomization with programmable seed	Μ	
Randoniization with programmable seed	M	
RS outer code other bursts	M	
Fixed codeword operation	M	
Shortened last codeword operation	M	
BCC inner code	M	
Burst preamble	M	
Modulation	M	
PS outer code information block length	M	
Minimum performance	1V1	
Channel allocation	М	
	IVI M	
Symbol timing accuracy	IVI	

Table 1—Required tests (continued)

Carrier frequency	М
Spectral mask	М
Spurious	М
Transmitter RMS power level	М
Ramp up / ramp down	М
Modulation accuracy	М
Receiver dynamic range	М
BER performance threshold	М
1st adjacent channel interference	М
2nd adjacent channel interference	М

Table 1—Required tests (continued)

9. Test Procedures

Some test procedures assume that the counterpart for the IUT, denoted "Test BS", "Test SS" or "Tester", has some additional features not mandated by the 802.16 standard. These features are solely there to aid the test procedures. Typical tester functions are: capability to eject gating signals for the measurement instruments, special software for requesting a special behaviour of the IUT. The Tester also has significantly better and known output signal quality than the IUT.

9.1 Tests for the Subscriber Station

9.1.1 RS outer code t = 10 / BCC - frame control

9.1.1.1 Test setup

Figure 3 shows the test setup for testing the RS outer code t = 10 / BCC - frame control.



Figure 3—Test setup for RS outer code t = 10 / BCC - frame control

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.1.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account

A connection is setup between the Test BS and the SS. The Test BS is setup to send data consisting of frames filled with QPSK modulated data and coded with Block Convolutional Code + Reed Solomon t = 4. The number of information bytes in a RS block shall be 128. The data received at the SS is compared with the transmitted data.

The attenuator is adjusted until the received power is $-98 + 10\log(B) dBm$, where B is the symbol rate in MBaud.

The bit error rate (BER) is measured at the SS from the payload of the accepted packets and shall be less than $1.12 \ 10^{-7}$. This test procedure, using the FEC, is in conformance with the BER requirement of uncoded QPSK in the base specification [1]. The fact that the packets are received correctly proves that the decoding of the frame control portion, BCC + Reed-Solomon t=10, works correctly. The measured BER is another proof of that the BCC decoding works satisfactorily.

9.1.2 RS outer code other bursts

9.1.2.1 Test setup

Figure 4 shows the test setup for testing the RS outer code other bursts.



Figure 4—Test setup for RS outer code other bursts

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.2.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS transmits the bursts with QPSK modulation, no BCC coding, RS coding with t = 0, 4, 8 and 12, and information bytes = 128.

The downlink frame is filled with bursts of test data. The received power is adjusted until the S/N is 10 dB above the actual threshold. The data received at the SS is checked for correctness.

The Test BS inserts alternatively 0, 4, 8 or 12 erraneous bytes in the codeword corresponding to t = 0, 4, 8 and 12. The SS shall receive the data correctly.

The Test BS inserts alternatively 1, 5, 9 or 13 erraneous bytes in the codeword corresponding to t = 0, 4, 8 and 12. The SS shall not be able to receive the data correctly.

9.1.3 Fixed codeword operation

9.1.3.1 Test setup

Figure 5 shows the test setup for testing the RS fixed codeword operation.



Figure 5—Test setup for Fixed codeword operation

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.3.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS transmits the bursts with Reed-Solomon using Fixed codeword option, QPSK modulation, no BCC coding, RS coding with t = 8 and information bytes = 128.

The downlink frame is filled with bursts of test data. The number of bytes in the downlink frame must be not be a multiple of 128. The received power is adjusted until the S/N is 10 dB above the actual threshold.

9.1.4 Shortened last codeword operation

9.1.4.1 Test setup

Figure 6 shows the test setup for testing the RS shortened codeword operation.



Figure 6—Test setup for Shortened codeword operation

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.4.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS transmits the bursts with Reed-Solomon using Shortened codeword option, QPSK modulation, no BCC coding, RS coding with t = 8 and information bytes = 128.

The downlink frame is filled with bursts of test data. The number of bytes in the downlink frame must be not be a multiple of 128. The received power is adjusted until the S/N is 10 dB above the actual threshold.

The SS receives the data correctly.

9.1.5 Burst preamble

9.1.5.1 Test setup

Figure 7 shows the test setup for testing the burst preamble.



Figure 7—Test setup for burst preamble

Instruments needed: Directional coupler Attenuator Average power meter

9.1.5.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS is setup to transmit data in the TDMA portion of the frame.

The downlink frame is filled with bursts of test data. The received power is adjusted until the S/N is 10 dB above the actual threshold.

The SS receives the data correctly.

The fact that the SS receives the data correctly proves that the SS is able to synchonize to burst preambles, which are in the beginning of each TDMA burst.

9.1.6 Modulation

9.1.6.1 Test setup

Figure 8 shows the test setup for testing the modulation.



Figure 8—Test setup for modulation

Instruments needed: Directional coupler Attenuator Average power meter

9.1.6.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS is setup to transmit data in the TDM and TDMA portions of the frame with all modulation schemes supported by the SS.

The downlink frame is filled with bursts of test data. The received power is adjusted until the S/N is 10 dB above the actual thresholds.

The SS receives the data correctly.

9.1.7 RS outer code - Information Block Length

9.1.7.1 Test setup

Figure 9 shows the test setup for testing the RS outer code - Information Block Length.



Figure 9—Test setup for RS outer code - Information Block Length

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.7.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. QPSK modulation, no BCC coding, RS coding with information block length = 6, 128, 239 and t = 8 are used.

The downlink frame is filled with bursts of test data. The received power is adjusted until the S/N is 10 dB above the actual threshold.

The SS shall receive the data correctly.

9.1.8 Randomization with programmable seed

9.1.8.1 Test setup

Figure 10 shows the test setup for randomization with programmable seed.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.8.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use burst profiles with different seed values for the randomization.

Data is transmitted in the uplink.

9.1.9 RS outer coder - Initial ranging

9.1.9.1 Test setup

Figure 11 shows the test setup for testing the RS outer code - Initial ranging.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.9.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS.

The Test BS commands the SS to use burst profiles with RS parameter t = 10 for initial ranging.

The SS sends a RNG-REQ mesage in the initial ranging opportunity. The Test BS receivs the data correctly.

9.1.10 RS outer code other bursts

9.1.10.1 Test setup

Figure 12 shows the test setup for testing the RS outer code other bursts.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.10.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use burst profiles with the RS parameter t = 0, 4, 8 or 12, and information bytes 128 are used.

Data is transmitted in the uplink

9.1.11 Fixed codeword operation

9.1.11.1 Test setup

Figure 13 shows the test setup for testing the RS fixed codeword operation.



Figure 13—Test setup for Fixed codeword operation

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.11.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use burst profiles with Reed-Solomon Fixed codeword option, QPSK modulation, no BCC coding, RS coding with t = 8 and information bytes = 128 in all uplink bursts. The number of bytes in the downlink frame must be not be a multiple of 128.

Data is transmitted in the uplink.

The Test BS receives the data correctly.

9.1.12 Shortened last codeword operation

9.1.12.1 Test setup

Figure 14 shows the test setup for testing the RS shortened codeword operation.



Figure 14—Test setup for Shortened codeword operation

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.12.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use burst profiles with Reed-Solomon Shortened codeword, QPSK modulation, no BCC coding, RS coding with t = 8 and information bytes = 128 in all uplink bursts. The number of bytes in the downlink frame must be not be a multiple of 128.

Data is transmitted in the uplink.

9.1.13 BCC inner code

9.1.13.1 Test setup

Figure 15 shows the test setup for testing the BCC innercode operation.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.13.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use burst profiles with BCC inner code in all uplink bursts.

Data is transmitted in the uplink.

9.1.14 Burst preamble

9.1.14.1 Test setup

Figure 16 shows the test setup for testing the burst preamble.



Figure 16—Test setup for burst preamble

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.14.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use burst profiles with different preamble lengths in the uplink bursts.

Data is transmitted in the uplink.

9.1.15 Modulation

9.1.15.1 Test setup

Figure 17 shows the test setup for testing the modulation schemes.





Instruments needed: Directional coupler Attenuator Average power meter

9.1.15.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use burst profiles with the different modulation schemes supported by the SS in the uplink bursts.

Data is transmitted in the uplink.

The Test BS receives the data correctly.

9.1.16 RS outer code - Information Block Length

9.1.16.1 Test setup

Figure 18 shows the test setup for testing the RS outer code - Information Block Length.





Instruments needed: Directional coupler Attenuator Average power meter

9.1.16.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use burst profiles with the the RS parameter Information block length = 6, 128 and 239. RS parameter t = 8.

Data is transmitted in the uplink.

9.1.17 Channel allocation

9.1.17.1 Test setup

Figure 19 shows the test setup for testing the channel allocation.



Figure 19—Test setup for Channel allocation

Instruments needed: Circulator Attenuator Frequency meter

9.1.17.2 Test procedure

The Test BS and the SS are set in the CW test mode. The attenuator is adjusted for an optimal reception level

The Test BS generates frequencies which are multiples of 250 KHz in frequency range declared by the SS manufacturer

The SS is able to lock to the frequencies generated by the Test BS. For TDD the frequencies for the Test BS and SS shall be equal and for FDD they shall be separated by the duplex distance declared by the manufacturer.

9.1.18 Tx Dynamic range

9.1.18.1 Test setup

Figure 20 shows the test setup for testing the Tx Dynamic Range



Figure 20—Test setup for Tx Dynamic Range

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.18.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use the most robust burst profile. Data is transmitted in the uplink.

The attenuator is slowly adjusted to its lowest value and as a consequency the SS shall decrease its transmit power until the minimum operable value is achieved. The transmitted power is measured and recorded. The attenuator is then slowly increased until the SS reaches its maximum operable value. The transmitted power is measured and recorded.

The difference between the two power values is the Tx dynamic range and shall be >= 40 dB.

9.1.19 Rx Dynamic range

9.1.19.1 Test setup

Figure 21 shows the test setup for testing the Rx Dynamic Range



Figure 21—Test setup for Rx Dynamic Range

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.19.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use the most robust burst profile. Data is transmitted in the downlink.

The attenuator is slowly adjusted to its lowest operable value. The power of the received signal is measured and recorded. The attenuator is then slowly increased until the the maximum operable value is reached. The power is measured and recorded.

The difference between the two power values is the Rx dynamic range and shall be >= 40 dB.

9.1.20 Tx Power level at maximum power level setting

9.1.20.1 Test setup

Figure 20 shows the test setup for testing the Tx Power level at maximum power level setting





Instruments needed: Directional coupler Attenuator Average power meter

9.1.20.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use the most robust burst profile. Data is transmitted in the uplink.

The attenuator is slowly adjusted towards its highest value until the SS increases its transmit power to its maximum. The Test BS shall receive the data correctly. The power is measured

The power shall be >= 15 dBm.

9.1.21 Tx Power level adjustment step accuracy

9.1.21.1 Test setup

Figure 23 shows the test setup for testing the Tx Power level adjustment step accuracy.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.21.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use the most robust burst profile at the bottom, medium and top values of the transmit power range. Data is transmitted in the uplink. The transmit power is measured

The Test BS commands the SS to adjust its transmit power level with the step sizes +/- [0.5 - 2.0] dB, +/- [2 - 5] dB and > +/- 5 dB.

The measured change in power shall be monotonically positive (negative), +/- 2 dB of the requested change, +/- 5 dB of the requested change.

9.1.22 Symbol timing accuracy

9.1.22.1 Test setup

Figure 24 shows the test setup for testing the symbol timing accuracy.



Figure 24—Test setup for symbol timing accuracy

Instruments needed:	Directional coupler
	Attenuator
	Jitter meter
	Phase comparator

9.1.22.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The downlink frame is filled with bursts of QPSK modulated data. The received power is adjusted until the S/N is 10 dB above the actual threshold.

The jitter of the SS symbol clock is measured. Peak-to-peak jitter during a 2 sec measurement period must be less than 2 %.

The symbol clock of the Test BS and SS are connected to a phase comparator. The SS shall be locked to the Test BS symbol clock.

9.1.23 Tx Burst timing

9.1.23.1 Test setup

Figure 25 shows the test setup for testing the Tx Burst timing.



Figure 25—Test setup for Tx Burst timing

Instruments needed:	Directional coupler
	Attenuator
	Downconveter
	Oscilloscope

9.1.23.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. Data is transmitted in the uplink with QPSK modulation.

The Test BS defines the burst at different positions with 0.25 symbol time resolution by using unsolicited RNG-RSP messages.

The actual position of the burst is compared with the gating signal provided by the Test BS. The difference shall be less than 0.125 symbol time.

9.1.24 Carrier frequency

9.1.24.1 Test setup

Figure 26 shows the test setup for testing the carrier frequency.



Figure 26—Test setup for Carrier frequency

Instruments needed: Circulator Attenuator Frequency meter

9.1.24.2 Test procedure

The Test BS and the SS are set in the CW test mode. The attenuator is adjusted for an optimal reception level

The Test BS generates frequencies which are multiples of 250 KHz in frequency range declared by the SS manufacturer

The SS is able to lock to the frequencies generated by the Test BS. For TDD the frequencies for the Test BS and SS shall be equal and for FDD they shall be separated by the duplex distance declared by the manufacturer.

9.1.25 Spectral mask

9.1.25.1 Test setup

Figure 27 shows the test setup for testing the spectral mask.



Figure 27—Test setup for Spectral mask

Instruments needed: Circulator Attenuator Spectrum Analyzer

9.1.25.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use the most robust burst profile. Data is transmitted in the uplink.

The spectrum is measured with a spectrum analyzer. The spectrum shall not exceed the mask given by the local regulator.

The settings of the spectrum analyzer shall be according to table 2

Paramter	SS
Center frequency	Actual
Span	140 MHz
Scan time	Auto
Resolution bandwidth	300 KHz
Video bandwidth	100 KHz

Table 2—Spectrum analyzer settings
9.1.26 Ramp up / down time

9.1.26.1 Test setup

Figure 28 shows the test setup for testing the Ramp up / down time.



Figure 28—Test setup for Ramp up / down time

Instruments needed:	Directional coupler
	Attenuator
	Downconerter
	Oscilloscope

9.1.26.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. Data is transmitted in the uplink with QPSK modulation.

The ramp up/ ramp down times are measured and shall be <= 24 symbols.

9.1.27 Output noise power spectral density when Tx is not transmitting

9.1.27.1 Test setup

Figure 29 shows the test setup for testing the Output noise power spectral density.





Instruments needed: Directional coupler Attenuator Average power meter

9.1.27.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

The SS is operable, listening to the downlink. No connections are setup.

The output noise power emitted from the SS when not trasnmitting shall be <= -80 dBm/Mhz

9.1.28 Modulation accuracy

9.1.28.1 Test setup

Figure 29 shows the test setup for testing the modulation accuracy.



Figure 30—Test setup for Modulation accuracy

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.28.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

The system is setup for a BER test for the Test BS. The sensitivity value P for the Test BS for $BER=10^{-3}$ is measured using a high quality transmitter as the signal source.

The sensitivity value M for the Test BS for $BER=10^{-3}$ is measured using the SS as the signal source. The difference M - P shall be less than or equal to the values in column 2 in table 3. The corresponding EVM figures are shown in columns 3 and 4.

	Tx implementation margin	EVM no equalizer	EVM equalizer
QPSK	0.5 dB	12 %	10 %
16-QAM	1.0 dB	6 %	3 %
64-QAM	1.5 dB		1.5 %

Table	3—E\	/M req	luirem	ents
-------	------	--------	--------	------

9.1.29 BER performance threshold

9.1.29.1 Test setup

Figure 31 shows the test setup for testing the BER performance threshold.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.29.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS transmits the bursts with all supported modulation schemes and no FEC. CRC is disabled

The BER is computed from the payload of the data packets accepted by the SS. The attenuator is adjusted until BER = 10^{-3} and then 10^{-6} . The input power is measured and shall be according to table 4. B is the symbol rate in MBaud.

	BER 10 ⁻³	BER 10 ⁻⁶
QPSK	-94 + 10log(B) dBm	-90 + 10log(B) dBm
16-QAM	-87 + 10log(B) dBm	-83 + 10log(B) dBm
64-QAM	-79 + 10log(B) dBm	-74 + 10log(B) dBm

Table 4—BER	performance	threshold	sensitivity	values
-------------	-------------	-----------	-------------	--------

9.1.30 Transition time from Tx to Rx and from Rx to Tx

9.1.30.1 Test setup

Figure 32 shows the test setup for testing the Transition time from Tx to Rx and from Rx to Tx.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.30.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The attenuator is adjusted for an optimal signal quality. The Test BS provides downlink and uplink maps with a transition time between the end of an uplink burst and the start of an downlink burst of 2 us for TDD and 20 us for H-FDD and with transition times between the end of an downlink burst and start of an uplink burst of 2 us for TDD and 20 us for H-FDD. Uplink and downlink data is generated.

The SS succesfully trasnmits uplink data and receives downlink data.

9.1.31 1st adjacent channel interference

9.1.31.1 Test setup

Figure 33 shows the test setup for testing the 1st adjacent channel interference.



Figure 33—Test setup for 1st adjacent channel interference

Instruments needed:

Directional coupler Attenuators Average power meter Power combiner

9.1.31.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuators are calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account. Attenuators 1 and 2 are used to adjust the ratio between the useful and interfering signals. Attenuator 3 is used for adjusteing the absolut signal level at the receiver and can be held at a constant value of 10 dB. The signal generator transmits a similar signal as the useful signal on the first adjacent channel.

A connection is setup between the Test BS and the SS. Attenuator 2 is set to its maximum value and the signal generator is switched off. Downlink QPSK data is generated and attenuator 1 is adjusted for BER = 10^{-3} (10⁻⁶). The signal power is increased by 3 (1) dB and the power is measured.

The signal generator is switched on and attenuator 2 is decreased until BER = 10^{-3} (10^{-6}) is achieved. The Test BS is turned off and the power of the interfereing signal is measured.

The procedure is repeated for the other modulation schemes, 1 dB degradation and BER = 10^{-6} . The C/I values shall be according to tables 5 and 6.

.

	1 dB degradation	3 dB degradation
QPSK	-5 dB	-9 dB
16-QAM	+2 dB	-2 dB
64-QAM	+9 dB	+5 dB

Table 5—1st adjacent channel interferenece BER10⁻³

Table 6—1st adjacent channel interference BER=10⁻⁶

	1 dB degradation	3 dB degradation
QPSK	-1 dB	-5 dB
16-QAM	+6 dB	+2 dB
64-QAM	+13 dB	+9 dB

9.1.32 2nd adjacent channel interference

9.1.32.1 Test setup

Figure 34 shows the test setup for testing the 2nd adjacent channel interference.



Figure 34—Test setup for 2nd adjacent channel interference

Instruments needed:

Directional coupler Attenuators Average power meter Power combiner

9.1.32.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuators are calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account. Attenuators 1 and 2 are used to adjust the ratio between the useful and interfering signals. Attenuator 3 is used for adjusteing the absolut signal level at the receiver and can be held at a constant value of 10 dB. The signal generator transmits a similar signal as the useful signal on the second adjacent channel.

A connection is setup between the Test BS and the SS. Attenuator 2 is set to its maximum value and the signal generator is switched off. Downlink QPSK data is generated and attenuator 1 is adjusted for BER = 10^{-3} (10⁻⁶). The signal power is increased by 3 (1) dB and the power is measured.

The signal generator is switched on and attenuator 2 is decreased until BER = 10^{-3} (10^{-6}) is achieved. The Test BS is turned off and the power of the interfereing signal is measured.

The procedure is repeated for the other modulation schemes, 1 dB degradation and BER = 10^{-6} . The C/I values shall be according to tables 7 and 8.

.

	1 dB degradation	3 dB degradation
QPSK	-30 dB	-34 dB
16-QAM	-22 dB	-27 dB
64-QAM	-16 dB	-20 dB

Table 7—2nd adjacent channel interferenece BER10⁻³

Table 8—2nd adjacent channel interference BER=10⁻⁶

	1 dB degradation	3 dB degradation
QPSK	-26 dB	-30 dB
16-QAM	-20 dB	-23 dB
64-QAM	-12 dB	-16 dB

9.1.33 Tx Power level absolute accuracy

9.1.33.1 Test setup

Figure 35 shows the test setup for testing the Tx Power level absolute accuracy.



Figure 35—Test setup for Tx Power level absolute accuracy

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.1.33.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the SS. The Test BS commands the SS to use the most robust burst profile at the bottom, medium and top values of the transmit power range. Data is transmitted in the uplink.The transmit power is measured

The Test BS commands the SS to adjust its transmit power level to an absolute level in the current power range. The Test BS shall receive the data correctly.

The accuracy of the power level shall be +/-6 dB.

3 4 6 24

9.2 Tests for the Base Station

9.2.1 RS outer code t = 10 / BCC - frame control

9.2.1.1 Test setup

Figure 36 shows the test setup for testing the RS outer code t = 10 / BCC - frame control.



Figure 36—Test setup for RS outer code t = 10 / BCC - frame control

Instruments needed: Directional coupler Attenuator Average power meter

9.2.1.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account

A connection is setup between the BS and the Test SSTest SS. The attenuator is increased until the Test SS requests the BS to use the most robust burst profile. Data is send in the downlink.

The Test SS receives the data correctly.

9.2.2 RS outer code other bursts

9.2.2.1 Test setup

Figure 37 shows the test setup for testing the RS outer code other bursts.



Figure 37—Test setup for RS outer code other bursts

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.2.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The Test SS requests the BS to use bursts profiles with RS parameter t = 0, 4, 8 and 12. Data is transmitted in the downlink.

The SS shall receive the data correctly.

9.2.3 Fixed codeword operation

9.2.3.1 Test setup

Figure 38 shows the test setup for testing the RS fixed codeword operation.



Figure 38—Test setup for Fixed codeword operation

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.3.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The Test SS requests the BS to use burst profiles with fixed codeword operation.

Data is transmitted in the downlink.

The SS receives the data correctly.

9.2.4 Shortened last codeword operation

9.2.4.1 Test setup

Figure 39 shows the test setup for testing the RS shortened codeword operation.



Figure 39—Test setup for Shortened codeword operation

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.4.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The Test SS requests the BS to use burst profiles with shortened codeword operation.

Data is transmitted in the downlink.

The SS receives the data correctly.

9.2.5 Burst preamble

9.2.5.1 Test setup

Figure 40shows the test setup for testing the burst preamble.



Figure 40—Test setup for burst preamble

Instruments needed: Directional coupler Attenuator Average power meter

9.2.5.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the Test BS and the half-duplex Test SS.

Data is transmitted in the TDMA portion of the downlink

The SS receives the data correctly.

9.2.6 Modulation

9.2.6.1 Test setup

Figure 41 shows the test setup for testing the modulation.



Figure 41—Test setup for modulation

Instruments needed: Directional coupler Attenuator Average power meter

9.2.6.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The Test SS requests the BS to use burst profiles with different modulation schemes supported by the BS.

The downlink frame is filled with bursts of test data. The received power is adjusted until the S/N is 10 dB above the actual thresholds.

The SS receives the data correctly.

9.2.7 RS outer code - Information Block Length

9.2.7.1 Test setup

Figure 42 shows the test setup for testing the RS outer code - Information Block Length.



Figure 42—Test setup for RS outer code - Information Block Length

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.7.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. QPSK modulation, no BCC coding, RS coding with information block length = 6, 128, 239 and t = 8 are used.

The downlink frame is filled with bursts of test data. The received power is adjusted until the S/N is 10 dB above the actual threshold.

The SS shall receive the data correctly.

9.2.8 Randomization with programmable seed

9.2.8.1 Test setup

Figure 43 shows the test setup for randomization with programmable seed.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.8.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. Various UL burst profiles are defined differeng only in their seed values. The test NMS requests the BS to use burst profiles with different seed values for the randomization.

Data is transmitted in the uplink.

The BS receives the data correctly.

9.2.9 RS outer code - Initial ranging

9.2.9.1 Test setup

Figure 44 shows the test setup for testing the RS outer code - Initial ranging.



Figure 44—Test setup for RS outer code - Initial ranging

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.9.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS.

The test NMS requests the BS to use burst profiles with RS parameter t = 10.

Data is trasnmitted in the uplink. The Test BS receivs the data correctly.

9.2.10 RS outer code other bursts

9.2.10.1 Test setup

Figure 45 shows the test setup for testing the RS outer code other bursts.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.10.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The test NMS requests the BS to use burst profiles with the RS parameter t = 0, 4, 8 or 12, and information bytes 128 are used.

The uplink frame is filled with bursts of test data. The data received at the BS is checked for correctness.

The Test SS inserts alternatively 0, 4, 8 or 12 erraneous bytes in the codeword corresponding to t = 0, 4, 8 and 12. The BS shall receive the data correctly.

The Test SS inserts alternatively 1, 5, 9 or 13 erraneous bytes in the codeword corresponding to t = 0, 4, 8 and 12. The BS shall not be able to receive the data correctly.

9.2.11 Fixed codeword operation

9.2.11.1 Test setup

Figure 46 shows the test setup for testing the RS fixed codeword operation.



Figure 46—Test setup for Fixed codeword operation

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.11.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The test NMS requests the BS to use burst profiles with Reed-Solomon Fixed codeword option, QPSK modulation, no BCC coding, RS coding with t = 8 and information bytes = 128.

The uplink frame is filled with bursts of test data. The number of bytes in the uplink frame must be not be a multiple of 128.

The BS receives the data correctly.

9.2.12 Shortened last codeword operation

9.2.12.1 Test setup

Figure 47 shows the test setup for testing the RS shortened codeword operation.



Figure 47—Test setup for Shortened codeword operation

Instruments needed: Directional coupler Attenuator Average power meter

9.2.12.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The test NMS requests the BS to use burst profiles with Reed-Solomon Shortened codeword option, QPSK modulation, no BCC coding, RS coding with t = 8 and information bytes = 128.

The uplink frame is filled with bursts of test data. The number of bytes in the uplink frame must be not be a multiple of 128.

The BS receives the data correctly.

9.2.13 BCC inner code

9.2.13.1 Test setup

Figure 48 shows the test setup for testing the BCC innercode operation.





Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.13.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The test NMS requests the BS to use a burst profile with BCC inner code.

Data is transmitted in the uplink.

The BS receives the data correctly.

9.2.14 Burst preamble

9.2.14.1 Test setup

Figure 49 shows the test setup for testing the burst preamble.



Figure 49—Test setup for burst preamble

Instruments needed:	Directional coupler
	Attenuator
	Average power meter

9.2.14.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The test NMS requests the BS to use burst profiles with different preamble lengths.

Data is transmitted in the uplink.

The BS receives the data correctly.

9.2.15 Modulation

9.2.15.1 Test setup

Figure 50 shows the test setup for testing the modulation schemes.



Figure 50—Test setup for the modulation schemes

Instruments needed: Directional coupler Attenuator Average power meter

9.2.15.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The test NMS requests the BS to use burst profiles with the different modulation schemes supported by the SS.

Data is transmitted in the uplink.

The BS receives the data correctly.

9.2.16 RS outer code - Information Block Length

9.2.16.1 Test setup

Figure 51 shows the test setup for testing the RS outer code - Information Block Length.



Figure 51—Test setup for RS outer code - Information Block Length

Instruments needed: Directional coupler Attenuator Average power meter

9.2.16.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The test NMS requests the BS to use burst profiles with the the RS parameter Information block length = 6, 128 and 239. RS parameter t = 8.

Data is transmitted in the uplink.

The BS receives the data correctly.

9.2.17 Channel allocation

9.2.17.1 Test setup

Figure 52 shows the test setup for testing the channel allocation.



Figure 52—Test setup for Channel allocation

Instruments needed: Attenuator Frequency meter

9.2.17.2 Test procedure

The BS is set in the CW test mode. The attenuator is adjusted for an optimal reception level.

The BS is requested to generate frequencies which are multiples of 250 kHz in the frequency range declared by the manufacturer

The BS is able to generate frequencies which are multiples of 250 kHz.

9.2.18 Symbol timing accuracy

9.2.18.1 Test setup

Figure 53 shows the test setup for testing the symbol timing accuracy.



Figure 53—Test setup for symbol timing accuracy

Instruments needed: Frequency meter Jitter meter

9.2.18.2 Test procedure

The BS is operable and the symbol clock frequency and jitter are measured.

The symbol clock accuracy shall be within \pm -15 ppm of its nominal value. The peak-to-peak jitter of the symbol clock during a 2 sec measurement period shall be less than 2 %.

9.2.19 Carrier frequency

9.2.19.1 Test setup

Figure 54 shows the test setup for testing the carrier frequency.



Figure 54—Test setup for Carrier frequency

Instruments needed: Attenuator Frequency meter

9.2.19.2 Test procedure

The BS is set in the CW test mode. The attenuator is adjusted for an optimal reception level

The BS is requested to generate frequencies which are multiples of 250 KHz in frequency range declared by the manufacturer

The accuracy shall be better than +/- 10 ppm.

9.2.20 Spectral mask

9.2.20.1 Test setup

Figure 55 shows the test setup for testing the spectral mask.



Figure 55—Test setup for Spectral mask

Instruments needed: Attenuator Spectrum Analyzer

9.2.20.2 Test procedure

A connection is setup between the BS and the Test SS. The downlink frame is filled with QPSK modulated data.

The spectrum is measured with a spectrum analyzer. The spectrum shall not exceed the mask given by the local regulator.

The settings of the spectrum analyzer shall be according to table 9

Paramter	SS
Center frequency	Actual
Span	140 MHz
Scan time	Auto
Resolution bandwidth	300 KHz
Video bandwidth	100 KHz

Table 9—Spectrum analyzer settings

9.2.21 Spurious

9.2.21.1 Test setup

Figure 56 shows the test setup for testing the spurious frequencies.



Figure 56—Test setup for Spurious frequencies

Instruments needed: Attenuator Spectrum Analyzer

9.2.21.2 Test procedure

A connection is setup between the BS and the Test SS. The downlink frame is filled with QPSK modulated data.

The spectrum is measured with a spectrum analyzer. The spurious frequencies shall not exceed the values given by the local regulator.

The settings of the spectrum analyzer shall be according to table 10

Paramter	SS
Center frequency	Actual
Span	140 MHz
Scan time	Auto
Resolution bandwidth	TBD
Video bandwidth	TBD

Table 10—Spectrum analyzer settings

9.2.22 Tx RMS Power level

9.2.22.1 Test setup

Figure 57 shows the test setup for testing the Tx RMS Power level



Figure 57—Test setup for Tx RMS power level

Instruments needed: Directional coupler Attenuator Average power meter

9.2.22.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The Test SS requests the BS to use the most robust burst profile. The downlink is filled with data.

The power is measured.

The power shall be = declared value +/-2 dB.

9.2.23 Ramp up / down time

9.2.23.1 Test setup

Figure 58 shows the test setup for testing the Ramp up / down time.



Figure 58—Test setup for Ramp up / down time

Instruments needed:	Directional coupler	
	Attenuator	
	Average power meter	

9.2.23.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. Data is transmitted in the uplink with QPSK modulation.

The BS allows \geq 24 symbols ramp up and ramp down times, including allowances for round trip delay when creating the maps.

9.2.24 Modulation accuracy

9.2.24.1 Test setup

Figure 59 shows the test setup for testing the modulation accuracy.



Figure 59—Test setup for Modulation accuracy

Instruments needed:	Directional coupler	
	Attenuator	
	Average power meter	

9.2.24.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

The sensitivity value P for the Test SS for $BER=10^{-3}$ is measured using a high quality transmitter as the signal source.

The sensitivity value M for the Test SS for $BER=10^{-3}$ is measured using the BS as the signal source. The difference M - P shall be less than or equal to the values in column 2 in table 11

Tx implementation margin		EVM no equalizer	EVM equalizer	
QPSK	0.5 dB	12 %	10 %	
16-QAM	1.0 dB	6 %	3 %	
64-QAM	1.5 dB		1.5 %	

Table 11—EVM	requirements
--------------	--------------

9.2.25 Rx Dynamic range

9.2.25.1 Test setup

Figure 60 shows the test setup for testing the Rx Dynamic Range



Figure 60—Test setup for Rx Dynamic Range

Instruments needed: Directional coupler Attenuator Average power meter

9.2.25.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The test NMS requets the BS to use the most robust burst profile. Data is transmitted in the uplink.

The attenuator is adjusted until the minimum operable value is reached. The power of the received signal is measured and recorded. The attenuator is then increased until the the maximum operable value is reached. The power is measured and recorded.

The difference between the two power values is the Rx dynamic range and shall be ≥ 27 dB.

9.2.26 BER performance threshold

9.2.26.1 Test setup

Figure 61 shows the test setup for testing the BER performance threshold.



Figure 61—Test setup for BER performance threshold

Instruments needed:	Directional coupler	
	Attenuator	
	Average power meter	

9.2.26.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuator is calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account.

A connection is setup between the BS and the Test SS. The Test SS transmits the bursts with all supported modulation schemes and no FEC. CRC is disabled

The BER is computed from the payload of the data packets accepted by the BS. The attenuator is adjusted until BER = 10^{-3} and then 10^{-6} . The input power is measured and shall be according to table 12. B is the symbol rate in MBaud.

	BER 10 ⁻³	BER 10 ⁻⁶
QPSK	-94 + 10log(B) dBm	-90 + 10log(B) dBm
16-QAM	-87 + 10log(B) dBm	-83 + 10log(B) dBm
64-QAM	-79 + 10log(B) dBm	-74 + 10log(B) dBm

Table 12—BER perform	ance threshold	sensitivity	v values
----------------------	----------------	-------------	----------
2003-05-08

9.2.27 1st adjacent channel interference

9.2.27.1 Test setup

Figure 62 shows the test setup for testing the 1st adjacent channel interference.



Figure 62—Test setup for 1st adjacent channel interference

Instruments needed: Directional coupler Attenuators Average power meter Power combiner

9.2.27.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuators are calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account. Attenuators 1 and 2 are used to adjust the ratio between the useful and interfering signals. Attenuator 3 is used for adjusteing the absolut signal level at the receiver and can be held at a constant value of 10 dB. The signal generator transmits a similar signal as the useful signal on the first adjacent channel.

A connection is setup between the BS and the Test SS. Attenuator 2 is set to its maximum value and the signal generator is switched off. The uplink frame is filled with QPSK modulated data and attenuator 1 is adjusted for BER = 10^{-3} (10^{-6}). The signal power is increased by 3 (1) dB and the power is measured.

The signal generator is switched on and attenuator 2 is decreased until BER = 10^{-3} (10^{-6}) is achieved. The Test BS is turned off and the power of the interfereing signal is measured.

The procedure is repeated for the other modulation schemes, 1 dB degradation and BER = 10^{-6} . The C/I values shall be according to tables 13 and 14.

	1 dB degradation	3 dB degradation
QPSK	-5 dB	-9 dB
16-QAM	+2 dB	-2 dB
64-QAM	+9 dB	+5 dB

Table 13—1st adjacent channel interferenece BER10⁻³

Table 14—1st adjacent channel int	terference BER=10 ⁻⁶
-----------------------------------	---------------------------------

	1 dB degradation	3 dB degradation
QPSK	-1 dB	-5 dB
16-QAM	+6 dB	+2 dB
64-QAM	+13 dB	+9 dB

2003-05-08

9.2.28 2nd adjacent channel interference

9.2.28.1 Test setup

Figure 63 shows the test setup for testing the 2nd adjacent channel interference.



Figure 63—Test setup for 2nd adjacent channel interference

Instruments needed: Directional coupler Attenuators Average power meter Power combiner

9.2.28.2 Test procedure

The losses for the coupler and the connecting waveguides are measured and the attenuators are calibrated. When measuring the power the losses and the effect of the coupler shall be taken into account. Attenuators 1 and 2 are used to adjust the ratio between the useful and interfering signals. Attenuator 3 is used for adjusteing the absolut signal level at the receiver and can be held at a constant value of 10 dB. The signal generator transmits a similar signal as the useful signal on the second adjacent channel.

A connection is setup between the BS and the Test SS. Attenuator 2 is set to its maximum value and the signal generator is switched off. The uplink frame is filled with QPSK modulated data and attenuator 1 is adjusted for BER = 10^{-3} (10^{-6}). The signal power is increased by 3 (1) dB and the power is measured.

The signal generator is switched on and attenuator 2 is decreased until BER = 10^{-3} (10^{-6}) is achieved. The Test BS is turned off and the power of the interfereing signal is measured.

The procedure is repeated for the other modulation schemes, 1 dB degradation and BER = 10^{-6} . The C/I values shall be according to tables 15 and 16.

	1 dB degradation	3 dB degradation
QPSK	-30 dB	-34 dB
16-QAM	-22 dB	-27 dB
64-QAM	-16 dB	-20 dB

Table 15—2nd adjacent channel interferenece BER10⁻³

Table 16—2nd adjacent channel interference BER=10⁻⁶

	1 dB degradation	3 dB degradation
QPSK	-26 dB	-30 dB
16-QAM	-20 dB	-23 dB
64-QAM	-12 dB	-16 dB

10. Annex A

10.1 Requirements for the test laboratories

11. Test equipment

The following equipment is needed for the tests and shall be provided by the test laboratory:

Terminal for system configuration (parameter setting) and control;

RF-Adapter

Spectrum Analyzer

Variable RF-Attenuator

Power meter

Oscilloscope

Printer, Plotter

12. General test platform

13. Carrier frequencies