
BEGIN
INIT
CRS ⇐ CARRIER_OFF
tx_cnt ⇐ 0
parity_cnt ⇐ 0
UCT
UPDATE
If (tx_cnt = block_size)
parity_cnt += parity_ratio
tx_cnt ⇐ 1
else
tx_cnt ++
T_Type(col) = C *
parity_cnt > 0
((T_Type(col) = C * parity_cnt = 0) +
T_Type(col) ≠ C)
DELAY
parity_cnt —
T_Type(col) = S
parity_cnt = 0
parity_cnt ≠ 0
CLEAR_CRS
CRS ⇐ CARRIER_OFF
SET_CRS
CRS ⇐ CARRIER_ON
UCT
UCT