

Add new PSE MIB (Before 30.9.1.1.17)

aReceivedDLLPDRRequestedPowerValue

ATTRIBUTE

APPROPRIATE SYNTAX:

INTEGER

BEHAVIOUR DEFINED AS:

A GET attribute that returns the requested power value **received from the remote system**. The requested power value is the new maximum input average power (see 33.3.7.2) the remote system will ever draw under this power allocation if it is accepted. The requested power value is encoded according to Equation (33–16), where X is the decimal value of aReceivedDLLPDRRequestedPowerValue.

Change definition of PSE MIB (30.9.1.1.17)

aMirroredDLLPDRRequestedPowerValue

ATTRIBUTE

APPROPRIATE SYNTAX:

INTEGER

BEHAVIOUR DEFINED AS:

A GET attribute that returns the requested power value that is mirrored back to the remote system. The definition for requested power value is same as described in (Prev Section). The requested power value is encoded according to Equation (33–16), where X is the decimal value of aMirroredDLLPDRRequestedPowerValue.

Add new PSE MIB (After 30.9.1.1.18)

aEchoedDLLPSEAllocatedPowerValue

ATTRIBUTE

APPROPRIATE SYNTAX:

INTEGER

BEHAVIOUR DEFINED AS:

A GET attribute that returns the PSE allocated power value on the remote system. The definition for allocated power value is same as described in (Prev Section). The power value is encoded according to equation Equation (33–16), where X is the decimal value of aEchoedDLLPSEAllocatedPowerValue.

Add the following state variables (33.7.6.2)

ReceivedPDRRequestedPowerValue

The copy of PDRRequestedPowerValue that the PSE receives from remote system.

This variable is mapped from the aReceivedDLLPDRRequestedPowerValue attribute (MIB reference).

Values: 0 through 295.

EchoedPSEAllocatedPowerValue

The copy of PDRRequestedPowerValue that the PSE receives from remote system.

This variable is mapped from the aEchoedDLLPSEAllocatedPowerValue attribute (MIB reference).

TempVar

A temporary variable used to store Power Value.

Change following variable definition (33.7.6.2)

MirroredPDRRequestedPowerValue

This variable is updated by the PSE state machine. This variable maps into aMirroredDLLPDRRequestedPowerValue attribute (MIB reference).

Change the PSE state diagram to the following:

