Project	iect IEEE 802.16 Broadband Wireless Access Working Group http://ieee802.org/16 >								
Title	OFDM mode for the IEEE 802.16a PHY draft standard								
Date Submitted	2001-04-30								
Source(s)	Durce(s) The following persons (in company alphabetical order) are among those who h document and support it as OFDM mode for the 802.16a amendment to the 802.1								
	Garik Markarian	Advanced Hardware Architectures Inc.	+44 7884231670	Garik@AHA.com					
	Neil M. McSparron	Advanced Hardware Architectures Inc.	+1(509)334-1000	Neil@AHA.com					
	Sean Sonander	Advanced Hardware Architectures Inc.	+44(0)2380763716	Sean@AHA.com					
	Dave Williams	Advanced Hardware Architectures Inc.	+1(509) 334 1000	DaveW@AHA.com					
	Naftali Chayat	Breezecom / OFDM Forum	+972 22 55 49	NaftaliC@Breezecom.co.il					
Marianna Goldhammer Tal Kaitz		Breezecom / OFDM Forum	+972 22 55 48	MariannaG@Breezecom.co.il					
		Breezecom / OFDM Forum	+ 972 3 6456273	TalK@breezecom.co.il					
	Michael Stewart	Escape Communications	+1(310)379-2305	MStewart@escapecom.com					
	Gregory Caso	Escape Communications	+1(310)379.2306	Gcaso@escapecom.com					
	Gordon Stuber	Georgia Institute of Technology	+1(404)894-2923	Stuber@ece.gatech.edu					
	Apurva Mody	Georgia Institute of Technology	+1(404)894-9370	Apurva@ee.gatech.edu					
	John Kim	Georgia Institute of Technology	+1(404)894-9370	YKim@ee.gatech.edu					
	Avi Freedman	Hexagon System Engineering Ltd.	+972 3-5449471	Avif@hexagonltd.com					
	Carl Scarpa	Hitachi America Ltd.	+1(609)-520-0071 x17	CGS@dmsl.Hitachi.com					
	Eric Jacobsen	Intel / wDSL Consortium	+1(480) 515-1142	Eric.A.Jacobsen@intel.com					
	Val Rhodes	Intel / wDSL Consortium	+1(480) 554-7329	Valentine.J.Rhodes@intel.com					
Ron McCallister		Intersil / OFDM Forum	+1(480)607-4831	RMcCalli@intersil.com					
	John Liebetreu	Intersil / OFDM Forum	+1(480)607-4830	Jliebetr@Intersil.com					
	Steven Smith	Intersil / OFDM Forum	+1(321) 729-5546	Ssmith@Intersil.com					
	Fernando Lopez de Victoria	Malibu Networks	+1(408)369-1590	Fernando@MalibuNetworks.com					

IEEE	802	16	3c-	01	/59
	004			UI.	151

Nico van Waes	Nokia / OFDM Forum	(see 802.16 member list)	Nico.vanWaes@Nokia.com
Anish Tolia	Oren Semiconductor / wDSL Consortium	+1(408)330-0300 x 22	Anish@Oren.com
David A. Fisher	Radia Communications	+1(408)830-9726 x225	DFisher@RadiaCommunications. com
Jerry V. Krinock	Radia Communications	+1(408)830-9726 x239	JKrinock@RadiaCommunication s.com
Chin-Chen Lee	Radia Communications	+1(408)830-9726 x244	Clee765982@AOL.com
Arvind V. Lonkar	Radia Communications	+1(408)830-9726 x246	Alonkar@RadiaCommunications. com
Manoneet Singh	Radia Communications	+1(408)830-9726 x225	MSingh@RadiaCommunications. com
Anthony Tsangaropoulos	Radia Communications	+1(408)830-9726 x246	AnthonyT@RadiaCommunicatio ns.com
Zion Hadad	Runcom / OFDM Forum	+972(3) 9528440	ZionH@Runcom.co.il
Yossi Segal	Runcom / OFDM Forum	+972(4) 9937333 x106	YossiS@Runcom.co.il
Itzik Kitroser	Runcom / OFDM Forum	+972-3-9528805	ItzikK@Runcom.co.il
Olivier Seller	Sacet	+33 29571656	Olivier.Seller@Sacet.com
Bob Ward	SciCom	(858)-513-4326	DrBMWard@IEEE.org
Chet Shirali	Vyyo	+1(408)523-4820	CShirali@Vyyo.com
Menashe Shahar	Vyyo	+1(408)863-2378	MShahar@Vyyo.com
Shawn Taylor	Wi-LAN / OFDM Forum	+1(403)207-6491	ShawnT@Wi-LAN.com
Lei Wang	Wi-LAN / OFDM Forum	+1(403)204-3288	LeiW@Wi-LAN.com
Brian Gieschen	Wi-LAN / OFDM Forum	+1(403)204-7745	BrianG@Wi-LAN.com
Gordon Antonello	Wi-LAN / OFDM Forum	+1(403)207-6477	GordonA@Wi-LAN.com
Ron Murias	Wi-LAN / OFDM Forum	+1(403)204-7766	RonM@Wi-LAN.com

Re:

Abstract	Baseline OFDM mode for PHY amendment to 802.16 standard for licensed frequencies between 2 and 11 GHz
Purpose	Addition to 802.16.3-01/13
Notice	This document has been prepared to assist IEEE 802.16. It is offered as a basis for discussion and is not binding on the contributing individual(s) or organization(s). The material in this document is subject to change in form and content after further study. The contributor(s) reserve(s) the right to add, amend or withdraw material contained herein.
Release	The contributor grants a free, irrevocable license to the IEEE to incorporate text contained in this contribution, and any modifications thereof, in the creation of an IEEE Standards publication; to copyright in the IEEE's name any IEEE Standards publication even though it may include portions of this contribution; and at the IEEE's sole discretion to permit others to reproduce in whole or in part the resulting IEEE Standards publication. The contributor also acknowledges and accepts that this contribution may be made public by IEEE 802.16.

Patent
Policy and
ProceduresThe contributor is familiar with the IEEE 802.16 Patent Policy and Procedures (Version 1.0)
<http://ieee802.org/16/ipr/patents/policy.html>, including the statement "IEEE standards may include the known use
of patent(s), including patent applications, if there is technical justification in the opinion of the standards-developing
committee and provided the IEEE receives assurance from the patent holder that it will license applicants under
reasonable terms and conditions for the purpose of implementing the standard."

Early disclosure to the Working Group of patent information that might be relevant to the standard is essential to reduce the possibility for delays in the development process and increase the likelihood that the draft publication will be approved for publication. Please notify the Chair <<u>mailto:r.b.marks@ieee.org</u>> as early as possible, in written or electronic form, of any patents (granted or under application) that may cover technology that is under consideration by or has been approved by IEEE 802.16. The Chair will disclose this notification via the IEEE 802.16 web site <<u>http://ieee802.org/16/ipr/patents/notices</u>>.

Table of Contents

7 OFDM PHY Layer	7
7.1 Introduction	7
7.2 System Considerations	7
7.2 System Constant and s	
7.2.2 Multiple Access	
7.2.3 Transmission Stream	8
7.3 OFDM PHY Parameters	8
7.3.1 Enhanced Features	
7.4 PHY Design Considerations	8
7.4.1 PHY Functionality	
7.4.2 PHY Components	8
7.4.3 Scrambling	
7.4.4 Channel Coding	9
7.4.5 Interleaving	9
7.4.7 Modulation	
7.4.7 Time/ Frequency Map	9
7.4.9 RF Transceiver	
7.5 OFDM Symbol Parameters	10
7.5.1 Introduction	
7.5.2 Time domain description	
7.5.3 Frequency Domain Description	
7.6 Scrambling (Randomization)	17
7.7 Channel Coding and interleaving	
7.7.1 Channel Coding	
7.7.1.1 Concatenated Reed Solomon and Convolutional Coding	
7.7.1.1.1 Reed Solomon encoding	
7.7.1.2 Block Turbo Coding	
7.7.1.2.1 Block Turbo Constituent Codes	
7.7.1.2.2 Extended Coding Mode	
7.7.2 Interleaving	
7.8 Modulation	
7.8.1 Data Modulation	
7.8.2 Pilot Modulation	
7.8.3 Ranging Pilot Modulation	
7.9 Time Domain Processing	
7.9.1 Framing Structure	
7.10 Time/Frequency Map Parameters	
7.10.1 Map I	

20	001-05-01 Version 0.60	IEEE 802.16.3c-01/59
	7.10.1.1 Downstream	
	7.10.1.1.1 Frame structure	
	7.10.1.2 Upstream	
	7.10.1.2.1 Frame structure	
	7.10.1.2.2 Symbol structure	
	7.10.2 Map II	
	7.10.2.1 Downstream	
	7.10.2.1.1 Frame structure	
	7.10.2.1.2 Symbol Structure	
	7.10.2.2 Upstream	
	7.10.2.2.1 Subchannel description	
	7.10.2.2.2 Framing Structure.	
	7.10.2.2.5 Symbol Structure	
	7.11 RF Transceiver	
	7.12 Control Mechanisms	34
	7.12.1 Synchronization	
	7.12.1.1 Network Synchronization	
	7.12.1.1.1 Time Stamp, Frame Timing Reference	
	7.12.1.1.2 Guard Timing and Frame Timing	
	7.12.1.2 Subscriber Station Synchronization	
	7.12.2 Ranging	
	7.12.2.1 Ranging using an OFDMA mapping	
	7.12.2.1.1 Long Ranging transmission	
	7.12.2.1.2 Short Ranging transmission	
	7.12.2.2 Ranging using the OFDM mapping	
	7.12.3 Bandwidth Requesting	
	7.12.3.1 Fast bandwidth requests using an OFDMA mapping	
	7.12.3.2 Bandwidth requests using an OFDM mapping	
	7.12.4 Power Control	
	7.13 Transmission convergence (TC) Sublayer	
	7.13.1 Uplink Transmission Convergence Sublayer	
	7.13.2 Downlink Transmission Convergence Sublayer	
	7.14 Additional Possible Features	30
	7.14 1 Adaptive Arrays	39
	7.14.2 Transmit diversity Alamouti's Space-Time Coding	40
	7.14.3 STC for FFT sizes 64 through 512	
	7.14.4 STC for FFT sizes 64 through 512	
	7.14.5 Alamouti STC Encoding	41
	7.14.6 Alamouti STC Decoding	
	C	
8	Sub-Channel Permutations	
9	Turbo Product Coding	43
	9.1 Encoding of a Turbo Product Code	
	9.2 Example of a 2-Dimesional Product Code	

2001-0	05-01 Version 0.60	IEEE 802.16.3c-01/59				
9.3	Shortened TPCs					
9.4	Example of a Shortened 2-Dimensional TPC					
9.5	Iterative Decoding					
10 R	.0 Regulatory Constraints					
10.1	FCC and ETSI regulatory masks					
10.2	2 FDD/TDD Co-existence					
Norma	ative references					

1 7 OFDM PHY Layer

2 7.1 Introduction

The following physical layer (PHY) specification is designed to meet the functional requirements that have been defined for Broadband Fixed Wireless Access (BFWA) systems. It incorporates many aspects of existing standards in order to leverage existing technology for reduced equipment cost and demonstrated robustness of implementation with modifications to ensure reliable operation in the targeted 2-11 GHz frequency band. In addition, this physical layer was designed with a high degree of flexibility in order to provide operators in different regulatory domains the ability to optimize system deployments with respect to cell planning, cost considerations, radio capabilities, offered services, and capacity requirements.

The PHY described in this clause is based on OFDM (Orthogonal Frequency Division Multiplex) modulation, and is described in terms of time/frequency mapping, which depending on the selected mapping parameters, can support Time Division Multiple Access (TDMA) as well as Orthogonal Frequency Division Multiple Access (OFDMA) [1], [2]. This flexibility ensures that the system can be optimized both for short burst type of applications, as well as more streaming type oriented applications and provides a seamless development migration path from various existing OFDM-based standards. An implementation in compliance with this standard shall implement at least one of the two mandatory time/frequency maps.

17

18 The carrier spacing in frequency is dictated by the multipath characteristics of the channels in which the FWA system is designated to operate. As the channel propagation characteristics depend on the topography of the 19 20 area and on the cell radius, the amount of carriers into which the channels is subdivided depends on the overall channel width and the carrier spacing. This PHY specification contains the programmability to deal with this 21 22 range of applications. As the modulation is implemented using Discrete Fourier Transforms (FFT), the modes 23 are designated by the FFT size, ranging from 64 for low bandwidth channels, up to 4096. The number of 24 carriers used for conveying data typically amounts between 83% and 95% of the FFT bins. Another parameter 25 controlling the multipath mitigation capability, at expense of overhead, is the time-domain "guard interval". The 26 size of the guard interval is programmable to 1/4, 1/8, 1/16, 1/32 of the FFT interval duration.

27 7.2 System Considerations

Multiple operational modes are defined. Although the desire is to converge to a limited set of modes, ultimately it will be up to the vendors and operators to decide which modes are supported based on market objectives such as service requirements and cost objectives.

31 **7.2.1 Duplexing**

Both frequency division duplex (FDD), half-duplex frequency division (H-FDD) and time division duplex (TDD) modes provide for bi-directional operation.

34 **7.2.2 Multiple Access**

In a point to multipoint (P-MP) system, the downstream (DS) and upstream (US) access to shared resources can be handled differently. In the DS, a base station (BS) can manage (schedule) resources, while in the US some measure of contention must be supported. In either case, multiple access can be based on one or more orthogonal or nearly orthogonal resources such as divisions in time, frequency, code, and space.

1 7.2.3 Transmission Stream

2 Transmissions may be organized in either a burst or continuous mode. In a packet switched system, both DS 3 and US links operate in a burst mode. Some designs use a continuous mode in the DS, although this approach is 4 problematic when incorporating adaptive antenna arrays for spatial processing because of the limitations 5 associated with a broadcast mechanism.

7.3 OFDM PHY Parameters 6

The carrier spacing, frequency extent, and guard time must be chosen to meet specific bit rate and delay spread 7 requirements. 8

7.3.1 Enhanced Features 9

The use of antenna arrays and transmit diversity techniques can provide significant improvements in system 10

performance or system capacity. These enhancements must be considered in the initial design so that their full 11 potential can be realized. 12

7.4 PHY Design Considerations 13

7.4.1 PHY Functionality 14

15 7.4.2 PHY Components

16 Conceptually, the PHY can be described in terms of upper and lower physical layers. As part of the upper 17 physical layer, higher layer (data link, transport, session, etc.) information and PHY control/management data 18 (e.g., training and synchronization) are mapped to symbols. For transmit data, the upper physical layer includes randomization, channel coding, Interleaving and modulation to form data symbols, while the lower physical 19 20 layer maps the data symbols to tones and forms OFDM symbols.

21 This PHY specification addresses the definition of each of the blocks shown in Figure 1. This figure is not 22 meant to imply a specific method or manner of implementation.

23



25

7.4.3 Scrambling 26

The scrambling (randomization) ensures sufficient bit transitions to simplify other PHY functions such as clock 27 recovery and demodulation. Design criteria include the size of the scrambler (i.e., the number of bits), seed size, 28

- 1 and how often the seed is set. A concern is how to set the scrambler so as to keep both ends of a communication
- 2 link synchronized.

3 7.4.4 Channel Coding

4 Channel coding provides enhanced signal recovery for given channel conditions by adding redundancy in a 5 prescribed manner. Key tradeoffs here are coding gain verses latency, complexity, and capacity. The amount of 6 coding gain goes directly to data rate and cell size calculations, while the acceptable latency is dictated by 7 application requirements. The performance in non-additive white Gaussian noise (AWGN) environments can be 8 significant design concern. For example, correcting burst errors can reduce the need for retransmissions, which 9 can have a dramatic effect on TCP throughput. This needs to be understood in the context of time and frequency 10 dispersion in a channel.

- 11 The amount of coding gain required may be influenced by other factors, such as SINR enhancements provided
- via spatial, spectral, or temporal processing. As such, the amount of coding gain may differ between the forward and reverse links.
- 14 In addition to channel coding, interleaving is used to mitigate against fast fading.

15 7.4.5 Interleaving

16 Interleaving is used to spread consecutive bits into separate symbols after modulation; the purpose of the 17 interleaver is to prevent a series of consecutive bad bits, which may occur on OFDMA/OFDM carriers due to 18 channel conditions.

19 **7.4.6 Modulation**

Modulation is the means for mapping digital data to discrete or analog symbols to efficiently utilize the available channel bandwidth. The goal is to transfer data with a given reliability within transmit power and receiver complexity constraints. This can be done using a single carrier or multiple carriers. For single carrier systems, an equalizer is required to compensate for any distortion resulting from a non-ideal frequency response of a channel. Alternatively, the available channel bandwidth can be subdivided into a number of subchannels such that the frequency response for each subchannel is nearly ideal. Depending on the implementation and interpretation of a subchannel, a subchannel may consist of one or many carriers.

Adaptive modulation and power allocation schemes based on water pouring algorithms can be used to provide greater efficiency with an increase in complexity (typically modest). The granularity with which it is applied – per carrier, per subchannel, per channel – needs to be described in a given implementation.

30 7.4.7 Time/ Frequency Map

The time/frequency map implements the time and frequency aspects of a framing structure. As depicted in Figure 2, this function assigns the modulated data (both transmit information and PHY control information) to specific carriers. In this context it is essentially a one-to-one mapping which can implemented as a downloadable look up table.



2

3

Figure 2: Time/Frequency Mapping Function

- There are numerous schemes for inserting PHY control information, including viewing it as out-of-band data, preamble data, or packet data. Consequently, as a function of time, PHY control information can be inserted continuously or periodically; as a function of frequency, PHY control information can be inserted at fixed carrier locations or mapped according to a time schedule.
- 8 Equally important, the time/frequency map reflects how time and frequency resources are used to provide
- 9 multiple access, as well as address other concerns such as fading due to multipath and increased system capacity
 10 when using adaptive antenna arrays.
- 11 An additional function that the time/frequency map can provide is mitigation of channel distortion. This 12 requires knowledge of frequency and time dispersion, and coherence bandwidth.

13 7.4.8 Time Domain Processing

The time domain processing converts the data from the frequency domain representation to a time domain representation. This includes assigning symbol data to specific bin locations and zeros to guard bins, implementing an inverse transform, and may include windowing, a cyclic prefix/postfix operation, and a PAPR (crest factor) reduction operation.

18 **7.4.9 RF Transceiver**

The discrete-time signal is converted to an analog waveform and mixed to an RF frequency. The non-linear distortions introduced as part of the RF conversion can create significant out-of-band interference, and must be reviewed in the context of deployment in specific frequency bands and out-of-band requirements, coexistence with adjacent (in-band and out-of-band) systems (in particular TDD/FDD), and tradeoffs in terms of guard bands, system performance, and system complexity.

24 7.5 OFDM Symbol Parameters

25 **7.5.1** Introduction

The OFDM symbol duration, or the related carrier spacing in frequency, is the major design parameter of an OFDM system. The symbol duration is composed of the FFT interval and of the Guard Interval (GI) (see clause 7.5.2). The Guard Interval, which constitutes an overhead, is closely related to the multipath delay spread parameter. In order to keep the overhead of the GI low, there is an interest in increasing the FFT interval duration as much as possible. On the other hand, excessive duration of the FFT interval affects adversely the sensitivity of the system to phase noise of the oscillators. For these reasons, the OFDM PHY can be configured

- 1 to FFT interval durations ranging from about ten microseconds to hundreds microseconds. The carrier spacing 2 ranges, correspondingly, from less than one kilohertz to tens of kilohertz.
- 3
- The effective bandwidth of the transmitted signal is related to the carrier spacing and the number of carriers.
 In order to calculate the sampling frequency for any bandwidth, we define the bandwidth efficiency:

6
$$BWEfficiency = \frac{F_s}{BW} \cdot \frac{N_{used}}{N_{FFT}} = \frac{\Delta f \cdot N_{used}}{BW}$$

7 in which

- 8 *BW* Channel bandwidth (Hz)
- 9 F_s Sampling frequency (Hz)
- 10 Δf Carrier spacing (Hz)
- 11 N_{used} Number of carriers used in the FFT

12
$$N_{FFT}$$
 FFT size

13

The Bandwidth efficiency is designed to be between 83-95%, mainly depending on the FFT size, in order to occupy the maximum usable bandwidth but still allow adequate RF filtering. From this notion we can extract the sampling frequency for each BW by:

17
$$F_s = BWEfficiency \cdot BW \cdot \frac{N_{FFT}}{N_{used}}$$

18 The conversion from carrier modulation values to time domain waveform is typically implemented by a FFT 19 algorithm on blocks of size 2^n . After the FFT, the time domain complex samples are transmitted at rate F_s . The 20 carrier spacing is, therefore,

$$21 \qquad \Delta f = \frac{F_s}{N_{FFT}}$$

The number of carriers utilized is usually only about 83% of the FFT bins. For implementation reasons, this number is chosen to be about 83% of the nearest power of 2. This choice involves implementation aspects of anti-aliasing filters.

Note that the choice of FFT size is an artificial implementation parameter. For example a modulation of less than 256 carriers can be implemented either with a FFT of size 256, or with a FFT of size 512 at double sampling rate. We will stick with the convention, in which OFDM modes are denoted by the "FFT size" which is the smallest power of two above the number of carriers.

- 29
- 30 The FFT interval duration is related to carrier spacing by

$$31 \qquad T_b = \frac{1}{\Delta f} = \frac{N_{FFT}}{F_s}$$

This specification allows for FFT sizes 64, 128, 256, 512, 1024, 2048, 4096. A compliant device shall
 implement either 256 FFT with TDMA, or alternatively 2048 FFT with OFDMA for any bandwidth.

The following tables give some calculation of the Carrier Spacing, Symbol Duration and Guard Interval duration for different masks. For FFT modes 256 and above, the sampling frequency is defined as

IEEE 802.16.3c-01/59

 $F_s = BW \cdot 8/7$. When using the 64, 128 FFT sizes, the sampling rate in the MMDS and WCS masks is $E_s = BW_s$

2 $F_s = BW$.

	[OFDM			OFDMA				
BW	N _{FFT}	64	128	256	512	512	1024	2048	4096
	Δf (kHz)	23 7/16	11 23/32	6 39/56	3 8/23	3 8/23	1 60/89	36/43	18/43
	BWefficiency	82.81%	80.47%	89.73%	84.60%	94.64%	94.64%	94.64%	94.64%
	T _b (us)	42 2/3	85 1/3	149 1/3	298 2/3	298 2/3	597 1/3	1194 2/3	2389 1/3
1.5	$T_g / T_b = 1/32$	1 1/3	2 2/3	4 2/3	9 1/3	9 1/3	18 2/3	37 1/3	74 2/3
	1/16	2 2/3	5 1/3	9 1/3	18 2/3	18 2/3	37 1/3	74 2/3	149 1/3
	1/8	5 1/3	10 2/3	18 2/3	37 1/3	37 1/3	74 2/3	149 1/3	298 2/3
	1/4	10 2/3	21 1/3	37 1/3	74 2/3	74 2/3	149 1/3	298 2/3	597 1/3
	Δf (kHz)	46 7/8	23 7/16	13 11/28	6 39/56	6 39/56	3 8/23	1 60/89	36/43
	BWefficiency	82.81%	80.47%	89.73%	84.60%	94.64%	94.64%	94.64%	94.64%
	I _b (US)	21 1/3	42 2/3	74 2/3	149 1/3	149 1/3	298 2/3	597 1/3	1194 2/3
3	$T_{g}/T_{b} = 1/32$	2/3	1 1/3	2 1/3	4 2/3	4 2/3	9 1/3	18 2/3	37 1/3
	1/16	1 1/3	2 2/3	4 2/3	9 1/3	9 1/3	18 2/3	37 1/3	74 2/3
	1/8	2 2/3	5 1/3	9 1/3	18 2/3	18 2/3	37 1/3	74 2/3	149 1/3
	1/4	5 1/3	10 2/3	18 2/3	37 1/3	37 1/3	74 2/3	149 1/3	298 2/3
	Δf (kHz)	93 3/4	40 7/8	20 11/14 90 72%	13 11/28 84 60%	13 11/28	04 64%	3 8/23 04 64%	1 60/89
		10 2/2	00.4770 21 1/3	03.13/0 27 1/2	04.00 /0 7/ 2/3	94.04 /0 7/ 2/2	94.0470 170 1/3	34.04 /0 208 2/3	94.0470 507 1/3
6	T /T $-1/32$	10 2/3	21 1/3	1 1/6	7 + 2/3	7 + 2/3	143 1/3	250 215	19 2/2
Ŭ	$I_g/I_b = 1/32$	1/3 2/2	2/3 1 1/2	1 1/0 2 1/2	Z 1/3	Z 1/3	4 2/3	9 1/J 10 2/2	10 2/3
	1/10	2/3 1 1/3	1 1/3 2 2/3	Z 1/3 1 2/3	4 Z/3 0 1/3	4 Z/3 0 1/3	9 1/3 18 2/3	10 2/3 37 1/3	5/ 1/3 7/ 2/3
	1/0	2 2/3	2 2/3 5 1/3	9 1/3	18 2/3	18 2/3	37 1/3	74 2/3	149 1/3
	Λf ($I_{\rm c} I_{\rm c} I_{\rm c}$)	187 1/2	93 3/4	53 4/7	26 11/14	26 11/14	13 11/28	6 39/56	3 8/23
	BWefficiency	82.81%	80.47%	89.73%	84.60%	94.64%	94.64%	94.64%	94.64%
	T _b (us)	5 1/3	10 2/3	18 2/3	37 1/3	37 1/3	74 2/3	149 1/3	298 2/3
12	$T_{a}/T_{b} = 1/32$	1/6	1/3	7/12	1 1/6	1 1/6	2 1/3	4 2/3	9 1/3
	1/16	1/3	2/3	1 1/6	2 1/3	2 1/3	4 2/3	9 1/3	18 2/3
	1/8	2/3	1 1/3	2 1/3	4 2/3	4 2/3	9 1/3	18 2/3	37 1/3
	1/4	1 1/3	2 2/3	4 2/3	9 1/3	9 1/3	18 2/3	37 1/3	74 2/3
	Δf (kHz)	375	187 1/2	107 1/7	53 4/7	53 4/7	26 11/14	13 11/28	6 39/56
	BWefficiency	82.81%	80.47%	89.73%	84.60%	94.64%	94.64%	94.64%	94.64%
	T _b (us)	2 2/3	5 1/3	9 1/3	18 2/3	18 2/3	37 1/3	74 2/3	149 1/3
24	$T_{g}/T_{b} = 1/32$	1/12	1/6	7/24	7/12	7/12	1 1/6	2 1/3	4 2/3
	1/16	1/6	1/3	7/12	1 1/6	1 1/6	2 1/3	4 2/3	9 1/3
	1/8	1/3	2/3	1 1/6	2 1/3	2 1/3	4 2/3	9 1/3	18 2/3
	1/4	2/3	1 1/3	2 1/3	4 2/3	4 2/3	9 1/3	18 2/3	37 1/3

Table 1: MMDS channelization parameters

2001-05-01 Version 0.60

IEEE 802.16.3c-01/59

		OFDM				OFDMA			
BW	N _{FFT}	64	128	256	512	512	1024	2048	4096
	Δf (kHz)	31 1/4	15 5/8	7 13/16	3 29/32	3 29/32	1 61/64	83/85	21/43
	BWefficiency	94.64%	91.96%	89.73%	84.60%	94.64%	94.64%	94.64%	94.64%
	T _b (us)	32	64	128	256	256	512	1024	2048
1.75	$T_g / T_b = 1/32$	1	2	4	8	8	16	32	64
	1/16	2	4	8	16	16	32	64	128
	1/8	4	8	16	32	32	64	128	256
	1/4	8	16	32	64	64	128	256	512
	Δf (kHz)	62 1/2	31 1/4	15 5/8	7 13/16	7 13/16	3 29/32	1 61/64	83/85
	BWefficiency	94.64%	91.96%	89.73%	84.60%	94.64%	94.64%	94.64%	94.64%
	T _b (us)	16	32	64	128	128	256	512	1024
3.5	$T_g / T_b = 1/32$	1/2	1	2	4	4	8	16	32
	1/16	1	2	4	8	8	16	32	64
	1/8	2	4	8	16	16	32	64	128
	1/4	4	8	16	32	32	64	128	256
	Δf_{rr} (kHz)	125	62 1/2	31 1/4	15 5/8	15 5/8	7 13/16	3 29/32	1 61/64
	BVV <i>efficiency</i>	94.64%	91.96%	89.73%	84.60%	94.64%	94.64%	94.64%	94.64%
_	I _b (us)	8	16	32	64	64	128	256	512
($T_{g}/T_{b} = 1/32$	1/4	1/2	1	2	2	4	8	16
	1/16	1/2	1	2	4	4	8	16	32
	1/8	1	2	4	8	8	16	32	64
	1/4	2	4	8	16	16	32	64	128
	$\Delta f_{\mu\nu}(kHz)$	250	125	62 1/2	31 1/4	31 1/4	15 5/8	7 13/16	3 29/32
		94.04%	91.90%	09.73%	04.00%	94.04%	94.04%	94.04%	94.04%
11		4	0	10	32	32	04	120	200
14	$I_g/I_b = 1/32$	1/8	1/4	1/2	1	1	2	4	8
	1/16	1/4	1/2	1	2	2	4	8	16
	1/8	1/2	1	2	4	4	8 16	10 22	32 64
	1/4	500	250	4	62 1/2	62 1/2	31 1//	JZ 15 5/8	7 13/16
	BW efficiency	94 64%	91 96%	89 73%	84 60%	94 64%	94 64%	94 64%	94 64%
	$T_{\rm h}$ (us)	2	4	8	16	16	32	64	128
28	$T_{a}/T_{b} = 1/32$	1/16	1/8	- 1/4	1/2	1/2	1	2	4
_	1/16	1/8	1/4	1/2	1	1	2	4	8
	1/8	1/4	1/2	1	2	2	4	8	16
	1/4	1/2	1	2	4	4	8	16	32

1

2

Table 2: ETSI channelization parameters

IEEE 802.16.3c-01/59

		OFDM				OFDMA			
BW	N _{FFT}	64	128	256	512	512	1024	2048	4096
	Δf (kHz) BW <i>efficiency</i>	39 1/16 82.81%	19 17/32 80.47%	11 9/56 89.73%	5 47/81 84.60%	5 47/81 94.64%	2 64/81 94.64%	1 32/81 94.64%	30/43 94.64%
	T _b (us)	25 3/5	51 1/5	89 3/5	179 1/5	179 1/5	358 2/5	716 4/5	1433 3/5
2.5	$T_{g}/T_{b} = 1/32$	4/5	1 3/5	2 4/5	5 3/5	5 3/5	11 1/5	22 2/5	44 4/5
	1/16	1 3/5	3 1/5	5 3/5	11 1/5	11 1/5	22 2/5	44 4/5	89 3/5
	1/8	3 1/5	6 2/5	11 1/5	22 2/5	22 2/5	44 4/5	89 3/5	179 1/5
	1/4	6 2/5	12 4/5	22 2/5	44 4/5	44 4/5	89 3/5	179 1/5	358 2/5
	Δf (kHz) BW <i>efficiency</i>	78 1/8 82.81%	39 1/16 80.47%	22 9/28 89.73%	11 9/56 84.60%	11 9/56 94.64%	5 47/81 94.64%	2 64/81 94.64%	1 32/81 94.64%
	T _b (us)	12 4/5	25 3/5	44 4/5	89 3/5	89 3/5	179 1/5	358 2/5	716 4/5
5	$T_{g}/T_{b} = 1/32$	2/5	4/5	1 2/5	2 4/5	2 4/5	5 3/5	11 1/5	22 2/5
	1/16	4/5	1 3/5	2 4/5	5 3/5	5 3/5	11 1/5	22 2/5	44 4/5
	1/8	1 3/5	3 1/5	5 3/5	11 1/5	11 1/5	22 2/5	44 4/5	89 3/5
	1/4	3 1/5	6 2/5	11 1/5	22 2/5	22 2/5	44 4/5	89 3/5	179 1/5
	Δf (kHz) BW efficiency	156 1/4 82.81%	78 1/8 80.47%	44 9/14 89.73%	22 9/28 84.60%	22 9/28 94.64%	11 9/56 94.64%	5 47/81 94.64%	2 64/81 94.64%
	T _b (us)	6 2/5	12 4/5	22 2/5	44 4/5	44 4/5	89 3/5	179 1/5	358 2/5
10	$T_{a}/T_{b} = 1/32$	1/5	2/5	7/10	1 2/5	1 2/5	2 4/5	5 3/5	11 1/5
	1/16	2/5	4/5	1 2/5	2 4/5	2 4/5	5 3/5	11 1/5	22 2/5
	1/8	4/5	1 3/5	2 4/5	5 3/5	5 3/5	11 1/5	22 2/5	44 4/5
	1/4	1 3/5	3 1/5	5 3/5	11 1/5	11 1/5	22 2/5	44 4/5	89 3/5
	$\Delta f_{\rm BW efficiency}({\rm kHz})$	234 3/8 82.81%	117 3/16 80.47%	66 27/28 89.73%	33 27/56 84.60%	33 27/56 94.64%	16 20/27 94.64%	8 10/27 94.64%	4 5/27 94.64%
	T _b (us)	4 4/15	8 8/15	14 14/15	29 13/15	29 13/15	59 11/15	119 7/15	238 14/15
15	$T_{g}/T_{b} = 1/32$	2/15	4/15	7/15	14/15	14/15	1 13/15	3 11/15	7 7/15
	1/16	4/15	8/15	14/15	1 13/15	1 13/15	3 11/15	7 7/15	14 14/15
	1/8	8/15	1 1/15	1 13/15	3 11/15	3 11/15	7 7/15	14 14/15	29 13/15
	1/4	1 1/15	2 2/15	3 11/15	7 7/15	7 7/15	14 14/15	29 13/15	59 11/15

1 2

3: PCS/WCS channelization parameters

3 7.5.2 Time domain description.

4 Inverse-Fourier-transforming creates the OFDM waveform; this time duration is referred to as the useful

5 symbol time (T_b) . A copy of the last samples is inserted before the useful symbol time, and is called the Guard

6 Interval (GI) its duration is denoted as a fraction of the useful symbol time as (T_g) . The two together are referred

7 to as the symbol time (T_s). Figure 3 illustrates this structure:



Figure 3: OFDM symbol time structure

1

A cyclic extension of $T_g \mu s$ is used to collect multipath, while maintaining the orthogonality of the tones. The transmitter energy increases with the length of the guard time while the receiver energy remains the same (the cyclic extension is discarded), so there is a $10 \log_{10}(1-T_g/(T_b+T_g))$ dB loss in SNR. Using a cyclic extension, the samples required for performing the FFT at the receiver can be taken anywhere over the length of the extended symbol. This provides multipath immunity as well as a tolerance for symbol time synchronization errors.

9 When implementing a TDD system, the frame structure is build from BS and SS transmissions. The cell radius 10 is dependent on the time left open for random system access. This time should at least equal the maximum 11 tolerable round trip delay plus the number of OFDM symbols necessary to transmit the ranging burst. Further, 12 in each frame, the TX/RX transition gap (TTG) and RX/TX transition gap (RTG) need to be inserted between 13 the downlink and uplink and at the end of each frame respectively to allow the BS to turn around (time plan for 14 a single frame is shown in Figure 4)

In FDD systems there is no need for TTG and RTG as the downstream and upstream transmit on independent
 frequencies (for H-FDD terminals, scheduling rules shall avoid TX and RX activity of the same terminal within

- 17 the TTG and RTG gap time)
- 18

19

20

25



21 **7.5.3 Frequency Domain Description**

- 22 The frequency domain description includes the basic structure of an OFDM symbol.
- An OFDM symbol is made up from carriers, the amount of carriers determines the FFT size used. There are several carrier types:
 - Data carriers for data transmission
- Pilot carriers for different estimation purposes
- Null carriers no transmission at all, for guard bands and DC carrier.







Figure 5: OFDM frequency description (schematic example)

5 The purpose of the guard bands is to enable the signal to naturally decay and create the FFT "brick Wall"6 shaping.

7 Within each symbol, only part of all active carriers may be used by the transmitter, the different carriers of 8 which may be intended for different (groups of) receivers. A set of carriers intended for one (group of) 9 receiver(s) is termed a subchannel. The carriers forming one subchannel may, but need not be adjacent.

10 This principle, termed OFDMA, is depicted in Figure 6 (pilots not shown).

11



12 13

Figure 6: OFDMA frequency description

14 The symbol is divided into logical sub-channels to support scalability, multiple access, and advanced antenna

array processing capabilities. The sub-channel structure will depend on the purpose for the sub-channelization.
 For wideband processing, the mapping is based upon a special permutation code, which distributes consecutive

17 symbols across the available bandwidth. For narrowband processing and advanced solutions employing antenna

18 array processing, the tone mapping places consecutive symbols next to adjacent tones.

One special case of OFDMA is recognized, which is the case in which all active subcarriers are mapped to the same subchannel irrespective of the FFT size. This mapping will be referred to as "OFDM mapping", whereas all other mappings will be referred to as "OFDMA mappings".

The number of carriers in the OFDMA mappings assigned to each subchannel is independent of the FFT size.
For example doubling the FFT size hence results in twice the number of subchannels which creates a very modular approach.

IEEE 802.16.3c-01/59

The OFDMA mappings result in systems that have more implementation complexity, but can provide several
 advantages.

3 4	•	Frequency diversity:	Possible random spreading of subchannel carriers across the frequency band
5 6	•	Power concentration:	Same power distributed on fewer carriers (most usable on the SS), providing up to 15 dB gain
7 8 9	•	Forward Power Control:	Digital allocation of different power amplification to the Sub-Channels (most usable on the Base-Station side), providing up to 6 dB concentration gain.

10 7.6 Scrambling (Randomization)

Data randomization is performed on data transmitted on the DS and US. The randomization is performed on each allocation (DS or US), which means that for each allocation of a data block (Sub-Channels on the frequency domain and OFDM symbols on the time domain) the randomizer shall be used independently. If the amount of data to transmit those not fit exactly the amount of data allocated, padding of FFx ('1' only) shall be added to the end of the transmission block, up to the amount of data allocated.

16

The shift-register of the randomizer shall be initialized for each new allocation or for every 1250 bytes passedthrough (if the allocation is larger then 1250 bytes).

19

The scrambler shall be randomly initialized. Each data byte to be transmitted shall enter sequentially into the randomizer, MSB first.

22 The Pseudo Random Binary Sequence (PRBS) generator shall be $1 + X^{14} + X^{15}$.

23



24

25

Figure 7: PRBS for data randomization

26 The bit issued from the randomizer shall be applied to the encoder. The first two octets in each burst shall be set

27 to zero, to allow estimation of the initial state of the scrambler. The purpose of this method is avoiding

28 perpetuation of PAPR problems during retransmissions.

2001-05-01 Version 0.60**7.7 Channel Coding and interleaving**

2 7.7.1 Channel Coding

3

1

Code rates of ¹/₂, ³/₄ for QPSK and 16QAM, and 2/3, ³/₄ for 64QAM are required. These coding rates shall be
implemented using concatenated Reed Solomon and Convolutional codes as shown in Table 4. In addition,
Block Turbo Codes may be implemented using the extended coding mode, as shown in Table 7. Specification
of the concatenated Reed Solomon- Convolutional Codes is given in clause 7.7.1.1. The BTC specification is
provided in clause 7.7.1.2.

The Reed-Solomon-Convolutional coding rate ¹/₂ shall be used as the coding mode when requesting access to
 the network.

12

13 7.7.1.1 Concatenated Reed Solomon and Convolutional Coding

First passing the data through the RS encoder and then passing the data in block format to a tail biting convolutional encoder perform the encoding.

- 16 Table 4 gives the block sizes and the code rates used for the different modulations and code rates:
- 17
- 18
- 19
- 20
- 21 22

Scheme	Modulation	Block Size	Over-All	RS Coding	CC Code
		(Bytes)	Coding Rate		Rate
	QPSK	18	1/2	(24,18,3)	2/3
	QPSK	26	~3/4	(30,26,2)	5/6
	16QAM	36	1/2	(48,36,6)	2/3
OFDMA	16QAM	54	3/4	(60,54,3)	5/6
	64QAM	72	2/3	(81,72,4)	3/4
	64QAM	82	~3/4	(90,82,4)	5/6
	QPSK	24	1/2	(32,24,4)	2/3
	QPSK	36	3/4	(40,36,2)	5/6
OEDM	16QAM	48	1/2	(64,48,8)	2/3
OPDIVI	16QAM	72	3/4	(80,72,4)	5/6
	64QAM	96	2/3	(108,96,6)	3/4
	64QAM	108	3/4	(120,108,6)	5/6

23

24

25 **7.7.1.1.1 Reed Solomon encoding**

The Reed Solomon encoding process shall use the systematic RS(255,239,8), with the possibility to make a variable RS(N,K,T), where:

Table 4

Mandatory channel coding

- N overall bytes, after encoding
- K data bytes before encoding
- T data bytes that can be fixed

5 The following polynomials are used for the systematic code:

- 6 Code generator polynomial: $g(x) = (x + \lambda^0)(x + \lambda^1)(x + \lambda^2)...(x + \lambda^{2T-1}), \lambda = 02_{her}$
- 7 Field Generator polynomial: $p(x) = x^8 + x^4 + x^3 + x^2 + 1$
- 8

1

2

3

4

- 9 7.7.1.1.1.1 Convolutional encoding
- Data bits issued from the Reed Solomon encoder, described in clause 7.7.1.1.1, shall feed the convolutional
 encoder depicted in Figure 8.



12

13

Figure 8: Convolutional encoder block diagram

- The Convolutional encoder shall have a constraint length equal to k=7 and shall use the following mother
 codes:
- 16
 $G_1 = 171_{oct}$ For X

 17
 $G_2 = 133$ For Y

$$G_1 = 133_{oct}$$
 For Y

- 18 A basic convolutional encoding scheme, as depicted in Figure 9, shall be used.
- 19



20

- Figure 9: Convolutional encoder basic scheme
- 22

The puncturing pattern shall be as defined in Table 5.

1 2

CC Code Rate	Puncturing Pattern	Transmitted Sequence
		(after parallel to serial conversion)
2/	X:10	$X_1Y_1Y_2$
/3	Y:11	1 1 2
3/	X:101	$X_{1}Y_{1}Y_{2}X_{3}$
/4	Y:110	1 1 2 5
5/	X:10101	$X_{1}Y_{1}Y_{2}X_{3}Y_{4}X_{5}$
/6	Y:11010	1 1 2 5 7 5

3 4

Table 5: Bit-Interleaver size as a function of the Modulation and Coding Rate

5 7.7.1.1.1.2 Tail Biting Code Termination

In order to allow sharing of the ECC decoder, each of the multiple data streams subdivides its data into RS
blocks. In this mode, each RS block is encoded by a tail-biting convolutional encoder. In order to achieve a tail
biting convolutional encoding the memory of the convolutional encoder shall be initialized with the last data
bits of the RS packet (the packet data bits are numbered b₀..b_n).

10

11 **7.7.1.2 Block Turbo Coding**

This type of coding based on the product of two or more simple component codes, is also called Turbo Product code, TPC. The decoding is based on the concept of Soft-in/Soft-out (SISO) iterative decoding (i.e., "Turbo decoding"). The component codes recommended for this proposal are binary extended Hamming codes or Parity check codes. The main benefits of using TPC mode are typically 2dB better performance over the Concatenated RS, and shorter decoding delays. A detailed description of Turbo Product Codes is included as Annex B. In this Section we present some particular turbo product codes that are perfectly matched for the proposed framing/modulation structure.

19 **7.7.1.2.1** Block Turbo Constituent Codes

As mentioned in Annex 9, TPCs are constructed as a product of simple component codes. The complete constituent code set is defined in Table 6. Bit shortening to achieve the codes as defined in Table 7 is described

in Annex 9.

(64, 57) Extended Hamming Code
(32,26) Extended Hamming Code
(16,11) Extended Hamming Code
(32,31) Parity Check Code
(16,15) Parity Check Code
(4,3) Parity Check Code

23

 Table 6: Constituent Block Turbo Code List

24 **7.7.1.2.2 Extended Coding Mode**

Table 7 gives the block sizes, code rates, code parameters and channel efficiency for different modulation and coding schemes.

Scheme	Modulation	Block	Code	Efficienc	Constituent	Code
		Size	Rate	у	Codes	Parameters
		(Bytes		Bit/S/Hz		

2001-05-01 Version 0.60

)				
OFDMA	QPSK	25	0.694	1.39	(8,7)(64,57)	$E=1, I_x=2, I_y=17$
	16QAM	38	0.528	2.11	(64,63)(16,11)	$E=1, I_x=20, I_y=3, B=40$
	16QAM	55	0.764	3.06	(16,15)(64,57)	$E=1, I_x=4, I_y=17$
	64QAM	79	0.731	4.39	(32,31)(32,26)	$E=1, I_x=2, I_y=4, B=6$
	64QAM	85	0.789	4.74	(32,31)(64,57)	$E=1, I_x=14, I_y=17$
OFDM	QPSK	26	0.542	1.1	(32,31)(16,11)	$E=1, I_x=4, I_y=3, B=8$
	QPSK	41	0.854	1.71	(32,31)(32,31)	$E=1, I_x=14, I_y=11, B=12$
	16QAM	56	0.583	2.33	(32,26)(32,26)	$E=1, I_x=6, I_y=3, B=12$
	16QAM	75	0.78	3.12	(16,15)(64,57)	$E=1, I_x=0, I_y=17$
	64QAM	107	0.74	4.44	(64,63)(32,26)	$E=1, I_x=25, I_y=3$
	64QAM	115	0.8	4.8	(32,31)(64,57)	$E=1, I_x=8, I_y=17$

Table 7Extended Coding Mode (not mandatory)

2 7.7.2 Interleaving

A combination of a bit interleaver and a symbol interleaver is proposed to interleave the data over the frequency domain. Table 8 summarises the bit interleaver sizes as a function of modulation and coding for both OFDMA and OFDM.

6

	OFDMA	OFDM
Modulation	144 Symbol	96 Symbol
	Interleave	Interleave
QPSK	288	192
QAM16	576	384
QAM64	864	576

7

Table 8Bit Interleaver Sizes

- 8 In the case of 64point FFT the interleaver is only the 96 Symbol allocation bit interleaver. This interleaver 9 operates over 2 OFDM symbols.
- 10 In the case of 128 point FFT an interleaver based on the 96 Symbol allocation is proposed. The bit interleaver is
- 11 sufficient on it's own and no carrier permutation is required.
- 12 In the case of 256 point FFT mode an interleaver based on the 96 Symbol allocation is proposed followed by the 13 simple symbol interleaver. This means that each OFDM symbol contains two bit-interleaved blocks.
- 14 In the case of 512 point FFT mode an interleaver based on 96 Symbol allocation is proposed followed by the 15 simple symbol interleaver. This means that each OFDM symbol contains four bit-interleaved blocks.
- 16 Table 9 summarises the number of bits within each block for different FFT sizes and modulation modes.
- 17

Modulation	64 Point	128 Point	256 Point	512 Point
QPSK	96	192	384	768
QAM16	192	384	768	1536
QAM64	288	576	1152	2304

Table 9Number of bits in an OFDM symbol

- 2 The bit interleaver is defined to be the same as the OFDMA mode bit interleaver.
- The PRBS generator depicted in Figure 10 is used to achieve the bit interleaver array, it is initialized with the
 binary value: 0001011010.
- 6 The PRBS generator produces an index value, which shall correspond to the new position of the input bit into 7 the output interleaved data burst.
- 8 The interleaver shall use the following algorithm:
- 9 The Interleaver indexes range from 1 to n (where n denotes the block size to be interleaved)
- For each input bit, the PRBS shall be rotated, the rotation produces a number, which is the value of the
 PRBS memory register.
- If the obtained number is bigger than n, it shall be discarded and the PRBS shall be rotated again. The rotation shall continue until an index between 1 to n is produced.
- The obtained index shall be used to address the position of the processed bit into the output interleaved data
 burst
- 16

1



17 18

Figure 10: PRBS for Bit-Interleaver array

19 7.8 Modulation

The modulation used both for the US and DS data carrier is QPSK, 16QAM and optionally 64QAM. These modulations are used adaptively in the downlink and the uplink in order to achieve the maximum throughput for each link.

The modulation on the DS can be changed for each allocation, to best fit the modulation for a specific user/users. When using OFDMA the power of the modulated carrier can also vary by attenuation or boosting of 6dB, this is used for the Forward APC.

- 26 For the up stream each user is allocated a modulation scheme, which is best suited for his needs.
- 27 The pilot carriers for the US and DS are mapped using a BPSK modulation.

28 **7.8.1 Data Modulation**

The data bits entering the mapper are after bit interleaving and they enter serially to the mapper, the mapping constellations are presented here after in Figure 11:



1

3

4 The complex number z shall be normalized by the value c, before mapping onto the carriers, by using the factor 5 defined in the next table:

IEEE 802.16.3c-01/59

Modulation scheme	Normalization Factor 6dB attenuation	Normalization Factor Reference – 0dB	Normalization Factor 6dB Boosting
QPSK	$c = \frac{z}{\sqrt{8}}$	$c = \frac{z}{\sqrt{2}}$	$c = z\sqrt{2}$
16QAM	$c = \frac{z}{\sqrt{40}}$	$c = \frac{z}{\sqrt{10}}$	$c = \frac{z\sqrt{2}}{\sqrt{5}}$
64QAM	$c = \frac{z}{\sqrt{168}}$	$c = \frac{z}{\sqrt{42}}$	$c = \frac{z\sqrt{2}}{\sqrt{21}}$

1

Table 10 Normalization factors

The complex number *c*, resulting from the normalization process, shall be modulated onto the allocated data carriers. The data mapping shall be done by sequentially modulating these complex values onto the relevant carriers. The reference-normalizing factor is used for the US, and the DS defined for 0dB boosting or attenuation. The normalizing factors used for attenuation and boosting are for DS use only, this is defined in the DS parameters for a specific burst type and is used for Forward APC.

7 7.8.2 Pilot Modulation

8 Pilot carriers shall be inserted into each data burst in order to constitute the Symbol Structure (see clause

- 9 7.10.2.1, 7.10.2.2) and they shall be modulated according to their carrier location within the OFDM symbol.
- 10

13 14

15

25

27

11 The Pseudo Random Binary Sequence (PRBS) generator depicted hereafter, shall be used to produce a

12 sequence, w_{k} . The polynomial for the PRBS generator shall be $X^{11} + X^2 + 1$.



Figure 12: PRBS used for pilot modulation

- 16 The value of the pilot modulation, on carrier k, shall be derived from w_k .
- 17 When using data transmission on the DS the initialization vector of the PRBS will be: [1111111111]
- 18 When using data transmission on the US the initialization vector of the PRBS will be: [10101010101]
- The PRBS shall be initialized so that its first output bit coincides with the first usable carrier. A new value shall
 be generated by the PRBS on every usable carrier. The DC carrier and the side-band carriers are not considered
 as usable carriers.
- The pilots shall be sent with a boosting of 2.5 dB over the average energy of the data. The Pilot carriers shall be modulated according to the following formula:

 $\text{Re}\{C_k\} = 4 / 3 \times 2 (\frac{1}{2} - w_k)$

- $Im\{C_k\} = 0$
- When OFDM symbols or Sub-Channels are used for pilots transmission only (preamble or midamble) the pilots shall not be boosted. The Pilot carriers shall be modulated according to the following formula:

30 $\operatorname{Re}\{C_k\} = 2(\frac{1}{2} - w_k)$

```
2001-05-01 Version 0.60
Im\{C_k\} = 0
```

IEEE 802.16.3c-01/59

1 2

3 7.8.3 Ranging Pilot Modulation

4 When using the ranging Sub-Channels the user shall modulate the pilots according to the following formula:

- 5 $\operatorname{Re}\{C_k\} = (\frac{1}{2} w_k) / 6$
- $6 \qquad \text{Im}\{C_k\} = 0$
- 7 C_k is derived in clause 7.12.2.

8 7.9 Time Domain Processing

9 7.9.1 Framing Structure

- 10 The framing structure used for the DS includes the transmission of a PHY control and US mapping, which is
- 11 transmitted in the most robust coding and modulation of the system followed by transmission using modulation
- 12 and coding schemes as defined in the PHY control. The MAC layer also defines the DS transmission frame
- 13 length and the length of the different transmission parts. Figure 13 illustrates the DS framing:



14 15

16 **7.10 Time/Frequency Map Parameters**

The basic resource allocation quantum is a subchannel. For all FFT sizes, each OFDM symbol contains an integer number of subchannels, both on downlink and on uplink. The amount of data, which fits into a subchannel, depends on the constellation and the coding method used within this subchannel, as well as the number of data-carriers per subchannel

A two dimensional map, in which one dimension denotes subchannels within the OFDM symbol (frequency domain) can visualize the available resource, and the other denotes the consecutive OFDM symbols (time domain).

The framing structure describes how logical channels or subchannels are mapped into physical layer tones as a function of the symbol number. Logical channels or subchannels include payload channels, ranging channels,

null channels, access channels, and training channels. Synchronization, pilot tones, and null tones are also
 mapped into the physical layer tones.

IEEE 802.16.3c-01/59

- 1 The framing structure is determined by the selection of OFDM or OFDMA, on the differences between the
- 2 multiple access methodologies used in OFDM and OFDMA and on the use of adaptive antenna arrays. As such,
- 3 the framing structure takes on different time/frequency maps according to the design selections made by the
- 4 equipment suppliers.
- 5 These maps are accommodated in the standard by an abstraction layer called the logical channel to physical 6 tone mapping function.

7 7.10.1 Map I

8 This map specifies the OFDM mapping. It is defined for FFT sizes 64, 128, 256 and 512, of which the 256 9 mode is mandatory. The basic resource allocation quantum is an OFDM symbol. The amount of data, which fits 10 into an OFDM symbol, depends on the constellation and the coding method used within this symbol.

11 7.10.1.1 Downstream

12 **7.10.1.1.1 Frame structure**

- 13 Data is encoded as a single stream and the resulting stream is mapped to consecutive OFDM symbols. In every
- 14 OFDM symbol, only one coding and constellation can be used. Figure 14 illustrates a possible two-dimensional
- 15 transmission mapping (every color represents a different Modulation and coding scheme).



- 16
- 17

- Figure 14: DS framing
- 18 As shown in Figure 14, the DS frame starts with a preamble consisting of one or more pilot symbols.
- 19 7.10.1.1.1 Preamble structure
- 20 **TBD**
- 21 7.10.1.2 Upstream

22 **7.10.1.2.1** Frame structure

The basic allocation for a user US transmission is made up of a preamble and an integer number of OFDM data symbols, adding more data symbols prolongs the transmission, while preamble is repeated every X data symbols transmission. Therefore the US mapping is illustrated in Figure 15:



- 1
- 2

Figure 15: Map I US framing

3 7.10.1.2.1.1 Preamble structure

4 TBD

5 **7.10.1.2.2 Symbol structure**

6 The data symbol structure is made up of data carriers and constant location pilots. The number of data carriers
7 and pilots depends on the FFT size being employed, but it the same for up- and down-stream.

8 In the table below, the DC carrier is numbered 0, whereas carrier numbers increase from the lowest to the 9 highest frequency.

10

Parameter	Va	lue
N _{FFT}	64	
N _{used}	52	
Guard Carriers: Left, Right	6	5
BasicConstantLocationPilots	{-21,-7,7,21}	

11

Parameter	Va	lue
N_{FFT}	128	
N _{used}	102	
Guard Carriers: Left, Right	13	12
BasicConstantLocationPilots	{-45,-27,-9,9,27,45}	

12

Parameter	Va	lue
N _{FFT}	256	
N_{used}	200	
Guard Carriers: Left, Right	28	27
BasicConstantLocationPilots	{-84,-60,-36,-12,12,36	5,60,84}

Parameter		Value
N _{FFT}	512	
N _{used}	378	
Guard Carriers: Left, Right	67	66

2001-05-0	1 Version 0.60	IEEE 802.16.3c-01/59
	BasicConstantLocationPilots	{-171,-133,-95,-57,-19,19,57,95,133,171}

Table 11Map I, Symbol parameters

2 7.10.2 Map II

1

This map specifies the OFDMA mapping. It is defined for FFT sizes 512, 1K, 2K and 4K of which the 2K mode is mandatory.

5 **7.10.2.1 Downstream**

6 **7.10.2.1.1 Frame structure**

7 The transmission of the DS is performed on the subchannels of the OFDMA symbol, the amount of subchannels 8 needed for the different transmissions (modulation and coding) and their mapping is defined in the PHY 9 control. The mapping of the subchannels is performed in a two-dimensional grid, involving the subchannels in 10 the frequency domain and OFDM symbols in the time domain. Figure 16 illustrates a possible two-dimensional 11 transmission mapping (every color represents a different Modulation and coding scheme). This example 12 disregards the fact that the carriers composing a subchannel may be scattered within the OFDM symbol in non-

13 consecutive locations.



14

15

Figure 16: Map II, DS framing

16 **7.10.2.1.2 Symbol Structure**

17 When using FFT size of 512 and above the DS shall use OFDMA modulation technique. The symbol structure

18 for those FFT sizes is made up of constant and variable location pilots, which are spread all over the symbol, 19 and from data carriers, which are divided into subchannels. The amount of Sub-Channels differs between the

20 different FFT sizes.

IEEE 802.16.3c-01/59

First allocating the pilots and then mapping the rest of the carriers to Sub-Channels construct the OFDMAsymbol. There are two kinds of pilots in the OFDM symbol:

- Continues location pilots which are transmitted every symbol
- Variable location pilots which shift their location every symbol with a cyclic appearance of 4 symbols

6 The variable pilots are inserted in the locations defined by the next formula:

$$k = 3 * L + 12 * P_{v}$$

- 8 $k \in$ Indices from 0 to the number of Overall Usable Carriers minus 1
- 9 $L \in 0..3$ denotes the symbol number with a cyclic period of 4
 - $P_{v} \ge 0$ is an integer number
- 10 11

3

4

5

7

- 12 The pilot's locations are illustrated in Figure 17:
- 13



14

20

23

25

26

27

- 15 Figure 17: pilots and data carrier location the DS OFDMA symbol using FFT 512 and above
- 16 The symbols are transmitted with the following order L=0,2,1,3.

After mapping the pilots, the rest of the carriers (not including the DC carrier, which is not used) are data carriers scattered all over the usable spectrum (we should mention that the exact location of those carriers changes as a function of the symbol number which is modulo 4).

Using special permutation code, which is based upon the following procedure, does the allocation of carriers to
 Sub-Channels (see also Annex 8):

- 1. The usable carrier space is divided into $\{N_{Groups}\}$ basic groups
 - 2. We define a basic permutation $\{PermutationBase_0\}$, containing $\{N_{elemets}\}$ elements
 - Different permutations ({*PermutatedSeries*}) are achieved by cyclically rotating the {*PermutationBase*₀} to the left
- 4. To get a $\{N_{Sub-Channel}\}$ length series we concatenate the permutated series, until the concatenated series
- has at least $\{N_{Sub-Channel}\}$ elements (number of concatenations is $N_{Concatenation} = ceil(N_{Sub-Channel} / N_{elemets}))$. The concatenation is performed by the next formula:

2001-05-01 Version 0.60 IEEE 802.16.3c-01/59 $\left[(PermutatedSeries + CellId) \mod(N_{elemets}); (PermutatedSeries + 2*CellId) \mod(N_{elemets}); ... \right], \text{ and then}$ 1 $\left\{ ...; (PermutatedSeries + N_{Concatenations} \cdot CellId) \mod(N_{elemets}); \right\}, \text{ and then} \right\}, \text{ and then}$ we take the first $\{N_{Sub-Channel}\}$ elements ($\{CellId\}$ is a MAC defined parameter, defining the current cell 2 identification numbers, to support different cells). 3 4 5 5. The last step achieves the carrier numbers allocated for the specific Sub-Channel with the current Cell Id. Using the next formula we achieve the 48 carriers of the current permutation in the cell: 6 7 $Carrier #= N_{elements} * n + Index(n)$ 8 9 where: *Carrier*# - denotes the carrier number for this Sub-Channel using the {*PermutatedSeries*} 10 *n* - Indices 0.. $\{N_{Sub-Channel} - 1\}$ 11 Index(n) - denotes the number at index n of the $\{N_{Sub-Channel}\}$ length series 12 13 14 In order to achieve the DS Sub-Channels, the data carriers are grouped into one space (in acceding order of their 15 indices) and then divided it into 48 basic groups ($\{N_{Groups}\}=48$). Each group containing a certain amount of 16

17 carriers, and then special permutations as described above are used to extract the Sub-Channels.

18

Parameter	Value	
N _{FFT}	512	
N _{used}	430	
Guard Carriers: Left, Right	41	41
Subchannels: nr, data carriers/subchannel	8	48
BasicConstantLocationPilots	{0,75,174,201,214,303,366,384,429}	
BasicVariableLocationPilots ₀	{}	
PermutationBase ₀	$\{7, 4, 0, 2, 1, 5, 3, 6\}$	

19

Parameter	Va	due
N _{FFT}	1024 (1K)	
N _{used}	850	
Guard Carriers: Left, Right	87	87
Subchannels: nr, data carriers/subchannel	16	48
BasicConstantLocationPilots	{0,39,261,330,348,351,522,645,651,726,75	
	6,849,850}	
BasicVariableLocationPilots ₀	{}	
PermutationBase ₀	{6, 14, 2, 3, 10, 8, 11	, 15, 9, 1, 13, 12, 5, 7,
	4,0}	

Parameter	Value
N _{FFT}	2048 (2K)
N _{used}	1703

IEEE 802.16.3c-01/59

Guard Carriers: Left, Right	172	172
Subchannels: nr, data carriers/subchannel	32	48
BasicConstantLocationPilots	{0, 39, 261, 330, 342 651, 708, 726, 756, 1017, 1143, 1155, 11 1407, 1419,1428, 14 1701, 1702}	2, 351, 522, 642, 645, 792, 849, 855, 918, 58, 1185, 1206, 1260, 61, 1530,1545, 1572,
BasicVariableLocationPilots ₀	{}	
PermutationBase ₀	{3, 18, 2, 8, 16, 10, 1 20, 25, 1, 29, 7, 21, 5 0, 13, 12, 19, 14, 30}	1, 15, 26, 22, 6, 9, 27, , 28, 31, 23, 17, 4, 24,

1

Parameter	Value	
N _{FFT}	4096(4K)	
N _{used}	TBD	
Guard Carriers: Left, Right	TBD	TBD
Subchannels: nr, data carriers/subchannel	64	48
BasicConstantLocationPilots	{}	
BasicVariableLocationPilots ₀	{TBD}	
PermutationBase ₀	{TBD}	

2 3

4 **7.10.2.2 Upstream**

5 7.10.2.2.1 Subchannel description

6

7 The next section gives a description of the structure of a subchannel. A subchannel is made up of 48 usable 8 carriers and 5 pilot carriers. The DS transmission for these modes is also made of subchannel transmissions, but 9 the Sub-Channel is made up of 48 data carriers only, while pilot carriers are spread all over the OFDMA 10 symbol, to be used for channel estimation. The US subchannel structure is shown in Figure 18.



Figure 18: Allocation of data and pilot carriers for a US Sub-Channel

The US data symbol structure is comprised of data carriers and pilot carriers. The data symbols are produced with a modulo 13 repetition (L denotes the modulo 13 index of the symbol with indices 0..12), the location of the variable location pilots are shifted for every symbol produced, the first symbol (L=0) is produced after the all-pilot symbols (preamble). For L=0 the variable location pilots are positioned at indices: 0,13, 27,40 for other L these location vary by addition of L to those position, for example for L=5 variable pilots location are: 5,18, 32, 45. the US Sub-Channel is also comprised of a constant pilot at the index 26. all other carriers (48) are data carriers, their location changes for every L, the transmission ordering of L is 0,2,4,6,8,10,12,1,3,5,7,9,11.

11

1 2

3

12 **7.10.2.2.2 Framing Structure**

The basic allocation for a user US transmission is made up of subchannels, a basic user allocation is made up of one Sub-Channel over duration of 4 OFDMA symbols. The first is a preamble and remaining are used for data transmission, adding more data symbols or subchannels increases the amount of data sent by the user, this allocation is presented in Figure 19:





18 19

Figure 19: Map II US User allocation

The framing structure used for the US includes the transmission of a possible symbol for Jamming monitoring, an allocation for Ranging and an allocation for data transmission. The MAC sets the length of the US framing, and the US mapping.

23

The framing for these modes involve the allocation of ranging Sub-Channels within the OFDMA symbols, while the rest of the Sub-channels are used for users transmission, the US mapping is illustrated in Figure 20:





4 7.10.2.2.3 Symbol Structure

5 The symbol structure for is made up of Sub-Channels, by their basic structure described in section 7.10.2.2.1. 6 There are several methods splitting the whole US OFDMA symbol into Sub-Channels, the first two methods are 7 performed by first dividing the used carriers into basic groups (not including the DC carrier, which is not used), 8 each containing a certain amount of carriers:

9

22

1 2

3

10 Then the following methods exist:

- 11 1. The number of basic groups is 53 ($\{N_{Groups}\}=53$) and they are allocated Y adjunct carriers, from the first
- 12 usable carrier to the last. Then special permutations are used to extract the Sub-Channels (the procedure 13 to use the permutation is defined in section 7.10.2.1.2, and each Sub-Channel is made up of 53 data 14 carriers $\{N_{Sub-Channel}\}=53$).
- Defining each basic group as a Sub-Channel, which implicate that the number of carriers Y=53 and that
 the carriers within the Sub-Channel are allocated adjunct. The carrier indices for each Sub-Channel is
 achieved using the next formula:
- 18 Carrier #= 53*n + I
- 19 where:
- 20 *Carrier*# denotes the carrier number for Sub-Channel *n*
- 21 *n* Indices from 0 to the amount of Sub-Channels minus one
 - *I* Indices 0..52
- 23 The last method for defining the Sub-Channels involves programming by MAC message the carrier numbers for
- 24 each Sub-Channel. When using method 1 (default) then the following parameters should be used:

Parameter	Value	
N _{FFT}	512	
N _{used}	425	
Guard Carriers: Left, Right	44	43
Subchannels: nr, data carriers/subchannel	8	48
PermutationBase ₀	$\{7, 4, 0, 2, 1, 5, 3, 6\}$	

4

1

Parameter	Value	
N _{FFT}	1024 (1K)	
N_{used}	849	
Guard Carriers: Left, Right	88	87
Subchannels: nr, data carriers/subchannel	16	48
PermutationBase ₀	{6, 14, 2, 3, 10, 8, 11	, 15, 9, 1, 13, 12, 5, 7,
	4,0}	

Parameter	Value	
N _{FFT}	2048 (2K)	
N _{used}	1696	
Guard Carriers: Left, Right	176	175
Subchannels: nr, data carriers/subchannel	32	48
BasicConstantLocationPilots ₀	{3, 18, 2, 8, 16, 10, 1	1, 15, 26, 22, 6, 9, 27,
	20, 25, 1, 29, 7, 21, 5	5, 28, 31, 23, 17, 4, 24,
	0, 13, 12, 19, 14, 30}	

5 6

Parameter	Value	
N_{FFT}	4096(4K)	
N _{used}	3392	
Guard Carriers: Left, Right	352	353
Subchannels: nr, data carriers/subchannel	64	48
BasicConstantLocationPilots ₀	{TBD}	

7

8 7.11 RF Transceiver

9 7.12 Control Mechanisms

10 Ranging for time (coarse synchronization) and power is performed during two phases of operation; during 11 registration of a new subscriber unit either on first registration or on re-registration after a period *TBD* of 12 in activity and accord during FDD or TDD temperiod is a second during the second during the

12 inactivity; and second during FDD or TDD transmission on a periodic basis.

1 7.12.1 Synchronization

2 7.12.1.1 Network Synchronization

For TDD realizations, all Base-Stations may have the facility to be time synchronized to a common timing signal. For FDD realizations, it is recommended (but not required) that all Base-Stations be time synchronized to a common timing signal.

6 In the event of the loss of the network timing signal, Base-Stations shall continue to operating and shall 7 automatically resynchronize to the network timing signal when it is recovered.

For both FDD and TDD realizations, frequency references derived from the timing reference may be used to
 control the frequency accuracy of Base-Stations provided that they meet the frequency accuracy requirements of

10 clause. 7.12.1.2. This applies during normal operation and during loss of timing reference.

11

12 **7.12.1.1.1 Time Stamp, Frame Timing Reference**

Each Base-Station and CPE shall have a facility to time stamp incoming OFDM or OFDMA symbols. The time stamp shall be an integer in the range from 0 to 2^Ntimestamp-1. The time stamp shall be synchronized to the network timing.

16 Time stamps shall be automatically reacquired after the loss of time or frequency synchronization.

- Frame and symbol timing at the Base-Station and CPE shall be derived from the synchronized timing epoch andthe time stamp.
- 19 CPE cannot transmit payload data until time, frequency, frame and time stamp synchronization is achieved.

A provision shall be made for time stamp rollover such that no ambiguity could occur across the network elements. This applies during normal operation and during loss of timing reference.

22

23 **7.12.1.1.2 Guard Timing and Frame Timing**

24 The Base-Station shall transmit an OFDM or OFDMA symbol coincident with the timing epoch.

The TDD guard timing between Basestation transmission and CPE transmission (RTG) shall be adjustable in the range of TBD microseconds to TBD microseconds.

The TDD guard timing between CPE transmission and Basestation transmission (TTG) shall be adjustable in the range of TBD microseconds to TBD microseconds.

29

30 **7.12.1.2 Subscriber Station Synchronization**

For any duplexing all CPEs shall acquire and adjust their timing such that all upstream OFDM symbols arrive time coincident at the Base-Station to a accuracy of +/- 30% of the guard-interval or better.

33

The frequency accuracy of the Base-Station RF and Base-Band reference clocks shall be at least 2ppm. The user reference clock could be at a 20ppm accuracy, and the user should synchronize to the DS and extract his clock from it, after synchronization the RF frequency would be accurate to 2% of the carrier spacing.

37 **7.12.2** Ranging

38 During registration, a new subscriber registers during the random access channel and if successful is entered 39 into a ranging process under control of the base station. The ranging process is cyclic in nature where default 40 time and power parameters are used to initiate the process followed by cycles where (re)calculated parameters

41 are used in succession until parameters meet acceptance criteria for the new subscriber. These parameters are

monitored, measured and stored at the base station and transmitted to the subscriber unit for use during normal exchange of data. During normal exchange of data, the stored parameters are updated in a periodic manner based on configurable update intervals to ensure changes in the channel can be accommodated. The update intervals will vary in a controlled manner on a subscriber unit by subscriber unit basis.

5

Ranging on re-registration follows the same process as new registration. The purpose of the ranging parameter
expiry is in support of portable applications capability. A portable subscriber unit's stored parameters will
expire and are removed after the expiry intervals no longer consuming memory space and algorithm decision
time.

10

11 This method is suitable for OFDM, OFDMA, FDD, and TDD operation.

12 **7.12.2.1** Ranging using an OFDMA mapping

Time and Power ranging is performed by allocating several Sub-Channels to one Ranging Sub-Channel upon this Sub-Channels users are allowed to collide, each user randomly chooses a random code from a bank of codes. These codes are modulated by BPSK upon the contention Sub-Channel. The Base Station can then separate colliding codes and extract timing and power ranging information, in the process of user code detection the base station get the Channel Impulse Response (CIR) of the code, acquiring the base station vast information about the user channel and condition. The time and power ranging allows the system to compensate the far near user problems and the propagation delay caused by large cells.

- 20 The usage of the Sub-Channels for ranging is done by the transmission of a Pseudo Noise (PN) code on the
- 21 Sub-Channel allocated for ranging transmission. The code is always BPSK modulated and is produced by the
- 22 PRBS described in Figure 21 (the PRBS polynomial generator shall be $1 + X^4 + X^7 + X^{15}$):



23

24

Figure 21: PRBS for ranging code production

Circulating through the PRBS (were each circulation produces one bit) produces the Ranging codes. The length
of the ranging codes are multiples of 53 bits long (the default for the 2k mode is 2 Sub-Channels allocated as
the ranging Sub-Channel therefore the ranging code length is 106), the codes produced are used for the next
purposes:

- The first 16 codes produced are for First Ranging; it shall be used by a new user entering the system.
- The next 16 codes produced are used for maintenance Ranging for users that are already entered the system.
- The last 16 codes produced are for users, already connected to the system, issuing bandwidth requests.
- 33

- 1 These 48 codes are denoted as Ranging Codes and are numbered 0..47.
- 2 The MAC sets the number of Sub-Channels allocated for Ranging, these ranging Sub-Channels could be used
- 3 concatenates as orders by the MAC in order to achieve a desired length.



4

- 5 Figure 22: Ranging subchannel allocation for OFDMA mapping (2k mode default configuration)
- 6

7 7.12.2.1.1 Long Ranging transmission

- 8 The Long Ranging transmission shall be used by any SU that wants to synchronize to the system channel for the 9 first time.
- 10 A Long Ranging transmission shall be performed during the two first consecutive symbols of the US frame.
- 11 Sending for a consecutive period of two OFDMA signals a preamble shall perform the long ranging
- transmission. The preamble structure is defined by modulating one Ranging Code, up on the Ranging Sub-Channel carriers. There shall not be any phase discontinuity on the Ranging Sub-Channel carriers during the
- 14 period of the Long Ranging transmission.
- This Long Ranging transmission is allowed only on the Ranging Sub-Channel resources defined by the MACprocess in the Base Station.
- 17

18 **7.12.2.1.2 Short Ranging transmission**

- 19 The Short Ranging transmission shall be used only by a SU that has already synchronized to the system.
- The Short Ranging transmission shall be used for system maintenance ranging or for fast bandwidth allocation requests.
- 22 To perform a Short Ranging transmission, the SU shall send a preamble for a period of one OFDM/OFDMA

IEEE 802.16.3c-01/59

- 1 symbol in the duration of the ranging interval. The preamble structure is defined by modulating one Ranging
- 2 Code on one Ranging Sub-Channel. This transmission may occur on any OFDM symbol out of the six available
- 3 ranging symbols.
- 4 This Short Ranging transmission is allowed only on the Ranging Sub-Channel resources defined by the MAC 5 process in the Base Station.
- 6

7 7.12.2.2 Ranging using the OFDM mapping

- 8 In the OFDM mapping regular uplink bursts shall be used for ranging. The only difference is that an extended
- 9 header shall be used in order to allow resolving larger timing uncertainty, arising from the propagation delay in

Time

10 large cells.



Figure 23: Ranging Symbol allocation for OFDM mapping

13 [fill in the preamble structure]

14 7.12.3 Bandwidth Requesting

15 7.12.3.1 Fast bandwidth requests using an OFDMA mapping

- 16 The usage of the Sub-Channels for fast bandwidth request is done by the transmission of a Pseudo Noise (PN) 17 code on the Sub-Channel allocated for ranging transmission (see clause 7.12.2.1).
- 18

11

12

19 **7.12.3.2** Bandwidth requests using an OFDM mapping20

- 21 Bandwidth request in OFDM can take two forms.
- Contention based requests. In this mode regular uplink bursts shall be used for BW requests.

- Subcarrier based polling. In this mode, the BTS may poll a group of stations, and each station responds by issuing an energy on a small set of subcarriers determined by station ID, if it desires to respond to a poll.
 (details TBD)
- 4 **7.12.4 Power Control**
- 5

6 7.13 Transmission convergence (TC) Sublayer

- 7 **7.13.1 Uplink Transmission Convergence Sublayer**
- 8 7.13.2 Downlink Transmission Convergence Sublayer

9 7.14 Additional Possible Features

10 **7.14.1** Adaptive Arrays

11 Employing adaptive antenna arrays can increase the spectral efficiency linearly with the number of antenna 12 elements. This is achieved by steering beams to multiple users simultaneously so as to realize an inter-cell frequency reuse of one and an in-cell reuse factor proportional to the number of antenna elements. An additional 13 14 benefit is the gain in signal strength (increased SNR) realized by coherently combining multiple signals, and the ability to direct this gain to particular users. This is in contrast to sectored antenna approaches where most users 15 16 are not in the direction of maximum antenna gain. Another benefit is the reduction in interference (increased signal to interference plus noise ratio, SINR) achieved by steering nulls in the direction of co-channel 17 interferers. 18

The benefits of adaptive arrays can be realized for both the upstream and downstream signals using retro directive beam forming concepts in TDD systems, and to some extent in FDD systems using channel estimation concepts. These techniques do not require multiple antennas at the SS, although further benefits can be achieved by doing this.

Further benefits can be realized by combining adaptive antenna arrays with frequency spreading. These techniques are based on Stacked Carrier Spread Spectrum implementations.

The framing methods outlined in previous sections addressing adaptive arrays are designed to exploit these advantages.

27

Adaptive array could be designed to accommodate Narrow Band or Broad Band systems, support for narrow band system is optional and achieved by defining the Sub-Channel carriers to be adjunct. The system inherently supports Broad Band channels, by using any other symbol structure (including the one were carriers of a sub-Channel are allocated adjunct).

When using Broad Band allocations in a Broad Band channel (up to 28MHz) there are several methods used to design adaptive arrays which are well known [23], this methods could comprise the use of matched receivers (amplitude and phase all over the band). Another method could comprise the use of non-matched receivers were processing could be done in the Base Band [(by first sending internal testing signals and tuning the arrays in the Base Band, easily implemented for OFDM modulation, which is a frequency domain processing).

1 7.14.2 Transmit diversity Alamouti's Space-Time Coding

- 2 Alamouti's scheme [25] is used on the downlink to provide (Space) transmit diversity of 2^{nd} order.
- 3 There are two transmit antennas on the BTS side and one reception antenna on the CPE side. This scheme
- 4 requires Multiple Input Single Output -MISO- channel estimation. Decoding is very similar to maximum
- 5 ratio combining.
- 6 Next figure shows Alamouti scheme insertion into the OFDM chain. Each Tx antenna has its own OFDM
- 7 chain, but they have the same Local Oscillator for synchronization purposes.



8 9 Remote

- 10
- 11

Figure 24: Illustration of the Alamouti STC

Both antennas transmit in the same time 2 different OFDM data symbols. Transmission is performed twice so as
 to decode and get 2nd order diversity. Time domain (Space-Time) repetition is used.

- 14
- 15 MISO channel estimation and synchronization -
- 16 Both antennas transmit in the same time, and they share the same Local Oscillator. Thus, received signal has
- exactly the same auto-correlation properties as in the 1 Tx mode. Time and frequency coarse and fine estimationcan so be performed in the same way as in the 1 Tx mode.
- 19 The scheme requires MISO channel estimation, which is allowed by splitting some preambles and pilots
- 20 between the 2 Tx antennas.
- 21

22 **7.14.3 STC for FFT sizes 64 through 512**

- A long preamble is transmitted once, either by one or both antennas. It is used for coarse synchronization.
- A short preamble is transmitted once, antenna 0 using even frequencies, and antenna 1 odd frequencies. This allows fine synchronization and MISO channel estimation. Each channel (0 & 1) is interpolated with very little
- 26 loss according to channel model.
- 27 Another option for short preamble is to transmit it twice alternatively from antenna 0 then antenna 1. This
- 28 yields to a preamble overhead, but with better fine synchronization.
- 29

IEEE 802.16.3c-01/59

- Pilots tones are used to estimate phase noise. There are transmitted alternatively (on a symbol basis) from one 1
- 2 antenna or the other. Since both antennas have the same LO, there is no penalty on phase noise estimation.
- 3

7.14.4 STC for FFT sizes 64 through 512 4

- 5 Pilot tones are shared between the two antennas in time.
- 6 Again, synchronization, including phase noise estimation, is performed in the same way as with one Tx antenna.
- 7 The estimation of the two channels is unchanged, but interpolation is more used (in the time domain).
- 8

9 7.14.5 Alamouti STC Encoding

- 10 s* denotes complex conjugate of s.
- (Scheme explanation) The basic scheme [25] transmits 2 complex symbols s_0 and s_1 , using twice a MISO 11
- channel (two Tx, one Rx) with channel values h_0 (for antenna 0) and h_1 (for antenna 1). 12
- Antenna0 transmits s_0 , antenna1 transmits s_1 . 13 first channel use:
- Second channel use: Antenna0 transmits $-s_1^*$, antenna1 transmits s_0^* . 14
- Receiver gets r_0 (first channel use) and r_1 (second channel use) and computes s_0 and s_1 estimates: 15
- 16 $s_0 = h_0 * r_0 + h_1 r_1 *$.
- 17 $S_1 = h_1 * r_0 - h_0 r_1 *$.
- These estimates benefit from 2nd order diversity as in the 1Tx-2Rx Maximum Ratio Combining scheme. 18
- 19
- 20 OFDM/OFDMA symbols are taken by pairs. (equivalently, 2 Tx symbol duration is twice 1 Tx symbol 21 duration, with twice more data in a symbol.)
- 22 In the transmission frame, variable location pilots are kept identical for two symbols, that means that the modulo L of the transmission is held the same for the duration of two symbols. 23
- 24 Alamouti's scheme is applied independently on each carrier, in respect to pilot tones positions.
- 25

Next figure shows Alamouti's scheme for OFDMA. Note that for OFDM, the scheme is exactly the same except 26 27 that a pilot symbol is inserted before the data symbols. Also note that since pilot positions do not change from 28 even to odd symbols, and pilots modulation is real, conjugation (and inversion) can be applied to a whole symbol (possibly in the time domain)

- 29
- 30
- 31 32

OFDM/OFDMA Alamouti's scheme adaptation



3 7.14.6 Alamouti STC Decoding

4 The receiver waits for 2 symbols, and combines them on a carrier basis according to the formula in section 5 7.14.5.

6 8 Sub-Channel Permutations

In section 7.10.2.1.2, the permutation procedure was explained. We give an example for using the procedure
with the US 1k mode.

10 The parameters characterizing the US 1K mode are as follow:

- 11 Number of FFT points = 1024 (1K)
- 12 Overall Usable Carriers = 849
- 13 Guard Bands = 88, 87 carriers on right an left side of the spectrum
- 14 Number of Sub-Channels = 16

16 The parameters characterizing the Sub-Channels allocation:

17

15

9

 $\frac{1}{2}$

- 18 Y Number of carriers in each basic group = 16
- 19 The basic series of 16 elements is $\{PermutationBase_0\} = 6, 14, 2, 3, 10, 8, 11, 15, 9, 1, 13, 12, 5, 7, 4, 0$

1 2 3

4

5

6

10 11

12 13 14

15 16

17 18 19

20 21

22

23

24 25

26

27

28

Using the defined procedure does the allocating:

- 1. The basic series of 16 numbers is 6, 14, 2, 3, 10, 8, 11, 15, 9, 1, 13, 12, 5, 7, 4, 0
- In order to get 16 different permutation the series is rotated to the left (from no rotation at all up to 15 rotations), for the first permutation we get the following series: 14, 2, 3, 10, 8, 11, 15, 9, 1, 13, 12, 5, 7, 4, 0, 6
- 7 3. To get a 53 length series we concatenate the permutated series 5 times (to get a 64 length series) and
 8 take the first 53 numbers only, the concatenation depends on the cell Id (which characterizes the
 9 working cell and can range from 0 to 15), the concatenated series is achieved by the next formula:
 - (PermutatedSeries + CellId) mod 16; (PermutatedSeries + 2*CellId) mod 16; (PermutatedSeries + 3*CellId) mod 16; (PermutatedSeries + 4*CellId) mod 16;
 - for example when using permutation 1 with CellId=2 we get the next concatenated series:

0,4,5,12,10,13,1,11,3,15,14,7,9,6,2,8,2,6,7,14,12,15,3,13,5,1,0,9,11,8,4,10,4,8,9,0,14,1,5,15,7,3,2,11,13,10,6,12,6,10,11,2,0,3,7,1,9,5,4,13,15,12,8,14

therefore the 53 length series is:

0,4,5,12,10,13,1,11,3,15,14,7,9,6,2,8,2,6,7,14,12,15,3,13,5,1,0,9,11,8,4,10,4,8,9,0,14,1,5,15,7,3,2,11,13,10,6,12,6,10,11,2,0,3

1. The last step achieves the carrier indices allocated for the specific Sub-Channel with the current Cell Id. Using the next formula we achieve the 53 carriers of the current permutation in the cell:

Carrier #= 16 * n + Index(n)

where:

Carrier# - denotes the carrier number for Sub-Channel *n*

n - Index 0..52

29 Index(n) - denotes the number at index n of the 53 length series

30 9 Turbo Product Coding

The Block Turbo Code is a Turbo decoded Product Code (TPC). The idea of this coding scheme is to use wellknown product codes in a matrix form for two-dimensional coding, or in a cubical form for three dimensions.

The matrix form of the two-dimensional code is depicted in Figure 26. The k_x information bits in the rows are encoded into n_x bits, by using a binary block (n_x , k_x) code. The binary block codes employed are based on extended Hamming codes.

- The redundancy of the code is $r_x = n_x k_x$ and d_x is the Hamming distance. After encoding the rows, the columns are encoded using another block code (n_y, k_y) , where the check bits of the first code are also encoded. The overall block size of such a product code is $n = n_x \times n_y$, the total number of information bits $k = k_x \times k_y$ and the
- 39 code rate is $R = R_x \times R_y$, where $R_i = k_i/n_i$, i=x, y. The Hamming distance of the product code is $d = d_x \times d_y$.



Figure 26 Two-dimensional product code matrix

3 9.1 Encoding of a Turbo Product Code

The encoder for TPCs has near zero latency, and is constructed of linear feedback shift registers (LFSRs), storage elements, and control logic. Encoding of a product code requires that each bit be encoded by 2 or 3 codes.

7 The constituent codes of TPCs are extended Hamming or parity only codes. Table 12 gives the generator

polynomials of the Hamming codes used in TPCs. For extended Hamming codes, an overall even parity check
bit is added at the end of each code word.

n	k	Generator Polynomial
7	4	$x^3 + x + 1$
15	11	$x^4 + x + 1$
31	26	$x^{5} + x^{2} + 1$
63	57	$x^{6} + x + 1$
127	120	$x^7 + x^3 + 1$
255	247	$x^8 + x + 1$

10

Table 12 Generators Polynomials of Hamming Codes

In order to encode the product code, each data bit is input both into a row encoder and a column encoder. Only one row encoder is necessary for the entire block, since data is input in row order. However, each column of the array is encoded with a separate encoder. Each column encoder is clocked for only one bit of the row, thus a more efficient method of column encoding is to store the column encoder states in a $k_x \times (n_y-k_y)$ storage memory. A single encoder can then be used for all columns of the array. With each bit input, the appropriate column encoder state is read from the memory, clocked, and written back to the memory.

17 The encoding process will be demonstrated with an example.

9.2 Example of a 2-Dimesional Product Code

Assume a two-dimensional $(8,4) \times (8,4)$ extended Hamming Product code is to be encoded. This block has 16 data bits, and 64 total encoded bits. Figure 27 shows the original 16 data bits denoted by D_{yx} . Of course the usual way is to have a serial stream of data of 16 bits and then label them as D_{11} , D_{21} , D_{31} , D_{41} , D_{12} ,..., D_{44} .

D ₁₁	D ₂₁	D ₃₁	D ₄₁
D ₁₂	D ₂₂	D ₃₂	D ₄₂

D ₁₃	D ₂₃	D ₃₃	D ₄₃
D ₁₄	D_{24}	D ₃₄	D_{44}

Figure 27	Original	Data	for	Encoding
i igule ZI	Unginal	Dala	101	LICOUNTY

> The first four bits of the array are loaded into the row encoder in the order D_{11} , D_{21} , D_{31} , D_{41} . Each bit is also fed into a unique column encoder. Again, a single column encoder may be used, with the state of each column stored in a memory. After the fourth bit is input, the first row encoder error correction coding (ECC) bits are shifted out.

> 7 This process continues for all four rows of data. At this point, 32 bits have been output from the encoder, and

8 the four column encoders are ready to shift out the column ECC bits. This data is also shifted out row-wise.
9 This continues for the remaining 3 rows of the array. Figure 28 shows the final encoded block with the 48

10 generated ECC bits denoted by E_{vx} .

1	1	
T	T	

D ₁₁	D ₂₁	D ₃₁	D ₄₁	E_{51}	E ₆₁	E ₇₁	E ₈₁
D ₁₂	D ₂₂	D ₃₂	D ₄₂	E ₅₂	E ₆₂	E ₇₂	E ₈₂
D ₁₃	D ₂₃	D ₃₃	D ₄₃	E ₅₃	E ₆₃	E ₇₃	E ₈₃
D ₁₄	D ₂₄	D ₃₄	D44	E54	E ₆₄	E ₇₄	E ₈₄
E ₁₅	E ₂₅	E ₃₅	E45	E ₅₅	E ₆₅	E ₇₅	E ₈₅
E_{16}	E ₂₆	E ₃₆	E46	E56	E ₆₆	E ₇₆	E ₈₆
E ₁₇	E ₂₇	E ₃₇	E47	E ₅₇	E ₆₇	E ₇₇	E ₈₇
E ₁₈	E ₂₈	E ₃₈	E ₄₈	E ₅₈	E ₆₈	E ₇₈	E ₈₈

12

17

Figure 28 Encoded Block

13 Transmission of the block over the channel may occur in a linear fashion, for example with all bits of the first 14 row transmitted left to right followed by the second row, etc. This allows for the construction of a near zero 15 latency encoder, since the data bits can be sent immediately over the channel, with the ECC bits inserted as 16 necessary. For the $(8,4)\times(8,4)$ example, the output order for the 64 encoded bits would be

 $D_{11}, D_{21}, D_{31}, D_{41}, E_{51}, E_{61}, E_{71}, E_{81}, D_{12}, D_{22}, \dots, E_{88}.$

18 Alternatively, a block based interleaver may be inserted to further improve the performance of the system.

19 9.3 Shortened TPCs

To match packet sizes, a product code may be shortened by removing symbols from the array. In the twodimensional case rows, columns or parts thereof can be removed until the appropriate size is reached. Unlike one-dimensional codes (such as Reed-Solomon codes), parity bits are removed as part of shortening process, helping to keep the code rate high.

There are two steps in the process of shortening of product codes. The first is to remove an entire row or column from a 2-dimensional code, or an entire X, Y, or Z plane from a 3-dimensional code. This is equivalent to shortening the constituent codes that make up the product code. This method enables a coarse granularity on shortening, and at the same time maintaining the highest code rate possible by removing both data and parity symbols. Further shortening is obtained by removing individual bits from the first row of a 2-dimensional code, or from the top plane of a 3-dimensional code.

9.4 Example of a Shortened 2-Dimensional TPC

For example, assume a 456-bit block size is required with a code rate of approximately 0.6. The base code chosen before shortening is the $(32,26)\times(32,26)$ code which has a data size of 676 bits. Shortening all rows by 5

- 1 bits and all columns by 4 bits results in a $(27,21) \times (28,22)$ code, with a data size of 462 bits. To get the exact
- 2 block size, the first row of the product is shortened by an additional 6 bits. The final code is a (750,456) code,
- 3 with a code rate of 0.608. Figure 29 shows the structure of the resultant block.



Figure 29: Structure of Shortened 2 D Block

5 6

4

7 Modifications to the encoder to support shortening are minimal. The shortening procedure is trivial, and yet an 8 extremely powerful tool that enables construction of a very versatile code set.

9 9.5 Iterative Decoding

Huge performance advantages may be directly associated with the decoding mechanism for product codes.
There are many different ways to decode product codes and each has its merits, however, the goal is maximum
performance for a manageable level of complexity.

13 It is known that if it is possible to use unquantized information (so called soft information) from the 14 demodulator to decode an error correcting code, then an additional gain of up to 2 dB over fully quantized (hard 15 decision) information is achievable. It is therefore desirable to have soft information decision available to the 16 TPC decoder.

17 Of course, we could in theory consider the decoding of this code a single linear code of size 18 $(n_x \times n_y \times n_z, k_x \times k_y \times k_z)$, using a soft decision decoder, but this will in general (apart from the smallest, and of 19 course worst performing) be prohibitively complex.

20 It makes sense therefore, since these codes are constructed from (simple) constituent code that these soft decoders are used to decode the overall code. However until recently there have only been hard decision 21 22 decoders for these constituent decoders. In recent years the computational power of devices has made it possible 23 to consider (sub optimal) soft decision decoders for all linear codes. This is only half the solution as the main 24 difficulty is with passing the information from one decoder to the next (i.e. when switching from decoding the rows to decoding the columns). For this, accuracy will need to be kept to a maximum, and so using soft input 25 soft output (SISO) decoders will need to be considered. This is such that an estimate of the transmitted code 26 27 word may be found and also an indication of the reliability. This new estimate may then be passed onto the next

28 decoding cycle. Inevitably, there will be some degradation from optimal if we are to achieve our decoding using

- this method, but it does enable the complexity to be reduced to a level that can be implemented. Also, studies have shown that this degradation is very small, so this decoding system is very powerful.
- 3 What follows now is an explanation regarding the iterative nature of the decoding procedure. If we consider
- 4 that, given 2-D TPC block, we define the first round of row and column decoding as a single iteration. We may
- 5 then perform further iterations, if required. Thus, the main areas of investigation are that of the SISOs, and that
- 6 of using some previously decoded information in subsequent decoding operations. These are both separate and
- 7 yet connected areas of interest, as shall be explained.
- 8 With regards to the SISOs, there are many different methods including the following which have been described 9 in detail in published academic papers:
- 10 1) Soft-Output Viterbi Algorithm (SOVA) [21]
 - 2) The modified Chase algorithm [22]
 - 3) The BCJR algorithm [25],

11

- There have been many other papers explaining these algorithms both as independent algorithms for coding schemes and as part of turbo type decoding schemes. It must be noted that these are not the only algorithms that can achieve soft input soft output style decoding, but they are at present the most readily cited in academic literature.
- 17 Each block in a product code is decoded using the information from a previous block decoding. This is then 18 repeated as many times as. In this way, each decoding iteration builds on the previous decoding performance.
- 19 Figure 7A illustrates the decoding of a 2-D TPC. Note here that prior to each decoding there needs to be a
- 20 mathematical operation on all the data we have at that particular time, that is the current estimate of the decoded
- 21 bits, the original estimate from the demodulator (this will not be used in the first decoding) and the channel
- 22 information (where applicable).



- 1
- 2 3

Figure 30: Procedure for decoding of 2-D TPC

4 It can easily be seen from Figure 30 that the iteration idea is applicable to one complete decoding of the rows 5 and one complete decoding of the columns.

6 There is an obvious question as to how the iteration procedure is terminated. This is a question only answerable

by the system provider and depends on performance and delay; more iterations imply better performance as the
expense of a larger latency. Of course, over clocking the system in comparison can significantly reduce the

9 latency. When considering hardware, the problem of varying delays may be encountered, thus it may be

10 advantageous to fix the number of iterations performed.

2 **10 Regulatory Constraints**

3 10.1 FCC and ETSI regulatory masks

Channel bandwidths for frequencies below 11GHz differ between several areas of the world. ETSI band plans
generally vary from 7 to 28 MHz. Within the United States, band plans in the PCS and WCS frequency bands
are 5, 10 or 15 MHz, and band plans in the MMDS frequency band are organized in multiples of 6 MHz
channels.

8 In general, when the available number of channels is too limited to deploy a network, splitting of these bands is 9 possible. In this document, splitting in factors of 2 for the ETSI and MMDS allocations to a minimum of 1.75, 10 respectively 1.5 MHz is taken into consideration. For the PCS and WCS, the only split is 2.5 MHz. These sub-11 allocations are (apart from their size) physically no different then 'regular' channel-widths and will hence not be 12 addressed separately.

In general, frequency band plans provide paired frequency blocks. Examples include the PCS band with 80
 MHz separation between blocks, the WCS band with 45 MHz separation between blocks A and B, the 3.5 GHz

15 band with 50 or 100 MHz separation, and the 3.4 to 3.6 GHz bands in Europe that include 50, 70 and 100 MHz 16 separations. The MMDS band does not have defined blocks, but a separation on the order of 6 to 48 MHz is

possible.





18

19

Figure 31: Generic paired Frequency block with channel splitting

The active bandwidth is less than the channel bandwidth to meet spectral mask designations associated with out-of-band spectral interference requirements. The key contribution to out-of-band interference is typically third and fifth order intermodulation distortion resulting from RF circuitry, but signal roll-off is also a consideration. The ETSI mask is shown in Figure 32 [22]; the spectral mask for the WCS band is shown in Figure 33; the spectral mask for the MMDS band is shown in Figure 34.



Figure 32: ETSI Spectral Mask^{*}

2

^{*}Different masks relate to different system throughput requirements. The higher the throughput, the more relaxed the mask. See [22] for details.



Figure 33: WCS Spectral Mask



1

2 3

5

Figure 34: MMDS Spectral Mask

6 10.2 FDD/TDD Co-existence

Coexistence requires additional consideration of adjacent channel interference, and has a significant impact on
 system design.

A number of engineering tradeoffs must be balanced in order to maximize system performance, maintain compatibility and enable RF coexistence. A number or facts are listed below which are significant factors within this trade space.

3 4 5

6

7

8

9

1 2

- We seek to fill the channel BW with active tones (the active tone bandwidth), thus minimizing the symbol duration and maximizing the link rate.
- We need to have adequate guard bands on each side of the active bandwidth so that energy generated by BSs and SSs decays to an acceptable level in the active tone region of the adjacent channel.
- Conditions will exist where an FDD system and a TDD system operating in adjacent channels will transmit while the other is receiving. Unfortunately, complying with the ETSI and North American emissions masks does not ensure RF coexistence between FDD and TDD systems in this case. This is shown in the hypothetical link susceptibility budget shown below in Table 1.
- RF emissions generated outside of the active tone bandwidth (ATB) arise from the spectral leakage of the rectangular windowed FFTs. For larger FFT sizes, this leakage decays more quickly for a fixed guard band.
- RF emissions generated outside of the active tone bandwidth arise from power amplifier
 intermodulation distortion (IMD) caused principally by 3rd order and 5th order non-linearities.
 The spectral bandwidth of the unwanted emissions is 3 and 5 times the ATB respectively for 3rd
 and 5th order IMD. In typical SS amplifiers, the 3rd order IMD dominates with the 5th order IMD
 15 dB below the 3rd order. The 3rd order IMD is typically controlled by backing off output
 power to meet the emission mask limits. A typical SS power amplifier spectrum is shown in
 Figure 1.
- Power amplifier IMD typically produces more unwanted IMD than spectral leakage from the
 FFT.
- High Q filtering technology is not available at SS price points that would significantly lower 3rd and 5th order IMD for the 2 3.5 MHz bands.
- High Q filtering technology is available at BS price points and can be used to reduce IMD. High Q filtering is usually needed at the BS since the active bandwidth occupies the majority of the channel bandwidth. Typical filter performance provides 20 dB rejection at 0.1% of the filter center frequency. Higher performance is achievable at 0.075% of the filter center frequency.
- Additional 3rd order IMD suppression can be obtained if the IMD falls in guard bands of the channel and adjacent channel. Only 5th order IMD will be present in the victim's band. In this case, the guard band should be specified as 1/2 of the active bandwidth.
- 35

36 Normative references

- 37 This part to be inserted to chapter 2 of the 802.16 standard
- H. Sari, Y. Levy, and G. Karam, "Orthogonal Frequency-Division Multiple Access for the Return
 Channel on CATV Networks," ICT '96 Conf. Rec., vol. 1, pp. 52-57, April 1996, Istanbul, Turkey.
- 40

	2001-05	5-01 Version 0.60 IEEE 802.16.3c-01/59
1 2 3	[2]	H. Sari and G. Karam, "Orthogonal Frequency-Division Multiple Access and its Application to CATV Networks," European Transactions on Telecommunications (ETT), vol. 9, no. 6, pp. 507-516, November - December 1998.
4 5 6	[3]	Richard V. Nee and Ramjee Prasad, "OFDM for wireless multimedia communicatons", Artech House Publishers, 2000.
8 7 8	[4]	802163c-00_33 – Initial OFDM/OFDMA PHY proposal for the 802.16.3 BWA
9 10	[5]	802163c-00_34 – Initial OFDMA/OFDMA PHY proposal for the 802.16.3 BWA
11 12 13	[6]	Document to the WirelessHUMAN TM study group - Proposal for an adaptive OFDM system for the WirelessHUMAN TM standard
14 15 16	[7]	Savo Glisic and Branka Vucteic, "Spread Spectrum CDMA Systems for Wireless Communications", Ch. 2-6, Artech House Inc., 1997.
17 18 19	[8]	William C. Y. Lee, "Mobile Cellular Telecommunications Systems", Ch. 6, McGraw-Hill Book Company, 1989.
20 21 22 23	[9]	Cheong Yui Wong, Roger S. Cheng, Khaled Ben Letaief and Ross D. Murch, "Multiuser OFDM with Adaptive Subcarrier, Bit, and Power Allocation", IEEE Journal on Selected Areas in Communications, Vol. 17, No. 10, pp. 1747-1757, October 1999.
23 24 25 26	[10]	Ye Li and Nelson R. Sollenberger, "Adaptive Antenna Arrays for OFDM Systems with Co-Channel Interference", IEEE Transaction On Communications, Vol. 47, No. 2, pp. 217-229, February 1999.
20 27 28 29 30	[11]	Heidi Steendam and Marc Moeneclaey, "Analysis and Optimization of the Performance of OFDM on Frequency Selective Time-Selective Fading Channels", IEEE Transaction On Communications, Vol. 47, No. 12, pp. 1811-1819, December 1999.
31 32 33	[12]	Andres Vahlin and Nils Holte, "Optimal Finite Duration Pulses for OFDM", IEEE Transaction On Communications, Vol. 44, No. 1, pp. 10-13, January 1996.
34 35	[13]	ETSI EN 300 744 (DVB-T), 1999.
36 37 38	[14]	Scott L. Miller and Robert j. O'Dea, "Peak Power and Bandwidth Efficient Linear Modulation", IEEE transactions on communications, Vol. 46, No. 12, pp. 1639-1648, December 1998.
39 40 41 42	[15]	Kazuki Maeda and Kuniaki Utsumi, "Bit-Error of M-QAM Signal and its Analysis Model for Composite Distortions in AM/QAM Hybrid Transmission", IEEE transactions on communications, Vol. 47, No. 8, pp. 1173-1180, August 1999.
43 44	[16]	EN 301 790, Digital Video Broadcasting (DVB) Interaction Channel for Satellite distribution system.
45 46 47	[17]	A Viterbi Algorithm with Soft-Decision Outputs and its Applications, J. Hagenauer, P. Hocher, IEEE Globecom '89, Nov. 1989, pp. 1680-1685.

	2001-05	E-01 Version 0.60 IEEE 802.16.3c-01/59
1 2 3	[18]	David Chase, "A Class of Algorithms for De-coding Block Codes With Channel measurement. Information," IEEE Transactions of Information Theory, vol. 18, No 1, pp. 170-182, January 1972.
4 5 6	[19]	RunCom Technologies, "Coding Performance of concatenated Reed-Solomon and Convolutional Coding, DVB-RCT Contribution", August 2000
7 8	[20]	DVB-RCT standard draft, October 2000
9 10 11	[21]	G.Drury, G.Markarian, K.Pickavance. "Coding and Modulation for Digital Television", KLUWER Academic Publishers, USA, 2001
12 13 14 15	[22]	ETSI EN 301021 v1.4.1 (2001/03) Fixed Radio Systems; Point-to-multipoint equipment; Time division Multiple access (TDMA); Point-to-Multipoint digital radio systems bands in the range 3 GHz to 11 GHz
16 17 18	[23]	A. Cantoni and L.C. Godara, "Fast Algorithm for Time Domain Broad Band Adaptive Array Processing", IEEE Trans. Aerops. Electr. Syst.AES-18, 682, September 1982.
19 20 21	[25]	Siavash M. Alamouti, "A Simple Transmit Diversity Technique for Wireless Communications", <i>IEEE journal on selected areas in communications</i> , VOL.16, No. 8, pages 1451-1458, October 1998