4. Media Access Control

99. Full-duplex media access control

99.1 Functional model of the MAC method

99.1.1 Overview

The architectural model described in Clause 1 is used in this clause to provide a functional description of the LAN CSMA/CD-full-duplex MAC sublayer.

The MAC sublayer defines a medium-independent facility, built on the medium-dependent physical facility provided by the Physical Layer, and under the access-layer-independent LAN LLC sublayer (or other MAC client). It is applicable to a general class of local area broadcast-point-to-point and point-to-multi-point media suitable for use with the <u>full-duplex</u> media access discipline known as Carrier Sense Multiple Access with Collision Detection (CSMA/CD)discipline.

The LLC sublayer and the MAC sublayer together are intended to have the same function as that described in the OSI model for the Data Link Layer alone. In a broadcast network, The major functionality in the notion of a MAC sublayer is limited to data link between two network entities does not correspond directly to a distinct physical connection. Nevertheless, encapsulation (transmit and receive) along with the partitioning of associated minor functions presented in this standard requires two main functions generally associated with a data link control procedure to be performed in the MAC sublayer. They are as followsincluding:

- a) Data encapsulation (transmit and receive)
- a) Framing (frame boundary delimitation, frame synchronization)
- b) Addressing (handling of source and destination addresses)
- c) Error detection (detection of physical medium transmission errors)
- d) Media Access Management
 - 1) Medium allocation (collision avoidance)
 - 2) Contention resolution (collision handling)

This MAC does not support the *half duplex* mode of operation so there is no need for collision avoidance or handling. Therefore, Media Access Management is limited to the transmission of bits to the physical layer and delaying any transmission for an interframe gap.

An optional MAC control sublayer, architecturally positioned between LLC (or other MAC client) and the MAC, is specified in <u>Clause 31 Clause 31 and Clause 65</u>. This MAC Control sublayer is transparent to both the underlying MAC and its client (typically LLC). The MAC sublayer operates independently of its client; i.e., it is unaware whether the client is LLC or the MAC Control sublayer. This allows the MAC to be specified and implemented in one manner, whether or not the MAC Control sublayer is implemented. References to LLC as the MAC client in text and figures apply equally to the MAC Control sublayer, if implemented.

This standard provides for two modes of operation of the MAC sublayer:

- a) In *half duplex* mode, stations contend for the use of the physical medium, using the CSMA/CD algorithms specified. Bidirectional communication is accomplished by rapid exchange of frames, rather than full duplex operation. Half duplex operation is possible on all supported media; it is required on those media that are incapable of supporting simultaneous transmission and reception without interference, for example, 10BASE2 and 100BASE-T4.
- b) The *full duplex* mode of operation can be used when all of the following are true:
 - 1) The physical medium is capable of supporting simultaneous transmission and reception without interference (e.g., 10BASE-T, 10BASE-FL, and 100BASE-TX/FX).

- 2) There are exactly two stations on the LAN. This allows the physical medium to be treated as a full duplex point-to-point link between the stations. Since there is no contention for use of a shared medium, the multiple access (i.e., CSMA/CD) algorithms are unnecessary.
- 3) Both stations on the LAN are capable of and have been configured to use full duplex operation.

The most common configuration envisioned for full duplex operation consists of a central bridge (also known as a switch) with a dedicated LAN connecting each bridge port to a single device.

The formal specification of the MAC in 99.2 comprises both the half duplex and full duplex modes of operation. The remainder of this clause provides a functional model of the CSMA/CD-this_MAC method.

99.1.2 CSMA/CD operation

99.1.3 Full duplex operation

This subclause provides an overview of frame transmission and reception in terms of the functional model of the architecture. This overview is descriptive, rather than definitional; the formal specifications of the operations described here are given in 99.2 and 99.3. Specific implementations for <u>CSMA/CD-full duplex</u> mechanisms that meet this standard are given in 99.4. Figure 1–1 provides the architectural model described functionally in the subclauses that follow.

The Physical Layer Signaling (PLS) component of the Physical Layer provides an interface to the MAC sublayer for the serial transmission of bits onto the physical media. For completeness, in the operational description that follows some of these functions are included as descriptive material. The concise specification of these functions is given in 99.2 for the MAC functions and in Clause 7 for PLS.

Transmit frame operations are independent from the receive frame operations. A transmitted frame addressed to the originating station will be received and passed to the MAC client at that station. This characteristic of the MAC sublayer may be implemented by functionality within the MAC sublayer or full duplex characteristics of portions of the lower layers.

99.1.3.1 Normal operation

99.1.3.1.1 Transmission without contention

Transmit frame operations are independent from receive frame operations.

99.1.3.2 Transmission

When a MAC client requests the transmission of a frame, the Transmit Data Encapsulation component of the <u>CSMA/CD-full duplex</u> MAC sublayer constructs the frame from the client-supplied data. It prepends a preamble and a Start Frame Delimiter to the beginning of the frame. Using information provided by the client, the <u>CSMA/CD-MAC</u> sublayer also appends a PAD at the end of the MAC information field of sufficient length to ensure that the transmitted frame length satisfies a minimum frame-size requirement (see <u>4.2.3.3)requirement</u>. It also prepends destination and source addresses, the length/type field, and appends a frame check sequence to provide for error detection. If the MAC supports the use of client-supplied frame check sequence values, then it shall use the client-supplied value, when present. If the use of client-supplied frame check sequence values is not supported, or if the client-supplied frame check sequence value is not present, then the MAC shall compute this value. The frame is then handed to Frame transmission may be initiated after the Transmit Media Access Management component in interframe delay, regardless of the MAC sublayer for transmissionpresence of receive activity.

In half duplex mode, Transmit Media Access Management attempts to avoid contention with other traffic on the medium by monitoring the carrier sense signal provided by the Physical Layer Signaling (PLS) compo-

end of the preamble and Start Frame Delimiter.

nent and deferring to passing traffic. When the medium is clear, frame transmission is initiated (after a brief 1 interframe delay to provide recovery time for other CSMA/CD MAC sublayers and for the physical 2 3 medium). The MAC sublayer then provides a serial stream of bits to the Physical Layer for transmission. 4 5 In half duplex mode, at an operating speed of 1000 Mb/s, the minimum frame size is insufficient to ensure the proper operation of the CSMA/CD protocol for the desired network topologies. To circumvent this prob-6 7 lem, the MAC sublayer will append a sequence of extension bits to frames which are less than slotTime bits in length so that the duration of the resulting transmission is sufficient to ensure proper operation of the 8 CSMA/CD protocol. 9 10 In half duplex mode, at an operating speed of 1000 Mb/s, the CSMA/CD MAC may optionally transmit 11 additional frames without relinquishing control of the transmission medium, up to a specified limit. 12 13 In full duplex mode, there is no need for Transmit Media Access Management to avoid contention with 14 other traffic on the medium. Frame transmission may be initiated after the interframe delay, regardless of the 15 presence of receive activity. In full duplex mode, the MAC sublayer does not perform either carrier exten-16 17 sion or frame bursting. 18 19 When operating in point-to-multi-point mode, contention avoidance with other traffic on the medium cannot be managed by this MAC sublayer as there are multiple MACs in parallel with this one. Sublayers other than 20 this must be responsible for contention avoidance. 21 22 The Physical Layer performs the task of generating the signals on the medium that represent the bits of the 23 frame. Simultaneously, it monitors the medium and generates the collision detect signal, which in the con-24 tention-free case under discussion, remains off for the duration of the frame. A functional description of the 25 Physical Layer is given in Clause 7 and beyond. 26 27 When transmission has completed without contention completed, the CSMA/CD-MAC sublayer so informs 28 the MAC client and awaits the next request for frame transmission. 29 30 99.1.3.2.1 Reception without contention 31 32 99.1.3.3 Reception 33 34 At each receiving station, the arrival of a frame is first detected by the Physical Layer, which responds by 35 synchronizing with the incoming preamble, and by turning on the receiveDataValid signal. As the encoded 36 bits arrive from the medium, they are decoded and translated back into binary data. The Physical Layer 37 passes subsequent bits up to the MAC sublayer, where the leading bits are discarded, up to and including the 38

Meanwhile, the Receive Media Access Management component of the MAC sublayer, having observed receiveDataValid, has been waiting for the incoming bits to be delivered. Receive Media Access Management collects bits from the Physical Layer entity as long as the receiveDataValid signal remains on. When the receiveDataValid signal is removed, the frame is truncated to an octet boundary, if necessary, and passed to Receive Data Decapsulation for processing.

Receive Data Decapsulation checks the frame's Destination Address field to decide whether the frame should be received by this station. If so, it passes the Destination Address (DA), the Source Address (SA), the Length/Type-Type, the Data Data, and (optionally) the Frame Check Sequence (FCS) fields to the MAC client, along with an appropriate status code, as defined in 4.3.299.3.2. It also checks for invalid MAC frames by inspecting the frame check sequence to detect any damage to the frame enroute, and by checking for proper octet-boundary alignment of the end of the frame. Frames with a valid FCS may also be checked for proper octet-boundary alignment.

52 53 54

39 40 41

42

43

44

45 46 47

48

49

50

In half duplex mode, at an operating speed of 1000 Mb/s, frames may be extended by the transmitting station under the conditions described in 4.2.3.4. The extension is discarded by the MAC sublayer of the receiving station, as defined in the procedural model in 4.2.9.

99.1.3.4 Access interference and recovery

In half duplex mode, if multiple stations attempt to transmit at the same time, it is possible for them to interfere with each other's transmissions, in spite of their attempts to avoid this by deferring. When transmissions from two stations overlap, the resulting contention is called a collision. Collisions occur only in half duplex mode, where a collision indicates that there is more than one station attempting to use the shared physical medium. In full duplex mode, two stations may transmit to each other simultaneously without causing interference. The Physical Layer may generate a collision indication, but this is ignored by the full duplex MAC.

A given station can experience a collision during the initial part of its transmission (the collision window) before its transmitted signal has had time to propagate to all stations on the CSMA/CD medium. Once the collision window has passed, a transmitting station is said to have acquired the medium; subsequent collisions are avoided since all other (properly functioning) stations can be assumed to have noticed the signal and to be deferring to it. The time to acquire the medium is thus based on the round-trip propagation time of the Physical Layer whose elements include the PLS, PMA, and physical medium.

In the event of a collision, the transmitting station's Physical Layer initially notices the interference on the medium and then turns on the collision detect signal. In half duplex mode, this is noticed in turn by the Transmit Media Access Management component of the MAC sublayer, and collision handling begins. First, Transmit Media Access Management enforces the collision by transmitting a bit sequence called jam. In 99.4, implementations that use this enforcement procedure are provided. This ensures that the duration of the collision is sufficient to be noticed by the other transmitting station(s) involved in the collision. After the jam is sent, Transmit Media Access Management terminates the transmission and schedules another transmission attempt after a randomly selected time interval. Retransmission is attempted again in the face of repeated collisions. Since repeated collisions indicate a busy medium, however, Transmit Media Access Management attempts to adjust to the medium load by backing off (voluntarily delaying its own retransmissions to reduce its load on the medium). This is accomplished by expanding the interval from which the random retransmission time is selected on each successive transmit attempt. Eventually, either the transmission succeeds, or the attempt is abandoned on the assumption that the medium has failed or has become overloaded.

In full duplex mode, a station ignores any collision detect signal generated by the Physical Layer. Transmit Media Access Management in a full duplex station will always be able to transmit its frames without contention, so there is never any need to jam or reschedule transmissions.

At the receiving end, the bits resulting from a collision are received and decoded by the PLS just as are the bits of a valid frame. Fragmentary frames received during collisions are distinguished from valid transmissions by the MAC sublayer's Receive Media Access Management component.

99.1.4 Relationships to the MAC client and Physical Layersphysical layers

The CSMA/CD-MAC sublayer provides services to the MAC client required for the transmission and reception of frames. Access to these services is specified in 99.3. The CSMA/CD-MAC sublayer makes a best effort to acquire the medium and transfer a serial stream of bits to the Physical Layer. Although certain errors are reported to the client, error recovery is not provided by MAC. Error recovery may be provided by the MAC client or higher (sub)layers.

3

4 5 6

7 8

13

14 15

16 17

18

19 20

21 22 23

24 25 26

27

28 29

30

31 32

33 34 35

36

37

38

39

40

41

42 43

44

45

46

47

48

49

50

51

52

53 54

99.1.5 CSMA/CD access Access method functional capabilities The following summary of the functional capabilities of the CSMA/CD-MAC sublayer is intended as a quick reference guide to the capabilities of the standard, as shown in Figure 99-2: MAC CLIENT SUBLAYER ACCESS TO MAC CLIENT TRANSMIT RECEIVE DATA ENCAPSULATION DATA DECAPSULATION b2 b3 a1 TRANSMIT MEDIA RECEIVE MEDIA ACCESS MANAGEMENT ACCESS MANAGEMENT a2 c d f g h i k m bl e j l n ACCESS TO PHYSICAL INTERFACE TRANSMIT RECEIVE DATA ENCODING DATA DECODING PHYSICAL LAYER SIGNALING


NOTE—a1, b2, etc., refer to functions listed in 99.1.5.

Figure 99–1—CSMA/CD Media Access Control functions

- a) For Frame Transmission
 - 1) Accepts data from the MAC client and constructs a frame.
 - 2) Presents a bit-serial data stream to the Physical Layer for transmission on the medium.

NOTE—Assumes data passed from the client sublayer are octet multiples.

- b) For Frame Reception
 - 1) Receives a bit-serial data stream from the Physical Layer.
 - 2) Presents to the MAC client sublayer frames that are either broadcast frames or directly addressed to the local station.
 - 3) Discards or passes to Network Management all frames not addressed to the receiving station.
- e) In half duplex mode, defers transmission of a bit-serial stream whenever the physical medium is busy.
- d) Appends proper FCS value to outgoing frames and verifies full octet boundary alignment.
- e) Checks incoming frames for transmission errors by way of FCS and verifies octet boundary alignment
- f) Delays transmission of frame bit stream for specified interframe gap period.
- g) In half duplex mode, halts transmission when collision is detected.
- h) In half duplex mode, schedules retransmission after a collision until a specified retry limit is reached.
- i) In half duplex mode, enforces collision to ensure propagation throughout network by sending jam message.



A precise algorithmic definition is given in this subclause, providing procedural model for the CSMA/CD MAC process with a program in the computer language Pascal. See references [B11] and [B34] for resource material. Note whenever there is any apparent ambiguity concerning the definition of some aspect of the CSMA/CD-MAC method, it is the Pascal procedural specification in 99.2.7 through 99.2.11 which-that should be consulted for the definitive statement. Subclauses 99.2.2 through 99.2.6 provide, in prose, a description of the access mechanism with the formal terminology to be used in the remaining subclauses.

47

48

49

50

51

99.2.2 Overview of the procedural model

The functions of the CSMA/CD-MAC method are presented below, modeled as a program written in the computer language Pascal. This procedural model is intended as the primary specification of the functions to be provided in any CSMA/CD-MAC sublayer implementation. It is important to distinguish, however, between the model and a real implementation. The model is optimized for simplicity and clarity of presentation, while any realistic implementation shall place heavier emphasis on such constraints as efficiency and suitability to a particular implementation technology or computer architecture. In this context, several important properties of the procedural model shall be considered.

99.2.2.1 Ground rules for the procedural model

- a) First, it shall be emphasized that *the description of the MAC sublayer in a computer language is in no way intended to imply that procedures shall be implemented as a program executed by a computer.* The implementation may consist of any appropriate technology including hardware, firmware, software, or any combination.
- b) Similarly, it shall be emphasized that it is the behavior of any MAC sublayer implementations that shall match the standard, not their internal structure. The internal details of the procedural model are useful only to the extent that they help specify that behavior clearly and precisely.
- c) The handling of incoming and outgoing frames is rather stylized in the procedural model, in the sense that frames are handled as single entities by most of the MAC sublayer and are only serialized for presentation to the Physical Layer. In reality, many implementations will instead handle frames serially on a bit, octet or word basis. This approach has not been reflected in the procedural model, since this only complicates the description of the functions without changing them in any way.
- d) The model consists of algorithms designed to be executed by a number of concurrent processes; these algorithms collectively implement the <u>CSMA/CD-MAC</u> procedure. The timing dependencies introduced by the need for concurrent activity are resolved in two ways:
 - Processes Versus External Events. It is assumed that the algorithms are executed "very fast" relative to external events, in the sense that a process never falls behind in its work and fails to respond to an external event in a timely manner. For example, when a frame is to be received, it is assumed that the Media Access procedure ReceiveFrame is always called well before the frame in question has started to arrive.
 - 2) *Processes Versus Processes*. Among processes, no assumptions are made about relative speeds of execution. This means that each interaction between two processes shall be structured to work correctly independent of their respective speeds. Note, however, that the timing of interactions among processes is often, in part, an indirect reflection of the timing of external events, in which case appropriate timing assumptions may still be made.

It is intended that the concurrency in the model reflect the parallelism intrinsic to the task of implementing the MAC client and MAC procedures, although the actual parallel structure of the implementations is likely to vary.

99.2.2.2 Use of **Paseal**-pascal in the procedural model

Several observations need to be made regarding the method with which Pascal is used for the model. Some of these observations are as follows:

- a) The following limitations of the language have been circumvented to simplify the specification:
 - 1) The elements of the program (variables and procedures, for example) are presented in logical groupings, in top-down order. Certain Pascal ordering restrictions have thus been circumvented to improve readability.
 - 2) The *process* and *cycle* constructs of Concurrent Pascal, a Pascal derivative, have been introduced to indicate the sites of autonomous concurrent activity. As used here, a process is simply a parameterless procedure that begins execution at "the beginning of time" rather than being

I

invoked by a procedure call. A cycle statement represents the main body of a process and is executed repeatedly forever.

- 3) The lack of variable array bounds in the language has been circumvented by treating frames as if they are always of a single fixed size (which is never actually specified). The size of a frame depends on the size of its data field, hence the value of the "pseudo-constant" frameSize should be thought of as varying in the long term, even though it is fixed for any given frame.
- 4) The use of a variant record to represent a frame (as fields and as bits) follows the spirit but not the letter of the Pascal Report, since it allows the underlying representation to be viewed as two different data types.
- b) The model makes no use of any explicit interprocess synchronization primitives. Instead, all interprocess interaction is done by way of carefully stylized manipulation of shared variables. For example, some variables are set by only one process and inspected by another process in such a manner that the net result is independent of their execution speeds. While such techniques are not generally suitable for the construction of large concurrent programs, they simplify the model and more nearly resemble the methods appropriate to the most likely implementation technologies (microcode, hardware state machines, etc.)

99.2.2.3 Organization of the procedural model

The procedural model used here is based on seven-five cooperating concurrent processes. The Frame Transmitter process and the Frame Receiver process are provided by the clients of the MAC sublayer (which may include the LLC sublayer) and make use of the interface operations provided by the MAC sublayer. The other five-three processes are defined to reside in the MAC sublayer. The seven-five processes are as follows:

- a) Frame Transmitter process
- b) Frame Receiver process
- c) Bit Transmitter process
- d) Bit Receiver process
- e) Deference process
- f) BurstTimer process
- g) SetExtending process

This organization of the model is illustrated in Figure 99–4 and reflects the fact that the communication of entire frames is initiated by the client of the MAC sublayer, while the timing of collision backoff and of individual bit transfers is based on interactions between the MAC sublayer and the Physical-Layer-dependent bit time.

Figure 99–4 depicts the static structure of the procedural model, showing how the various processes and procedures interact by invoking each other. Figures 99–5a, 99–5b, and 99–6, and 99–7b summarize the dynamic behavior of the model during transmission and reception, focusing on the steps that shall be performed, rather than the procedural structure that performs them. The usage of the shared state variables is not depicted in the figures, but is described in the comments and prose in the following subclauses.

99.2.2.4 Layer management extensions to procedural model

In order to incorporate network management functions, this Procedural Model has been expanded beyond that provided in ISO/IEC 8802-3: 1990. Network management functions have been incorporated in two ways. First, 99.2.7–99.2.11, 99.3.2, Figure 99–5a, and Figure 99–5b have been modified and expanded to provide management services. Second, Layer Management procedures have been added as 5.2.4. Note that Pascal variables are shared between Clauses 99 and 5. Within the Pascal descriptions provided in Clause 99, a "‡" in the left margin indicates a line that has been added to support management services. These lines are




Figure 99–2—Relationship among CSMA/CD procedures

only required if Layer Management is being implemented. These changes do not affect any aspect of the MAC behavior as observed at the LLC-MAC and MAC-PLS interfaces of ISO/IEC 8802-3: 1990.

The Pascal procedural specification shall be consulted for the definitive statement when there is any apparent ambiguity concerning the definition of some aspect of the CSMA/CD-MAC access method.

The Layer Management facilities provided by the CSMA/CD-MAC and Physical Layer management definitions provide the ability to manipulate management counters and initiate actions within the layers. The





Figure 99–3a—Control flow summary





managed objects within this standard are defined as sets of attributes, actions, notifications, and behaviors in accordance with IEEE Std 802.1F-1993, and ISO/IEC International Standards for network management.

99.2.3 Frame transmission model

Frame transmission includes data encapsulation and Media Access management aspects:

- a) Transmit Data Encapsulation includes the assembly of the outgoing frame (from the values provided by the MAC client) and frame check sequence generation.
- b) Transmit Media Access Management includes carrier deference, interframe spacing, collision detection_spacing_and enforcement, collision_backoff and retransmission, carrier extension and frame burstingbit transmission.






99.2.3.1 Transmit data encapsulation


The fields of the CSMA/CD-MAC frame are set to the values provided by the MAC client as arguments to the TransmitFrame operation (see 4.399.3) with the following possible exceptions: the padding field, the extension field, field and the frame check sequence. The padding field is necessary to enforce the minimum frame size. The extension field is necessary to enforce the minimum carrier event duration on the medium in half duplex mode at an operating speed of 1000 Mb/s. The frame check sequence field may be (optionally) provided as an argument to the MAC sublayer. It is optional for a MAC to support the provision of the frame check sequence in such an argument. If this field is not provided by the MAC client, or if the MAC does not support the provision of the frame check sequence as an external argument, it is set to the CRC value generated by the MAC sublayer, after appending the padding field, if necessary.


99.2.3.2 Transmit media access management

99.2.3.2.1 Deference

When a frame is submitted by the MAC client for transmission, the transmission is initiated as soon as possible, but in conformance with the rules of deference stated below. The rules of deference differ between half duplex and full duplex modes.









no

*

*





If, at the end of the interFrameSpacing, a frame is waiting to be transmitted, transmission is initiated independent of the value of carrierSense. When transmission has completed (or immediately, if there was nothing to transmit) the CSMA/CD MAC sublayer resumes its original monitoring of carrierSense.

NOTE It is possible for the PLS carrier sense indication to fail to be asserted briefly during a collision on the media. If the Deference process simply times the interframe gap based on this indication it is possible for a short interframe gap to be generated, leading to a potential reception failure of a subsequent frame. To enhance system robustness the following optional measures, as specified in 99.2.8, are recommended when interFrameSpacingPart1 is other than zero:

Start the timing of the interFrameSpacing as soon as transmitting and carrierSense are both false. Reset the interFrameSpacing timer if carrierSense becomes true during the first 2/3 of the inter-FrameSpacing timing interval. During the final 1/3 of the interval, the timer shall not be reset to ensure fair access to the medium. An initial period shorter than 2/3 of the interval is permissible including zero.

b) Full duplex mode

In full duplex mode, When a frame is submitted by the CSMA/CD-MAC does not defer pending transmissions based on client for transmission, the carrierSense signal from transmission is initiated as soon as possible, but in conformance with the PLSfollowing rule. Instead, it The MAC uses the internal variable *transmitting* to maintain proper MAC state while the <u>a</u> transmission is in progress. After the last bit of a transmitted frame, (that is, when *transmitting* changes from true to false), the MAC continues to defer for a proper interFrameSpacing (see 99.2.3.2.2).

99.2.3.2.2 Interframe spacing

As defined in 99.2.3.2.1, the <u>rules rule for deferring to passing frames ensure ensures</u> a minimum interframe spacing of interFrameSpacing bit times. This is intended to provide interframe recovery time for other <u>CSMA/CD sublayers and for to aid in frame delineation on</u> the physical medium.

Note that interFrameSpacing is the minimum value of the interframe spacing. If necessary for implementation reasons, a transmitting sublayer may use a larger value with a resulting decrease in its throughput. The larger value is determined by the parameters of the implementation, see 99.4.

A larger value for interframe spacing is used for dynamically adapting the nominal data rate of the MAC sublayer to SONET/SDH data rates (with packet granularity) for WAN-compatible applications of this standard. While in this optional mode of operation, the MAC sublayer counts the number of bits sent during a frame's transmission. After the frame's transmission has been completed, the MAC sublayer extends the minimum interframe spacing by a number of bits that is proportional to the length of the previously transmitted frame. For more details, see <u>4.2.7-99.2.7</u> and <u>4.2.899.2.8</u>.

99.2.3.2.3 Collision handling (half duplex mode only)

Once a CSMA/CD sublayer has finished deferring and has started transmission, it is still possible for it to experience contention for the medium. Collisions can occur until acquisition of the network has been accomplished through the deference of all other stations' CSMA/CD sublayers.

The dynamics of collision handling are largely determined by a single parameter called the slot time. This single parameter describes three important aspects of collision handling:

- a) It is an upper bound on the acquisition time of the medium.
- b) It is an upper bound on the length of a frame fragment generated by a collision.
- e) It is the scheduling quantum for retransmission.

To fulfill all three functions, the slot time shall be larger than the sum of the Physical Layer round-trip propagation time and the Media Access Layer maximum jam time. The slot time is determined by the parameters of the implementation, see 99.4.

99.2.3.2.4 Collision detection and enforcement (half duplex mode only)

Collisions are detected by monitoring the collisionDetect signal provided by the Physical Layer. When a collision is detected during a frame transmission, the transmission is not terminated immediately. Instead, the transmission continues until additional bits specified by jamSize have been transmitted (counting from the time collisionDetect went on). This collision enforcement or jam guarantees that the duration of the collision is sufficient to ensure its detection by all transmitting stations on the network. The content of the jam is unspecified; it may be any fixed or variable pattern convenient to the Media Access implementation; however, the implementation shall not be intentionally designed to be the 32-bit CRC value corresponding to the (partial) frame transmitted prior to the jam.

99.2.3.2.5 Collision backoff and retransmission (half duplex mode only)

When a transmission attempt has terminated due to a collision, it is retried by the transmitting CSMA/CD sublayer until either it is successful or a maximum number of attempts (attemptLimit) have been made and all have terminated due to collisions. Note that all attempts to transmit a given frame are completed before any subsequent outgoing frames are transmitted. The scheduling of the retransmissions is determined by a controlled randomization process called "truncated binary exponential backoff." At the end of enforcing a collision (jamming), the CSMA/CD sublayer delays before attempting to retransmit the frame. The delay is an integer multiple of slotTime. The number of slot times to delay before the nth retransmission attempt is chosen as a uniformly distributed random integer r in the range:

 $\theta \leq r < 2^k$

where

 $k = \min(n, 10)$

If all attemptLimit attempts fail, this event is reported as an error. Algorithms used to generate the integer r should be designed to minimize the correlation between the numbers generated by any two stations at any given time.

Note that the values given above define the most aggressive behavior that a station may exhibit in attempting to retransmit after a collision. In the course of implementing the retransmission scheduling procedure, a station may introduce extra delays that will degrade its own throughput, but in no case may a station's retransmission scheduling result in a lower average delay between retransmission attempts than the procedure defined above.

99.2.3.2.6 Full duplex transmission

In full duplex mode, there is never contention for a shared physical medium. The Physical Layer may indicate to the MAC that there are simultaneous transmissions by both stations, but since these transmissions do not interfere with each other, a MAC operating in full duplex mode must not react to such Physical Layer indications. Full duplex stations do not defer to received traffie, nor abort transmission, jam, backoff, and reschedule transmissions as part of Transmit Media Access Management. Transmissions may be initiated whenever the station has a frame queued, subject only to the interframe spacing required to allow recovery for other sublayers and for the physical medium.

99.2.3.2.7 Frame bursting (half duplex mode only)

At an operating speed of 1000 Mb/s, an implementation may optionally transmit a series of frames without relinquishing control of the transmission medium. This mode of operation is referred to as *burst mode*. Once a frame has been successfully transmitted, the transmitting station can begin transmission of another frame without contending for the medium because all of the other stations on the network will continue to defer to its transmission, provided that it does not allow the medium to assume an idle condition between frames. The transmitting station fills the interframe spacing interval with extension bits, which are readily distinguished from data bits at the receiving stations, and which maintain the detection of carrier in the receiving stations. The transmitting station is allowed to initiate frame transmission until a specified limit, referred to as burstLimit, is reached. The value of burstLimit is specified in 99.4.2. Figure 99–5 shows an example of transmission with frame bursting.

The first frame of a burst will be extended, if necessary, as described in 99.2.3.4. Subsequent frames within a burst do not require extension. In a properly configured network, and in the absence of errors, collisions cannot occur during a burst at any time after the first frame of a burst (including any extension) has been transmitted. Therefore, the MAC will treat any collision that occurs after the first frame of a burst, or that occurs after the slotTime has been reached in the first frame of a burst, as a late collision.




Figure 99–5—Frame bursting

99.2.3.3 Minimum frame size

The CSMA/CD Media Access mechanism requires that a minimum frame length of minFrameSize bits be transmitted. If frameSize is less than minFrameSize, then the CSMA/CD MAC sublayer shall append extra bits in units of octets (pad), after the end of the MAC elient data field but prior to calculating, and appending, the FCS (if not provided by the MAC elient). The number of extra bits shall be sufficient to ensure that the frame, from the DA field through the FCS field inclusive, is at least minFrameSize bits. If the FCS is (optionally) provided by the MAC elient, the pad shall also be provided by the MAC elient. The content of the pad is unspecified.

99.2.3.4 Carrier extension (half duplex mode only)

At an operating speed of 1000 Mb/s, the slotTime employed at slower speeds is inadequate to accommodate network topologies of the desired physical extent. Carrier Extension provides a means by which the slotTime can be increased to a sufficient value for the desired topologies, without increasing the minFrameSize parameter, as this would have deleterious effects. Nondata bits, referred to as extension bits, are appended to frames that are less than slotTime bits in length so that the resulting transmission is at least one slotTime in duration. Carrier Extension can be performed only if the underlying physical layer is capable of sending and receiving symbols that are readily distinguished from data symbols, as is the case in most physical layers that use a block encoding/decoding scheme. The maximum length of the extension is equal to the quantity (slotTime — minFrameSize). Figure 99–6 depicts a frame with carrier extension.

The MAC continues to monitor the medium for collisions while it is transmitting extension bits, and it will treat any collision that occurs after the threshold (slotTime) as a late collision.




Figure 99–6—Frame with carrier extension

99.2.3.4.1 Transmission

Transmissions may be initiated whenever the station has a frame queued, subject only to the interframe spacing required to allow recovery for the physical medium.

99.2.4 Frame reception model

- CSMA/CD-The MAC sublayer frame reception includes both data decapsulation and Media Access management aspects:
 - a) Receive Data Decapsulation comprises address recognition, frame check sequence validation, and frame disassembly to pass the fields of the received frame to the MAC client.
 - b) Receive Media Access Management comprises <u>recognition assembly</u> of <u>collision fragments frames</u> from <u>incoming frames and truncation of frames to oetet boundaries the received bits</u>.

99.2.4.1 Receive data decapsulation

99.2.4.1.1 Address recognition

The CSMA/CD-MAC sublayer is capable of recognizing individual and group addresses.

- a) *Individual Addresses*. The CSMA/CD-MAC sublayer recognizes and accepts any frame whose DA field contains the individual address of the station.
- b) *Group Addresses*. The CSMA/CD-MAC sublayer recognizes and accepts any frame whose DA field contains the Broadcast address.

The CSMA/CD-MAC sublayer is capable of activating some number of group addresses as specified by higher layers. The CSMA/CD-MAC sublayer recognizes and accepts any frame whose Destination Address field contains an active group address. An active group address may be deactivated.

The MAC sublayer may also provide the capability of operating in the promiscuous receive mode. In this mode of operation, the MAC sublayer recognizes and accepts all valid frames, regardless of their Destination Address field values.

99.2.4.1.2 Frame check sequence validation

FCS validation is essentially identical to FCS generation. If the bits of the incoming frame (exclusive of the FCS field itself) do not generate a CRC value identical to the one received, an error has occurred and the frame is identified as invalid.

99.2.4.1.3 Frame disassembly

Upon recognition of the Start Frame Delimiter at the end of the preamble sequence, the CSMA/CD-MAC sublayer accepts the frame. If there are no errors, the frame is disassembled and the fields are passed to the MAC client by way of the output parameters of the ReceiveFrame operation.

99.2.4.2 Receive media access management

99.2.4.2.1 Framing

The <u>CSMA/CD-MAC</u> sublayer recognizes the boundaries of an incoming frame by monitoring the receive-DataValid signal provided by the Physical Layer. Two possible length errors can occur that indicate illframed data: the frame may be too long, or its length may not be an integer number of octets.

- a) Maximum Frame Size. The receiving CSMA/CD-MAC sublayer is not required to enforce the frame size limit, but it is allowed to truncate frames longer than maxUntaggedFrameSize octets and report this event as an (implementation-dependent) error. A receiving CSMA/CD-MAC sublayer that supports tagged MAC frames (see 3.5) may similarly truncate frames longer than (maxUntaggedFrame-Size + qTagPrefixSize) octets in length, and report this event as an (implementation-dependent) error.
 - b) Integer Number of Octets in Frame. Since the format of a valid frame specifies an integer number of octets, only a collision or an error can produce a frame with a length that is not an integer multiple of 8 bits. Complete frames (that is, not rejected as collision fragments; see 99.2.4.2.2) that do not contain an integer number of octets are truncated to the nearest octet boundary. If frame check sequence validation detects an error in such a frame, the status code alignmentError is reported.

When a burst of frames is received while operating in half duplex mode at an operating speed of 1000 Mb/s, the individual frames within the burst are delimited by sequences of interframe fill symbols, which are conveyed to the receiving MAC sublayer as extension bits. Once the collision filtering requirements for a given frame, as described in 99.2.4.2.2, have been satisfied, the receipt of an extension bit can be used as an indication that all of the data bits of the frame have been received.

99.2.4.2.2 Collision filtering

In the absence of a collision, the shortest valid transmission in half duplex mode must be at least one slot-Time in length. Within a burst of frames, the first frame of a burst must be at least slotTime bits in length in order to be accepted by the receiver, while subsequent frames within a burst must be at least minFrameSize in length. Anything less is presumed to be a fragment resulting from a collision, and is discarded by the receiver. In half duplex mode, occasional collisions are a normal part of the Media Access management procedure. The discarding of such a fragment by a MAC is not reported as an error.

The shortest valid transmission in full duplex mode must be at least minFrameSize in length. While collisions do not occur in full duplex mode MACs, a full duplex MAC nevertheless discards received frames containing less than minFrameSize bits. The discarding of such a frame by a MAC is not reported as an error.

99.2.5 Preamble generation

In a LAN implementation, most of the Physical Layer components are allowed to provide valid output some number of bit times after being presented valid input signals. Thus it is necessary for a preamble to be sent before the start of data, to allow the PLS circuitry to reach its steady state. Upon request by TransmitLink-Mgmt to transmit the first bit of a new frame, <u>PhysicalSignalEncap-BitTransmitter</u> shall first transmit the preamble, a bit sequence used for physical medium stabilization and synchronization, followed by the Start

I

I

Frame Delimiter. If, while transmitting the preamble or Start Frame Delimiter, the collision detect variable becomes true, any remaining preamble and Start Frame Delimiter bits shall be sent. The preamble pattern is:

10101010 10101010 10101010 10101010 10101010 10101010 10101010

The bits are transmitted in order, from left to right. The nature of the pattern is such that, for Manchester encoding, it appears as a periodic waveform on the medium that enables bit synchronization. It should be noted that the preamble ends with a "0."

99.2.6 Start frame sequence

The receiveDataValid signal is the indication to the MAC that the frame reception process should begin. Upon reception of the sequence 10101011 following the assertion of receiveDataValid, PhysicalSignalDecap shall begin passing successive bits to ReceiveLinkMgmt for passing to the MAC client.

99.2.7 Global declarations

This subclause provides detailed formal specifications for the CSMA/CD-MAC sublayer. It is a specification of generic features and parameters to be used in systems implementing this media access method. Subclause 99.4 provides values for these sets of parameters for recommended implementations of this media access mechanism.

99.2.7.1 Common constants, types, and variables

The following declarations of constants, types and variables are used by the frame transmission and reception sections of each <u>CSMA/CD-MAC</u> sublayer:

	27
const	28
addressSize = 48; {In bits, in compliance with 3.2.3}	29
lengthOrTypeSize = 16; {In bits}	30
clientDataSize =; {In bits, size of MAC client data; see $\frac{4.2.2.299.2.2.2}{99.2.2.2}$, $\frac{1}{8a}$ }	31
padSize =; { <u>iIn In</u> bits, = max (0, minFrameSize – (2 x addressSize + lengthOrTypeSize +	32
clientDataSize + crcSize))}	33
dataSize =; {In bits, = clientDataSize + padSize}	34
crcSize = 32; {In bits, 32 <u>-</u> bit CRC}	35
frameSize =; {In bits, = 2 x addressSize + lengthOrTypeSize + dataSize + crcSize; see 4.2.2.2, a)}	36
minFrameSize = ; {In bits, implementation-dependent, see 4.4}	37
qTagPrefixSize-minFrameSize = 4; {In octetsbits, length of QTag Prefiximplementation-dependent,	38
see 34.54	39
extend_maxUntaggedFrameSize =; {BooleaniIn_octets, true_if (slotTimeminFrameSize) >	40
Oimplementation-dependent, false otherwise see 4.4	41
extensionBit qTagPrefixSize =4; {A nondata value which is used for carrier extension and interframe	42
during burstsIn octets, length of QTag Prefix, see 3.5}	43
extensionErrorBit =; {A nondata value which is used to jam during carrier extension}	44
minTypeValue = 1536; {Minimum value of the Length/Type field for Type interpretation}	45
maxValidFrame = maxUntaggedFrameSize - (2 x addressSize + lengthOrTypeSize + crcSize) / 8;	46
{In octets, the maximum length of the MAC client data field. This constant is	47
defined for editorial convenience, as a function of other constants}	48
slotTime =; {In bit times, unit of time for collision handling, implementation-dependent, see 4.4}	49
preambleSize = 56; {In bits, see 4.2.5}	50
$sfdSize = 8; {In bits, start frame delimiter}$	51
headerSize = 64; {In bits, sum of preambleSize and sfdSize}	52
type	53
syre	54

PhysicalBit Bit = (0, 1, extensionBit, extensionErrorBit); 1
(Bits transmitted to the Physical Layer can be either 0, 1, extensionBit or 2
extensionErrorBit. PhysicalBit = $(0, 1)$; {Bits received from transmitted to 3
the Physical Layer can be either $\frac{0}{0}$, <u>0 or 1</u> . <u>Bits received</u> 4
from the Physical Layer can be either 0 or extensionBit.1} 5
AddressValue = array [1addressSize] of Bit;
LengthOrTypeValue = array [1lengthOrTypeSize] of Bit; 77
$DataValue = array [1dataSize] of Bit; {Contains the portion of the frame that starts with the first bit 8$
following the Length/Type field and ends with the last bit 9
prior to the FCS field. For VLAN Tagged frames, this value
includes the Tag Control Information field and the original
MAC client Length/Type field. See 3.5}
CRCValue = array [1crcSize] of Bit; $PreambleValue = array [1preambleSize] of Bit;$ 1
PreambleValue = $array$ [1preambleSize] of Bit;1SfdValue = $array$ [1sfdSize] of Bit;1
ViewPoint = (fields, bits); {Two ways to view the contents of a frame}
HeaderViewPoint = (headerFields, headerBits);
$Frame = record \{Format of Media Access frame\}$
case view: ViewPoint of
fields: (
destinationField: AddressValue; 2
sourceField: AddressValue; 2
lengthOrTypeField: LengthOrTypeValue; 2
dataField: DataValue; 2
fcsField: CRCValue); 2
bits: (contents: <i>array</i> [1frameSize] <i>of</i> Bit) 2
end; {Frame}
Header = $record$ {Format of preamble and start frame delimiter} 22
<i>case</i> headerView: HeaderViewPoint <i>of</i> 3 headerFields: (
headerFields: (preamble: PreambleValue; 3
sfd: SfdValue);
headerContents: <i>array</i> [1headerSize] <i>of</i> Bit)
headerBits: (headerContents: <i>array</i> [1headerSize] <i>of</i> Bit) 3
end; {Defines header for MAC frame}
var 3
halfDuplex: Boolean; {Indicates the desired mode <u>of operation</u> , halfDuplex is a static variable; its value 3
shall only be changed by the invocation of the Initialize procedure}
4
99.2.7.2 Transmit state variables
The following items are specific to frame transmission. (See also 99.4.) 4
The following items are specific to frame transmission. (See also 99.4.)44
const 4
interFrameSpacing =; {In bit times, minimum gap between frames. Equal to interFrameGap, 4
$\frac{1}{\sec 4.4}$
interFrameSpacingPart1 =; {In bit times, duration of the first portion of interFrameSpacing. In the 4
range of 0 to 2/3 of interFrameSpacing} 4
interFrameSpacingPart2 <u>interFrameSpacing</u> =; {In bit times, duration of the remainder of inter- 5
FrameSpacingminimum gap between frames. Equal to 5
interFrameSpacing – interFrameSpacingPart1}to interFrameGap. 5
interFrameSize =; {in bits, length of interframe fill during a burst. Equal to interFrameGap-
divided by the bit periodsee 99.4}

1	ifsStretchRatio =; {In bits, determines the number of bits in a frame that require one octet of
2	interFrameSpacing extension, when ifsStretchMode is enabled; implementation
3	dependent, see 4.4}
4	attemptLimit =; {Max number of times to attempt transmission}
5	<pre>backOffLimit =; {Limit on number of times to back off}</pre>
6	burstLimit=; {In bits, limit for initiation of frame transmission in Burst Mode,
7	implementation dependent, see 4.4}
8	jamSize =; {In bits, the value depends upon medium and collision detect implementation}
9	var
10	outgoingFrame: Frame; {The frame to be transmitted}
11	outgoingHeader: Header;
12	currentTransmitBit, lastTransmitBit: 1frameSize; {Positions of current and last outgoing bits in
13	outgoingFrame}
14 15	lastHeaderBit: 1headerSize;
15 16	frameWaitingdeferring: Boolean; {Indicates that outgoingFrame is deferringImplies any pending trans-
16 17	<u>mission must wait</u> }
17	attemptsframeWaiting: 0attemptLimitBoolean; {Number of transmission attempts on outgoing-
18	FrameIndicates that outgoingFrame is deferring} newCollisionifsStretchMode: Boolean; {Indicates that a collision has occurred but has not yet been
19 20	
20 21	jammed} the desired mode of operation, and enables the lowering of the transmitSuggarding: Realean: (Running indicator of whather transmission is suggarding)
21 22	transmitSucceeding: Boolean; (Running indicator of whether transmission is succeeding)
	burstMode: Boolean; {Indicates the desired mode of operation, and enables the transmission of
23	multiple frames in a single carrier event. burstMode is a static variable; its
24 25	value shall only be changed by the invocation of the Initialize procedure)
25 26	bursting: Boolean; {In burstMode, the given station has acquired the medium and the burst timer has
26 27	not yet expired) humtStant: Declary (In humtMade, indicates that the first forme termonicsion is in measure)
27	burstStart: Boolean; {In burstMode, indicates that the first frame transmission is in progress}
28 29	extendError: Boolean; [Indicates a collision occurred while sending extension bits] if Stretch Mode: Boolean; [Indicates the desired mode of operation, and enables the lowering of the
29 30	ifsStretchMode: Boolean; {Indicates the desired mode of operation, and enables the lowering of the oueroge data rate of the MAC sublayer (with frame grapularity) using
30 31	average data rate of the MAC sublayer (with frame granularity), using extension of the minimum interFrameSpacing. ifsStretchMode is a static
31	
32 33	variable; its value shall only be changed by the invocation of the Initialize procedure }
	1
34	ifsStretchCount: 0ifsStretchRatio; {In bits, a running counter that counts the number of bits during a frame's transmission that are to be considered for the minimum
35	
36	interFrameSpacing extension, while operating in ifsStretchMode}
37	ifsStretchSize: 0(((maxUntaggedFrameSize + qTagPrefixSize) x 8 + headerSize + interFrameSpacing
38	+ ifsStretchRatio $- 1$) div ifsStretchRatio); (In sector, a supplier counter that counts the integer number of sectors that are to be
39 40	{In octets, a running counter that counts the integer number of octets that are to be added to the minimum interFrameSpacing, while operating in ifeStratehMode]
	added to the minimum interFrameSpacing, while operating in ifsStretchMode}
41	p2mpMode: Boolean; {Indicates the desired mode of operation, and disables waiting for the deferring
42	variable before transmitting}
43 44	99.2.7.3 Receive state variables
44 45	77.2.7.5 Receive state variables
45 46	The following items are specific to frame reception. (See also 99.4.)
47	var
48	incomingFrame: Frame; {The frame being received}
49	receiving: Boolean; {Indicates that a frame reception is in progress}
50	excessBits: 07; {Count of excess trailing bits beyond octet boundary}
51	receiveSucceeding: Boolean; {Running indicator of whether reception is succeeding}
52	validLength: Boolean; {Indicator of whether received frame has a length error}
53	exceedsMaxLength: Boolean; {Indicator of whether received frame has a length longer than the
54	exceeds waxbeingth, boolean, indicator of whether received frame has a length longer than the

	maximum permitted length}
	ReceiveFCSMode: Boolean; {Indicates whether the current frame is subject to carrier ex-
	de of operation, and enables passing of
extensionOK:	Boolean; {Indicates whether any bit errors were found in the extension part of a frame,
	which is not checked by the CRC}
passReceiveF	CSMode: Boolean; [Indicates the desired mode of operation, and enables passing of
	the frame check sequence field of all received frames from the
	MAC sublayer to the MAC client. passReceiveFCSMode is a
	static variable}
2.7.4 Summary	of interlayer interfaces
a) The interfac	te to the MAC client, defined in 4.3.299.3.2, is summarized below:
,	
type	
	<u>s = (transmitDisabled, transmitOK);</u>
TransmitStatu	<pre>s = (transmitDisabled, transmitOK, excessiveCollisionError, lateCollisionErrorStatus);</pre>
	{Result of TransmitFrame operation, reporting of lateCollisionErrorStatus is}
	optional for MACs operating at speeds at or below 100Mb/s}
ReceiveStatus	= (receiveDisabled, receiveOK, frameTooLong, frameCheckError, lengthError,
	alignmentError); {Result of ReceiveFrame operation}
	optional for MACs operating at speeds at or below 100Mb/s}
ReceiveStatus	= (receiveDisabled, receiveOK, frameTooLong, frameCheckError, lengthError,
	alignmentError); {Result of ReceiveFrame operation}
function Transmi	
	ram: AddressValue;
	AddressValue;
	Param: LengthOrTypeValue;
dataParam: D	
	e: CRCValue;
	ent: Bit): TransmitStatus; {Transmits one frame}
function Receive	
	nParam: AddressValue;
	am: AddressValue;
0	YpeParam: LengthOrTypeValue;
var dataParan	
	Value: CRCValue;
var tcsParam	Present: Bit): ReceiveStatus; {Receives one frame}
The interfer	to the Dhusical Louis defined in 1,2,200,2,2, is successful in the falls in the
b) The interfac	the to the Physical Layer, defined in $\frac{4.3.399.3.3}{99.3.3}$, is summarized in the following:
var raaaiyaDataW	slid: Poolean: (Indiantes incoming hits)
	alid: Boolean; {Indicates incoming bits} Boolean; {In half duplex mode, indicates that transmission should defer}
	Boolean; {Indicates outgoing bits}
-	t: Boolean; {Indicates outgoing ons }
	nitBit (bitParam: PhysicalBit); {Transmits one bit}
	Bit: PhysicalBit; {Receives one bit}
	bit Times: integer); {Waits for indicated number of bit times}
procedure wait (on rances. meger, { wans for mulcated number of on thinks}
2.7.5 State varia	ble initialization
_	
-	alize must be run when the MAC sublayer begins operation, before any of the processes
gin execution. In	tialize sets certain crucial shared state variables to their initial values. (All other global

variables are appropriately reinitialized before each use.) Initialize then waits for the medium to be idle, starts operation of the various processes.
NOTE Care should be taken to ensure that the time from the completion of the Initialize process to when the
packet transmission begins is at least an interFrameGap.
If Layer Management is implemented, the Initialize procedure shall only be called as the result of the initizeMAC action (30.3.1.2.1).
procedure Initialize;
begin
frameWaiting := false;
deferring := false;
frameWaiting: Boolean; {Indicates that outgoingFrame is deferring}
newCollision deferring := false;
transmitting := false; {An interface to Physical Layer; see below}
receiving := false;
halfDuplex-passReceiveFCSMode :=; {True for half duplex operation, false for full duplex operat
tion. For operation at when enabling the passing of the frame check sequence of all
bursting := false;
burstMode :=; { True for half duplex operation at an operating speed of 1000-
Mb/s, when multiple frames' transmission in a single carrier event received frames
from the MAC sublayer to the MAC client is desired and
supported, false otherwise] between invocations of the Initialize pre
ture}
extending := extend and halfDuplex; ifsStretchMode :=; {True for operating speeds above 1000 Mb/s when lowering the average data i
of the MAC sublayer (with frame granularity) is desired and supported, fal otherwise}
ifsStretchCount := 0;
ifsStretchSize := 0;
passReceiveFCSMode p2mpMode :=; {True when enabling the passing of the frame check seque
of all for Point-to-Multi-Point implementations, false otherwise}
received frames from the MAC sublayer to the MAC elient is desired
supported, false otherwise}
if halfDuplex then while carrierSense or receiveDataValid do nothing
else-while receiveDataValid do nothing
{Start execution of all processes}
end; {Initialize}
09.2.8 Frame transmission
The algorithms in this subclause define MAC sublayer frame transmission. The function TransmitFra mplements the frame transmission operation provided to the MAC client:
function TransmitFrame (
destinationParam: AddressValue;
sourceParam: AddressValue;
lengthOrTypeParam: LengthOrTypeValue;
dataParam: DataValue;
fcsParamValue: CRCValue;
fcsParamPresent: Bit): TransmitStatus;
<pre>procedure TransmitDataEncap; {Nested procedure; see body below}</pre>
hegin

begin

if transmitEnabled then	1
begin	2
TransmitDataEncap;	3
TransmitFrame := TransmitLinkMgmt	4
end	5
else TransmitFrame := transmitDisabled	6
and [TransmitErama]	7
<i>end</i> ; {TransmitFrame}	8
If transmission is analyad. TransmitErama calls the internal propadure TransmitDateErace to construct the	9
If transmission is enabled, TransmitFrame calls the internal procedure TransmitDataEncap to construct the	10
frame. Next, TransmitLinkMgmt is called to perform the actual transmission. The TransmitStatus returned	11
indicates the success or failure of the transmission attempt.	12
	12
TransmitDataEncap builds the frame and places the 32-bit CRC in the frame check sequence field:	13
	14
procedure TransmitDataEncap;	15
begin	10
with outgoingFrame do	
<i>begin</i> {Assemble frame}	18
view := fields;	19
destinationField := destinationParam;	20
sourceField := sourceParam;	21
lengthOrTypeField := lengthOrTypeParam;	22
if fcsParamPresent then	23
begin	24
dataField := dataParam; {No need to generate pad if the FCS is passed from MAC client}	25
fcsField := fcsParamValue {Use the FCS passed from MAC client}	26
end	27
else	28
begin	29
dataField := ComputePad(dataParam);	30
fcsField := CRC32(outgoingFrame)	31
end;	32
view := bits	33
end {Assemble frame}	34
with outgoingHeader do	35
begin	36
headerView := headerFields;	37
preamble :=; {* '101010,' LSB to MSB^* }	38
$sfd :=; {* '10101011, 'LSB to MSB*}$	39
headerView := headerBits	40
end	41
	42
end; {TransmitDataEncap}	43
	44
If the MAC client chooses to generate the frame check sequence field for the frame, it passes this field to the	4.5

If the MAC client chooses to generate the frame check sequence field for the frame, it passes this field to the MAC sublayer via the fcsParamValue parameter. If the fcsParamPresent parameter is true, TransmitDataEncap uses the fcsParamValue parameter as the frame check sequence field for the frame. Such a frame shall not require any padding, since it is the responsibility of the MAC client to ensure that the frame meets the minFrameSize constraint. If the fcsParamPresent parameter is false, the fcsParamValue parameter is unspecified-, TransmitDataEncap first calls the ComputePad function, followed by a call to the CRC32 function to

- generate the padding (if necessary) and the frame check sequence field for the frame internally to the MAC sublayer.
- 52 53 54

45

46

47

48

49

50

51

ComputeP frame size	ad appends an array of arbitrary bits to the MAC client data to pad the frame to the minimum
begin	
	putePad := {Append an array of size padSize of arbitrary bits to the MAC client dataField}
end; {C	omputePadParam}
	a ComputePad(var dataParam: DataValue): DataValue;
begin	
	putePad := {Append an array of size padSize of arbitrary bits to the MAC client dataField} omputePad}
FransmitL	inkMgmt attempts to transmit the frame. In half duplex mode, it first defers to any passing traffic.
n half du f	plex mode, if a collision occurs, transmission is terminated properly and retransmission is sched-
led follow	ving a suitable backoff interval:
function	7 TransmitLinkMgmt: TransmitStatus;
begin	
	npts := 0;
	mitSucceeding := false;
	CollisionCount := 0;
defe	rred := false; {Initialize}
<u>`ransmitL</u>	inkMgmt attempts to transmit the frame. It first defers to ensure proper interframe spacing:
exce	<pre>ssDefer := falsefunction TransmitLinkMgmt: TransmitStatus;</pre>
while	e (attempts < attemptLimit) and (not transmitSucceeding)
	and (not extend or lateCollisionCount = 0) do
	{No retransmission after late collision if operating at 1000 Mb/s}
b	egin {Loop}
	if bursting then {This is a burst continuation}
	<pre>frameWaiting := true {Start transmission without checking deference}</pre>
	else {Non bursting case, or first frame of a burst}
	begin
	if attempts_ <u>0 then BackOff;</u>
	frameWaiting := true;
	if not p2mpMode then while deferring do nothing {Defer to passing frame, if any ⁺ ensure
proper inte	rframe spacing}
	<i>if</i> halfDuplex <i>then</i> deferred := true;
	nothing;
+	if halfDuplex then deferred := true
	endStartTransmit;
	<pre>burstStart_frameWaiting := truefalse;</pre>
	if burstMode then bursting := true
	end; leteCollisionError := felse:
	lateCollisionError := false; StortTronomit:
	StartTransmit; frameWaiting := falco:
	frameWaiting := false; if halfDurnlay than
	if halfDuplex <i>then</i>
	begin while transmitting do WatchForCollision;
	white transmitting to watch of consion,
The Defere	nce process ensures that the reception of traffic does not cause deferring to be true when in full duplex mode. Deferring is
used in full d	uplex mode to enforce the minimum interpacket gap spacing.

used in full duplex mode to enforce the minimum interpacket gap spacing.

<pre>if lateCollisionError then lateCollisionCount := lateCollisionCount + 1;</pre>
attempts := attempts + 1
end {Half duplex mode}
else while transmitting do nothing {Full duplex mode}
end; {Loop}
LayerMgmtTransmitCounters; {Update transmit and transmit error counters in 5.2.4.2}
if transmitSucceeding then
begin
if burstMode <i>then</i> burstStart := false; {Can't be the first frame anymore}
TransmitLinkMgmt := transmitOK
end
<pre>else-TransmitLinkMgmt := excessiveCollisionErrortransmitOK</pre>
end; {TransmitLinkMgmt}

If the p2mpMode is enabled, then IPG is enforced outside this sublayer. If it is not enabled, then the IPG is timed using the Deference process.

Editors note: To be removed prior to final publication

This test for p2mpMode is option #1 to making the IPG optional for P2MP.

Each time a frame transmission attempt is initiated, StartTransmit is called to alert the BitTransmitter process that bit transmission should begin:

<i>procedure</i> StartTransmit;
begin
currentTransmitBit := 1;
lastTransmitBit := frameSize;
transmitSucceeding := true;
transmitting := true;
lastHeaderBit:= headerSize
end; [StartTransmit]
balf dupley mode. Transmitt ink Mant monitors the medium for contention by repeatedly calling

In half duplex mode, TransmitLinkMgmt monitors the medium for contention by repeatedly calling Watch-ForCollision, once frame transmission has been initiated:

	38
procedure WatchForCollision;	39
begin	40
if transmitSucceeding and collisionDetect then	41
begin	42
<pre>if currentTransmitBit > (slotTime headerSize) then lateCollisionError := true;</pre>	43
newCollision := true;	44
transmitSucceeding := false;	45
if burstMode then	46
begin	47
	48
— if not burstStart then	49
	50
end	51
end	52
end; {WatchForCollision}	53
	54

Amendment to IEEE Std 802.3-2002™ Ethernet in the First Mile

WatchForCollision, upon detecting a collision, updates newCollision to ensure proper jamming by the Bit-	1
Transmitter process. The current transmit bit number is checked to see if this is a late collision. If the colli-	2
sion occurs later than a collision window of slotTime bits into the packet, it is considered as evidence of a	3
late collision. The point at which the collision is received is determined by the network media propagation	4
time and the delay time through a station and, as such, is implementation-dependent (see 4.1.2.2). While	5
operating at speeds of 100 Mb/s or lower, an implementation may optionally elect to end retransmission	6
attempts after a late collision is detected. While operating at the speed of 1000 Mb/s, an implementation	7
shall end retransmission attempts after a late collision is detected.	8
shar end retransmission attempts after a fate consion is detected.	9
After transmission of the jam has been completed, if TransmitLinkMgmt determines that another attempt	10
should be made, BackOff is called to schedule the next attempt to retransmit the frame.	10
should be made, backon is called to seledule the next attempt to retraismit the mane.	11
function Random (low, high: integer): integer;	12
begin	13
Random := {Uniformly distributed random integer r, such that low $\leq r < high$ }	14
end; [Random]	16
ena, (Random)	10
BackOff performs the truncated binary exponential backoff computation and then waits for the selected mul-	18
	18
tiple of the slot time:	19 20
www.man.Deal-Off. 2, 1024. (Weaking surrichle of Deal-Off)	
var maxBackOff: 21024; (Working variable of BackOff)	21
<i>procedure</i> BackOff;	22
begin	23
$\frac{if \text{ attempts} = 1 \text{ then maxBackOff} := 2}{1 + 1 + 1 + 1 + 1 + 1 + 1 + 1 + 1 + 1 +$	24
<i>else if</i> attempts ≤ backOffLimit <i>then</i> maxBackOff := maxBackOff x 2;	25
Wait(slotTime x Random(0, maxBackOff))	26
end; {BackOff}	27
	28
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst-	28 29
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the	28 29 30
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst-	28 29 30 31
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting:	28 29 30 31 32
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer;	28 29 30 31 32 33
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; <i>begin</i>	28 29 30 31 32 33 34
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele	28 29 30 31 32 33 34 35
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; [wait for a burst]	28 29 30 31 32 33 34 35 36
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin cycle while not bursting do nothing; {wait for a burst} burstCounter := 0;	28 29 30 31 32 33 34 35 36 37
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; [wait for a burst]	28 29 30 31 32 33 34 35 36 37 38
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; [wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin	28 29 30 31 32 33 34 35 36 37 38 39
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin cycle while not bursting do nothing; [wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do	28 29 30 31 32 33 34 35 36 37 38 39 40
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; [wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin	28 29 30 31 32 33 34 35 36 37 38 39 40 41
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eycle while not bursting do nothing; {wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end;	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; [wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; {wait for a burst} burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; bursting := false end {burstMode eyele}	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eycle while not bursting do nothing; {wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; bursting := false	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; [wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; bursting := false end {burstMode cycle} end; {BurstTimer}	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; {wait for a burst} burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; bursting := false end {burstMode eyele}	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; [wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; bursting := false end {burstMode cycle} end; {BurstTimer}	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eycle while not bursting do nothing; {wait for a burst} burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; bursting := false end {burstMode cycle} end; {BurstTimer} process BurstTimer;	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eyele while not bursting do nothing; [wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; bursting := false end {burstMode cycle} end; {BurstTimer} process BurstTimer; begin	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst- Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integer; begin eycle while not bursting do nothing; [wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; burstMode cycle} end [burstMode cycle] end; [BurstTimer] process BurstTimer; begin eycle	28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the value false to bursting: var burstCounter: integor; begin eyele while not bursting do nothing; (wait for a burst] burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; burstCounter := burstCounter + 1 end; burstTimer] process BurstTimer; begin eyele while not bursting do nothing; (Wait for a burst] Wait(burstLimit);	$\begin{array}{c} 28\\ 29\\ 30\\ 31\\ 32\\ 33\\ 34\\ 35\\ 36\\ 37\\ 38\\ 39\\ 40\\ 41\\ 42\\ 43\\ 44\\ 45\\ 46\\ 47\\ 48\\ 49\\ 50\\ \end{array}$
BurstTimer is a process that does nothing unless the bursting variable is true. When bursting is true, Burst Timer increments burstCounter until the burstLimit limit is reached, whereupon BurstTimer assigns the var burstCounter: integer; begin eycle while not bursting do nothing; {wait for a burst} burstCounter := 0; while bursting and (burstCounter < burstLimit) do begin Wait(1); burstCounter := burstCounter + 1 end; burstGounter := burstCounter + 1 process BurstTimer} process BurstTimer; begin eycle while not bursting do nothing; {Wait for a burst]	$\begin{array}{c} 28\\ 29\\ 30\\ 31\\ 32\\ 33\\ 34\\ 35\\ 36\\ 37\\ 38\\ 39\\ 40\\ 41\\ 42\\ 43\\ 44\\ 45\\ 46\\ 47\\ 48\\ 49\\ 50\\ 51\\ \end{array}$

Amendment to IEEE Std 802.3-2002™ Ethernet in the First Mile

The Deference process runs asynchronously to continuously compute the proper value for the variable defer-	1
ring. In the case of half duplex burst mode, deferring remains true throughout the entire burst. Interframe	2
spacing may be used to lower the average data rate of a MAC at operating speeds above 1000 Mb/s in the	3
full duplex mode, when it is necessary to adapt it to the data rate of a WAN-based physical layer. When	4
interframe stretching is enabled, deferring remains true throughout the entire extended interframe gap,	5
which includes the sum of interFrameSpacing and the interframe extension as determined by the BitTrans-	6
mitter:	7
	8
process Deference <u>procedure StartTransmit;</u>	9
var realTimeCounter: integer; wasTransmitting: Boolean;	10
begin	11
if halfDuplex then cycle [Half duplex loop]	12
while not carrierSense do nothing; (Watch for carrier to appear)	13
deferring := true; {Delay start of new transmissions}	14
wasTransmitting_:=_transmitting;	15
while carrierSense or transmitting do_wasTransmitting := wasTransmitting or transmitting;	16
if wasTransmitting then Wait(interFrameSpacingPart1) {Time out first part of interframe gap}	17
else	18
begin	19
StartRealTimeDelaycurrentTransmitBit := 1;	20
repeat	21
while carrierSense do StartRealTimeDelay	22
until not RealTimeDelay(interFrameSpacingPart1)	23
<pre>realTimeCounter := interFrameSpacingPart1;</pre>	24
repeat	25
while carrierSense do realTimeCounter lastTransmitBit :=	26
interFrameSpacingPart1frameSize;	27
Wait(1)transmitting := true;	28
realTimeCounter_lastHeaderBit:= realTimeCounter - 1headerSize	29
<i>until</i> (realTimeCounter = 0)	30
<u>end; {StartTransmit}</u>	31
	32
The Deference process runs asynchronously to continuously compute the proper value for the variable defer-	33
ring. Interframe spacing may be used to lower the average data rate of a MAC at operating speeds above	34
1000 Mb/s in the full duplex mode, when it is necessary to adapt it to the data rate of a WAN-based physical	35
layer. When interframe stretching is enabled, deferring remains true throughout the entire extended inter-	36
frame gap, which includes the sum of interFrameSpacing and the interframe extension as determined by the	37
BitTransmitter:	38
	39
endprocess Deference;	40
Wait(interFrameSpacingPart2); {Time out second part of interframe gap}	41
deferring := false; Allow new transmissions to proceed}	42
while frameWaiting do nothing {Allow waiting transmission, if any}	43
end {Half duplex loop}	44
<u>begin</u>	45
else cycle {Full duplex Main loop}	46
while not transmitting do nothing; {Wait for the start of a transmission}	47
deferring := true; {Inhibit future transmissions}	48
while transmitting <i>do</i> nothing; {Wait for the end of the current transmission}	49
Wait(interFrameSpacing + ifsStretchSize x 8); {Time out entire interframe gap and IFS extension}	50
if not frameWaiting then {Don't roll over the remainder into the next frame}	51
begin	52
Wait(8);	53
ifsStretchCount := 0	54

1 end 2 deferring := false {Don't inhibit transmission} end {Full duplex Main loop} 3 *end*; {Deference} 4 5 If the ifsStretchMode is enabled, the Deference process continues to enforce interframe spacing for an addi-6 7 tional number of bit times, after the completion of timing the interFrameSpacing. The additional number of 8 bit times is reflected by the variable ifsStretchSize. If the variable ifsStretchCount is less than ifsStretchRatio and the next frame is ready for transmission (variable frameWaiting is true), the Deference process 9 enforces interframe spacing only for the integer number of octets, as indicated by ifsStretchSize, and saves 10 ifsStretchCount for the next frame's transmission. If the next frame is not ready for transmission (variable 11 frameWaiting is false), then the Deference process initializes the ifsStretchCount variable to zero. 12 13 begin 14 15 {reset the realtime timer and start it timing} end; [StartRealTimeDelay] 16 17 function RealTimeDelay (usec:real): Boolean; 18 19 begin freturn the value true if the specified number of microseconds have 20 not elapsed since the most recent invocation of StartRealTimeDelay, 21 otherwise return the value false 22 end; {RealTimeDelay} 23 24 The BitTransmitter process runs asynchronously, transmitting bits at a rate determined by the Physical 25 Layer's TransmitBit operation: 26 27 28 process BitTransmitter; begin 29 30 cycle {Outer loop} begin [Inner loop] if transmitting then 31 extendError := false;begin {Inner loop} 32 if ifsStretchMode then {Calculate the counter values} 33 begin 34 ifsStretchSize := (ifsStretchCount + headerSize + frameSize + interFrameSpacing) div 35 ifsStretchRatio; {Extension of the interframe spacing} 36 ifsStretchCount := (ifsStretchCount + headerSize + frameSize + interFrameSpacing) 37 *mod* ifsStretchRatio {Remainder to carry over into the next frame's transmission} 38 39 end PhysicalSignalEncap; {Send preamble and start of frame delimiter}*end*; 40 *while* transmitting *do* 41 42 begin 43 *if* (currentTransmitBit > lastTransmitBit) *then*-TransmitBit(extensionBitoutgoing-Frame[currentTransmitBit]); 44 else if extendError then TransmitBit(extensionErrorBit) {Jam in extension}current-45 TransmitBit := currentTransmitBit + 1; 46 TransmitBittransmitting := (extensionErrorBit) {jam in extension}currentTrans-47 mitBit \leq lastTransmitBit) 48 *else* TransmitBit(outgoingFrame[currentTransmitBit])*end*; 49 *if* newCollision *then* StartJam *else* NextBitend {Inner loop} 50 *end* {Outer loop} 51 52 end; {BitTransmitter}

99.2.9 Frame reception		
The algorithms in this subclause define the MAC sublayer frame reception.		
The function ReceiveFrame implements the frame reception operation provided to the MAC client:		
function ReceiveFrame (
endvar destinationParam: AddressValue;		
if bursting <i>then</i>		
beginvar sourceParam: AddressValue;		
InterFrameSignalyar lengthOrTypeParam: LengthOrTypeValue;		
if extendError <i>then</i>		
<i>if transmitting then transmitting :=</i>		
called during InterFrameSignal}		
{TransmitFrame may have been called during InterFrameSignal}		
else IncLargeCounter(lateCollision);		
(Count late collisions which were missed by TransmitLinkMgmt)		
bursting := bursting and (frameWaiting or transmitting)		
endyar dataParam: DataValue;		
end [Inner loop]		
end {Outer loop}		
end; {BitTransmitter}		
The bits transmitted to the physical layer can take one of four values: data zero (0), data one (1), extension- Bit (EXTEND), or extensionErrorBit (EXTEND_ERROR). The values extensionBit and extensionErrorBit are not transmitted between the first preamble bit of a frame and the last data bit of a frame under any cir- cumstances. The BitTransmitter calls the procedure TransmitBit with bitParam = extensionBit only when it is necessary to perform carrier extension on a frame after all of the data bits of a frame have been transmit- ted. The BitTransmitter calls the procedure TransmitBit with bitParam = extensionErrorBit only when it is necessary to jam during carrier extension.		
procedure PhysicalSignalEncap;		
var fcsParamPresent: Bit): ReceiveStatus;		
function ReceiveDataDecap: ReceiveStatus; {Nested function; see body below}		
begin		
while currentTransmitBit ≤ lastHeaderBit doif receiveEnabled then		
beginrepeat		
TransmitBit(outgoingHeader[currentTransmitBit]); [Transmit header one bit at a time]		
ReceiveLinkMgmt;		
currentTransmitBit ReceiveFrame := currentTransmitBit + 1<u>ReceiveDataDecap</u>;		
end;until receiveSucceeding		
if newCollision then StartJam else currentTransmitBit ReceiveFrame := 4receiveDisabled		
end; {PhysicalSignalEncapReceiveFrame}		
The procedure InterFrameSignal fills the interframe interval between the frames of a burst with extension-		
Bits. InterFrameSignal also monitors the variable collisionDetect during the interframe interval between the		
frames of a burst, and will end a burst if a collision occurs during the interframe interval. The procedural		
model is defined such that a MAC operating in the burstMode will emit an extraneous sequence of		
interFrameSize extensionBits in the event that there are no additional frames ready for transmission after		
InterFrameSignal returns. Implementations may be able to avoid sending this extraneous sequence of exten-		
sionBits if they have access to information (such as the occupancy of a transmit queue) that is not assumed		
to be available to the procedural model.		
to be available to the procedular model.		
procedure InterFrameSignal;		
proceaure mich fameoignai,		

it it should do so. The returned Recei	veStatus indicates the presence or absence of detected transmission
ors in the frame.	
	Cotalfunction ReceiveDataDecap: integerReceiveStatus;
var status: ReceiveStatus; {Holds	receive status information}
<u>begin</u>	
with incomingFrame do	
begin	
$\frac{\text{interFrameCount-view}}{\text{view}} := 0 \underline{f}$	
	MgmtRecognizeAddress(destinationField);
interFrameTotal := interFrameSpa	
<i>while</i> interFrameCount < inte	ne l'otal <i>do</i>
begin Lesin (Dissessmills form	-)
begin {Disassemble fram	
<u>destinationParam := d</u>	smitBit(extensionBit)sourceParam := sourceField;
	sintBit(extensionBit)<u>sourceraram</u> := sourcerieid, i rrorBit) lengthOrTypeParam := lengthOrTypeField;
	Pad(lengthOrTypeField, dataField);
	<i>a</i> lue := interFrameCount + 1 fcsField;
	tendError then fcsParamPresent := passReceiveFCSMode:
begin	tendention mentesi arann resent passiceerver estitode,
	; {Check to determine if receive frame size exceeds the maximum
	permitted frame size. MAC implementations may use either
	maxUntaggedFrameSize or (maxUntaggedFrameSize +
	gTagPrefixSize) for the maximum permitted frame size,
	either as a constant or as a function of whether the frame being
	received is a basic or tagged frame (see 3.2, 3.5). In
	implementations that treat this as a constant, it is recommended
	that the larger value be used. The use of the smaller value
	in this case may result in valid tagged frames exceeding the
	maximum permitted frame size.}
	ength then status := false; frameTooLong
	32(incomingFrame) then
· · · · · ·	nen status := receiveOK else status := lengthError
	hen status := frameCheckError
	<u>s</u> := true alignmentError;
	<pre>punters(status); {Update receive counters in 5.2.4.3}</pre>
interFrameCount_view :=	
	ze end {Disassemble frame}
<u>t</u> end: {With incomingFrame}	
	DataDecap := jamSizestatus
end	
end; { InterFrameSignalReceiveDataI	Jecap}
procedure Novt Dit.	
procedure NextBit;	
<i>begin</i> currentTransmitBit := currentTran	emitRit 1.
	ansmitSucceeding then {Carrier extension may be required}
	tBit ≤ max(lastTransmitBit, slotTime))
else transmitting := (current Transmitting :=	
end; (NextBit)	$\operatorname{Int} \mathcal{D} \mathfrak{n} \cong \operatorname{IastIIansmitD} \mathfrak{n} \mathfrak{n}$

<u>begin</u> <u>RecognizeAddress :=; {Returns true for the set of physical, broadcast,</u>	
and multicast-group addresses corresponding	
to this station}	
end: {RecognizeAddress}	
<i>procedure</i> StartJam;	
begin	
extendError := currentTransmitBit > lastTransmitBit;	
eurrentTransmitBit := 1;	
lastTransmitBit := jamSize;	
newCollision := false	
end; {StartJam}	
Transmitter, upon detecting a new collision, immediately enforces it by calling StartJam to initiat	e the
nsmission of the jam. The jam should contain a sufficient number of bits of arbitrary data so that	it is
sured that both communicating stations detect the collision. (StartJam uses the first set of bits of the f	
to jamSize, merely to simplify this program.)	
2.10 Frame reception	
e algorithms in this subclause define CSMA/CD Media Access sublayer frame reception.	
e function ReceiveFrame implements the frame reception operation provided to the MAC client:	
function ReceiveFrame_LayerMgmtRecognizeAddress(address: AddressValue): Boolean;	
<u>begin</u>	
<i>if</i> {promiscuous receive enabled} <i>then</i> LayerMgmtRecognizeAddress := true;	
<i>if</i> address = {MAC station address} <i>then</i> LayerMgmtRecognizeAddress := true;	
<i>if</i> address = {Broadcast address} <i>then</i> LayerMgmtRecognizeAddress := true;	
<i>if</i> address = {One of the addresses on the multicast list and multicast reception is enabled} <i>then</i>	
LayerMgmtRecognizeAddress := tru	<u>e;</u>
<i>var</i> destinationParam: AddressValue;LayerMgmtRecognizeAddress := false	
<i>var</i> sourceParam: AddressValue;	
<u>end; {LayerMgmtRecognizeAddress}</u>	
e function RemovePad strips any padding that was generated to meet the minFrameSize constraint, if	pos-
le. When the MAC sublayer operates in the mode that enables passing of the frame check sequence	field
all received frames to the MAC client (passReceiveFCSMode variable is true), it shall not strip the	pad-
ng and it shall leave the data field of the frame intact. Length checking is provided for Length interp	oreta
ns of the Length/Type field. For Length/Type field values in the range between maxValidFrame	and
nTypeValue, the behavior of the RemovePad function is unspecified:	
function RemovePad(var lengthOrTypeParam: LengthOrTypeValue; dataParam: DataValue): 1	Data
lue;	
var fesParamValue: CRCValue;	
var fesParamPresent: Bit): ReceiveStatus;	
function ReceiveDataDecap: ReceiveStatus; [Nested function; see body below]	
begin	
if receiveEnabled_lengthOrTypeParam ≥ minTypeValue then	
repeat begin	
validLength := true; {Don't perform length checking for Type field interpretations}	
ReceiveLinkMgmt;RemovePad := dataParam	
ReceiveFrame := ReceiveDataDecap; end	

until r	ecciveSucceedingbegin
	idLength := {For length interpretations of the Length/Type field, check to determine if value
	represented by Length/Type field matches the received clientDataSize}:
<u>if v</u>	alidLength and not passReceiveFCSMode then
	RemovePad := {Truncate the dataParam (when present) to the value represented by the
	lengthOrTypeParam (in octets) and return the result}
else	e RemovePad := dataParam
else Rece	iveFrame := receiveDisabledend
end; {Receiv	veFrameRemovePad}
	eiveFrame calls ReceiveLinkMgmt to receive the next valid frame, and then calls the internal
	veDataDecap to return the frame's fields to the MAC client if the frame's address indicates
	o so. The returned ReceiveStatus indicates the presence or absence of detected transmission
errors in the fra	me.
	gmt attempts repeatedly to receive the bits of a frame, discarding any fragments smaller than
the minimum v	alid frame size:
	ceiveDataDecap: ReceiveStatusprocedure ReceiveLinkMgmt;
· ·	a: ReceiveStatus; {Holds receive status information}
begin	
•	mingFrame do <u>repeat</u>
	StartReceive:
	receiving do nothing; {Wait for frame to finish arriving}
•	wexcessBits := fieldsframeSize mod 8;
	Size := frameSize - excessBits; {Truncate to octet boundary}
	eSucceeding := LayerMgmtRecognizeAddressreceiveSucceeding and (destinationField-
<u>frameSize ≥ mi</u>	
if r	{Reject frames too small}
	begin end; {Disassemble frameReceiveLinkMgmt}
	begur end. (Bisassemble framerecenterinkivigine)
<u>procedure S</u>	tartReceive:
<u>begin</u>	
	icceeding := true;
receiving	· · · · · · · · · · · · · · · · · · ·
end; {StartR	
The BitReceive	er process runs asynchronously, receiving bits from the medium at the rate determined by the
	's ReceiveBit operation, partitioning them into frames, and optionally receiving them:
process BitF	Receiver:
· · · · · · · · · · · · · · · · · · ·	PhysicalBit;
	omingFrameSize: integer; {Count of all bits received in frame including extension}
	destinationParam := destinationFieldframeFinished: Boolean;
	<pre>sourceParam := sourceFieldenableBitReceiver: Boolean;</pre>
cur	rentReceiveBit: 1frameSize; {Position of current bit in incomingFrame}
<u>begin</u>	
<u>cycle {O</u>	<u>iter loop}</u>
	<pre>lengthOrTypeParam := lengthOrTypeField;if receiveEnabled then</pre>
<u>beg</u>	tin {Receive next frame from physical layer}
	<pre>dataParam currentReceiveBit := RemovePad(lengthOrTypeField, dataField)1;</pre>
	fesParamValue_incomingFrameSize := fesField0;
	<pre>fcsParamPresent frameFinished := passReceiveFCSModefalse;</pre>

LayerMgmtRecognizeAddress := false 1 end; {LayerMgmtRecognizeAddress} 2 3 The function RemovePad strips any padding that was generated to meet the minFrameSize constraint, if pos-4 5 sible. When the MAC sublayer operates in the mode that enables passing of the frame check sequence field of all received frames to the MAC elient (passReceiveFCSMode variable is true), it shall not strip the pad-6 ding and it shall leave the data field of the frame intact. Length checking is provided for Length interpreta-7 8 tions of the Length/Type field. For Length/Type field values in the range between maxValidFrame and minTypeValue, the behavior of the RemovePad function is unspecified: 9 10 function RemovePad(var lengthOrTypeParam: LengthOrTypeValue; dataParam: DataValue): DataValue; 11 begin 12 if lengthOrTypeParam ≥ minTypeValue then 13 14 begin validLength := true; {Don't perform length checking for Type field interpretations} 15 RemovePad := dataParam 16 17 and else if lengthOrTypeParam ≤ maxValidFrame then 18 19 begin validLength := {For length interpretations of the Length/Type field, check to determine if value 20 represented by Length/Type field matches the received clientDataSize}; 21 if validLength and not passReceiveFCSMode then 22 RemovePad := {Truncate the dataParam (when present) to the value represented by the 23 lengthOrTypeParam (in octets) and return the result] 24 else RemovePad := dataParam 25 26 end end; {RemovePad} 27 28 ReceiveLinkMgmt attempts repeatedly to receive the bits of a frame, disearding any fragments from colli-29 30 sions by comparing them to the minimum valid frame size: 31 procedure ReceiveLinkMgmt; 32 begin 33 repeat 34 StartReceive: 35 while receiving do nothing; {Wait for frame to finish arriving} 36 excessBits := frameSize mod 8; 37 frameSize := frameSize - excessBits; {Truncate to octet boundary} 38 receiveSucceeding := receiveSucceeding and (frameSize ≥ minFrameSize)-39 {Reject collision fragments} 40 until receiveSucceeding 41 end; {ReceiveLinkMgmt} 42 43 procedure StartReceive; 44 45 begin receiveSucceeding := true; 46 receiving := true 47 48 end; {StartReceive} 49 50 The BitReceiver process runs asynchronously, receiving bits from the medium at the rate determined by the Physical Layer's ReceiveBit operation, partitioning them into frames, and optionally receiving them: 51 52 process BitReceiver; 53 *var* b: PhysicalBit; 54

incomingFrameSize: integer; {Count of all bits received in frame including externation	ension 1
frameFinished: Boolean;	2
enableBitReceiver: Boolean:	3
currentReceiveBit: 1frameSize; {Position of current bit in incomingFrame}	4
begin	5
cycle {Outer loop}	6
if receiveEnabled then	7
begin {Receive next frame from physical layer}	8
currentReceiveBit := 1:	9
incomingFrameSize := 0;	10
frameFinished := false;	10
enableBitReceiver := receiving;	12
PhysicalSignalDecap; {Skip idle and extension, strip off preamble and sfd}	12
if enableBitReceiver <i>then</i> extensionOK := true;	13
while receiveDataValid and not frameFinished do	14
<i>begin</i> {Inner loop to receive the rest of an incoming frame}	15
b:= ReceiveBit; {Next bit from physical medium}	10
incomingFrameSize := incomingFrameSize + 1;	18
$\frac{if b = 0 \text{ or } b = 1 \text{ then } \{\text{Normal case}\}$	10
if enableBitReceiver then {Append to frame}	20
begin	20 21
if incomingFrameSize > currentReceiveBit then extensionOK :=	
incomingFrame[currentReceiveBit] := b;	24
currentReceiveBit := currentReceiveBit + 1	25
end	25 26
else if not extending then frameFinished := true; {b must be an extensi	
if incomingFrameSize ≥ slotTime then extending := false	28
end; {i <u>Inner loop}</u>	20
if enableBitReceiver then	30
begin	31
frameSize := currentReceiveBit – 1;	32
receiveSucceeding := <i>not</i> extending;	33
receiving := false	34
end	35
end {Enabled}	36
end [Outer loop]	37
end; {BitReceiver}	38
	39
The bits received from the physical layer can take one of three values: data zero (0), data of	one (1), or exten- 40
sionBit (EXTEND). The value extensionBit will not occur between the first preamble bit of	
last data bit of a frame in normal circumstances. Extension bits are counted by the BitRee	
appended to the incoming frame. The BitReceiver checks whether the bit received from the	
a data bit or an extensionBit before appending it to the incoming frame. Thus, the array of t	
Frame will only contain data bits. The underlying Reconciliation Sublayer (RS)	
EXTEND_ERROR bits to normal data bits. Thus, the reception of additional data bits after	
sion has started is an indication that the frame should be discarded.	47
	48
procedure PhysicalSignalDecap;	49
begin	50
Receive one bit at a time from physical medium until a valid sfd is detected, diseard	bits and return.] 51
end; {PhysicalSignalDecap}	52
	53
	54

The process SetExtending controls the extending variable, which determines whether a received frame must	1
be at least slotTime bits in length or merely minFrameSize bits in length to be considered valid by the BitRe-	2
eciver. SetExtending sets the extending variable to true whenever receiveDataValid is de-asserted, while in	3
half duplex mode at an operating speed of 1000 Mb/s:	4
han duplex mode at an operating speed of 1000 100/s.	4 5
nuo sea SatEritan dinanassa duna Dhusiaa (Siana) Dasani	5
process SetExtendingprocedure PhysicalSignalDecap;	
begin la	7
eyele {Loop forever}	8
while receiveDataValid do nothing;	9
extending := extend Receive one bit at a time from physical medium until a valid sfd is detected,	10
discard bits and halfDuplex	11
end {Loopreturn.}	12
end; {SetExtendingPhysicalSignalDecap}	13
	14
99.2.11 Common procedures	15
	16
The function CRC32 is used by both the transmit and receive algorithms to generate a 32-bit CRC value:	17
	18
function CRC32(f: Frame): CRCValue;	19
begin	20
CRC32 := {The 32-bit CRC for the entire frame, excluding the FCS field (if present)}	21
<i>end</i> ; {CRC32}	22
	23
Purely to enhance readability, the following procedure is also defined:	24
	25
procedure nothing; begin end;	26
	27
The idle state of a process (that is, while waiting for some event) is cast as repeated calls on this procedure.	28
	29
00.2 Interfaces to from a discont layons	30
99.3 Interfaces to/from adjacent layers	31
00.2.1. Отголизати	32
99.3.1 Overview	33
	34
The purpose of this clause is to provide precise definitions of the interfaces between the architectural layers	35
defined in Clause 1 in compliance with the Media Access Service Specification given in Clause 2. In addi-	36
tion, the services required from the physical medium are defined.	37
	38
The notation used here is the Pascal language, in keeping with the procedural nature of the precise MAC	39
sublayer specification (see 99.2). Each interface is described as a set of procedures or shared variables, or	40
both, that collectively provide the only valid interactions between layers. The accompanying text describes	40 41
the meaning of each procedure or variable and points out any implicit interactions among them.	
	42
Note that the description of the interfaces in Pascal is a notational technique, and in no way implies that they	43
can or should be implemented in software. This point is discussed more fully in 99.2, that provides complete	44
Pascal declarations for the data types used in the remainder of this clause. Note also that the synchronous	45
(one frame at a time) nature of the frame transmission and reception operations is a property of the architec-	46
tural interface between the MAC client and MAC sublayers, and need not be reflected in the implementation	47
	48
interface between a station and its sublayer.	49
	50
	51
	52
	53
	54
	54

99.3.2 Services provided by the MAC sublayer

The services provided to the MAC client by the MAC sublayer are transmission and reception of frames. The interface through which the MAC client uses the facilities of the MAC sublayer therefore consists of a pair of functions.

- Functions:
 - TransmitFrame
 - ReceiveFrame

Each of these functions has the components of a frame as its parameters (input or output), and returns a status code as its result.

NOTE 1—The frame_check_sequence parameter defined in 2.3.1 and 2.3.2 is mapped here into two variables: fcsParamValue and fcsParamPresent. This mapping has been defined for editorial convenience. The fcsParamPresent variable indicates the presence or absence of the fcsParamValue variable in the two function calls. If the fcsParamPresent variable is true, the fcsParamValue variable contains the frame check sequence for the corresponding frame. If the fcsParamPresent variable is false, the fcsParamValue variable is unspecified. If the MAC sublayer does not support client-supplied frame check sequence values, then the fcsParamPresent variable in TransmitFrame shall always be false.

NOTE 2—The mac_service_data_unit parameter defined in 2.3.1 and 2.3.2 is mapped here into two variables: lengthOr-TypeParam and dataParam. This mapping has been defined for editorial convenience. The first two octets of the mac_service_data_unit parameter contain the lengthOrTypeParam variable. The remaining octets of the mac_service_data_unit parameter form the dataParam variable.

The MAC client transmits a frame by invoking TransmitFrame:

function TransmitFrame (destinationParam: AddressValue; sourceParam: AddressValue; lengthOrTypeParam: LengthOrTypeValue; dataParam: DataValue; fcsParamValue: CRCValue; fcsParamPresent: Bit): TransmitStatus;

The TransmitFrame operation is synchronous. Its duration is the entire attempt to transmit the frame; when the operation completes, transmission has either succeeded or failed, as indicated by the resulting status code:

type TransmitStatus = (transmitOK, excessiveCollisionError, lateCollisionErrorStatus);
type TransmitStatus = (transmitDisabled, transmitOK, excessiveCollisionError,);
lateCollisionErrorStatus);
The transmitDisabled status code indicates that the transmitter is not enabled. Successful transmission is

indicated by the status code indicates that the transmitter is not enabled. Successful transmission is indicated by the status code transmitOK... The code excessiveCollisionError indicates that the transmission attempt was aborted due to excessive collisions, because of heavy traffic or a network failure. MACs operating in the half duplex mode at the speed of 1000 Mb/s are required to report lateCollisionErrorStatus in response to a late collision; MACs operating in the half duplex mode at speeds of 100 Mb/s and below are not required to do so. TransmitStatus is not used by the service interface defined in 2.3.1. TransmitStatus may be used in an implementation dependent manner.

The MAC client accepts incoming frames by invoking ReceiveFrame:

function ReceiveFrame (

var destinationParam: AddressValue;
var sourceParam: AddressValue;
var lengthOrTypeParam: LengthOrTypeValue;
var dataParam: DataValue;
var fcsParamValue: CRCValue;
var fcsParamPresent: Bit): ReceiveStatus;

The ReceiveFrame operation is synchronous. The operation does not complete until a frame has been received. The fields of the frame are delivered via the output parameters with a status code:

type ReceiveStatus = (<u>receiveDisabled</u>, receiveOK, <u>lengthErrorframeTooLong</u>, frameCheckError, alignmentError);

type ReceiveStatus = (receiveDisabled, receiveOK, frameTooLong, frameCheckError, lengthError, alignmentError);

The receiveDisabled status indicates that the receiver is not enabled. Successful reception is indicated by the status code receiveOK. The frameTooLong error indicates that a frame was received whose frameSize was beyond the maximum allowable frame size. The code frameCheckError indicates that the frame received was damaged by a transmission error. The lengthError indicates that the lengthOrTypeParam value was both consistent with a length interpretation of this field (i.e., its value was less than or equal to maxValidFrame), and inconsistent with the frameSize of the received frame. The code alignmentError indicates that the frame received was damaged, and that in addition, its length was not an integer number of octets. ReceiveStatus is not mapped to any MAC client parameter by the service interface defined in 2.3.2. ReceiveStatus may be used in an implementation dependent manner.

Note that maxValidFrame represents the maximum number of octets that can be carried in the MAC client data field of a frame and is a constant, regardless of whether the frame is a basic or tagged frame (see 3.2 and 3.5). The maximum length of a frame (including all fields from the Destination address through the FCS, inclusive) is either maxUntaggedFrameSize (for basic frames) or maxUntaggedFrameSize + qTagPrefix-Size, for tagged frames.

99.3.3 Services required from the physical layer

The interface through which the CSMA/CD-MAC sublayer uses the facilities of the Physical Layer consists of a function, a pair of procedures and four two Boolean variables:

Function	Procedures	Variables
ReceiveBit	TransmitBit	collisionDetect
	Wait	carrierSense
		receiveDataValid
		transmitting

Function	Procedures	Variables	
ReceiveBit	TransmitBit	receiveDataValid	
	Wait	transmitting	

During transmission, the contents of an outgoing frame are passed from the MAC sublayer to the Physical 1 2 Layer by way of repeated use of the TransmitBit operation: 3 procedure TransmitBit (bitParam: PhysicalBit); 4 5 6 Each invocation of TransmitBit passes one new bit of the outgoing frame to the Physical Layer. The 7 TransmitBit operation is synchronous. The duration of the operation is the entire transmission of the bit. The 8 operation completes, completes when the Physical Layer is ready to accept the next bit and it transfers control to the MAC sublayer. 9 10 The overall event of data being transmitted is signaled to the Physical Layer by way of the variable 11 transmitting: 12 13 var transmitting: Boolean; 14 15 Before sending the first bit of a frame, the MAC sublayer sets transmitting to true, to inform the Physical 16 Media Access-physical layer that a stream of bits will be presented via the TransmitBit operation. After the 17 last bit of the frame has been presented, the MAC sublayer sets transmitting to false to indicate the end of the 18 19 frame. 20 21 The presence of a collision in the physical medium is signaled to the MAC sublayer by the variable 22 collisionDetect: 23 var collisionDetect: Boolean; 24 25 The collisionDetect signal remains true during the duration of the collision. 26 27 NOTE In full duplex mode, collision indications may still be generated by the Physical Layer; however, they are 28 ignored by the full duplex MAC. 29 30 The collisionDetect signal is generated only during transmission and is never true at any other time; in 31 particular, it cannot be used during frame reception to detect collisions between overlapping transmissions 32 from two or more other stations. 33 34 During reception, the contents of an incoming frame are retrieved from the Physical Layer by the MAC 35 sublayer via repeated use of the ReceiveBit operation: 36 function ReceiveBit: PhysicalBit; 37 38 Each invocation of ReceiveBit retrieves one new bit of the incoming frame from the Physical Layer. The 39 ReceiveBit operation is synchronous. Its duration is the entire reception of a single bit. Upon receiving a bit, 40 the MAC sublayer shall immediately request the next bit until all bits of the frame have been received. (See 41 99.2 for details.) 42 43 The overall event of data being received is signaled to the MAC sublayer by the variable receiveDataValid: 44 45 var receiveDataValid: Boolean: 46 47 When the Physical Layer sets receiveDataValid to true, the MAC sublayer shall immediately begin retriev-48 ing the incoming bits by the ReceiveBit operation. When receiveDataValid subsequently becomes false, the 49 MAC sublayer can begin processing the received bits as a completed frame. If an invocation of ReceiveBit 50 is pending when receiveDataValid becomes false, ReceiveBit returns an undefined value, which should be 51 discarded by the MAC sublayer. (See 99.2 for details.) 52 NOTE When a burst of frames is received in half duplex mode at an operating speed of 1000 Mb/s, the variable 53 receiveDataValid will remain true throughout the burst. Furthermore, the variable receiveDataValid remains true 54

throughout the extension field. In these respects, the behavior of the variable receiveDataValid is different from the 1 underlying GMII signal RX_DV, from which it may be derived. See 35.2.1.7. 2 3 The overall event of activity on the physical medium is signaled to the MAC sublayer by the variable 4 carrierSense: 5 6 var carrierSense: Boolean; 7 8 In half duplex mode, the MAC sublayer shall monitor the value of carrierSense to defer its own transmis-9 sions when the medium is busy. The Physical Layer sets carrierSense to true immediately upon detection of 10 activity on the physical medium. After the activity on the physical medium ceases, carrierSense is set to 11 false. Note that the true/false transitions of carrierSense are not defined to be precisely synchronized with 12 the beginning and the end of the frame, but may precede the beginning and lag the end, respectively. (See 13 99.2 for details.) In full duplex mode, carrierSense is undefined. 14 15 The Physical Layer also provides the procedure Wait: 16 17 procedure Wait (bitTimes: integer); 18 19 This procedure waits for the specified number of bit times. This allows the MAC sublayer to measure time 20 intervals in units of the (physical-medium-dependent) bit time. 21 22 Another important property of the Physical Layer, which is an implicit part of the interface presented to the 23 MAC sublayer, is the round-trip propagation time of the physical medium. Its value represents the maximum 24 time required for a signal to propagate from one end of the network to the other, and for a collision to propa-25 gate back. The round-trip propagation time is primarily (but not entirely) a function of the physical size of 26 the network. The round-trip propagation time of the Physical Layer is defined in 99.4 for a selection of phys-27 ical media. 28 29 30 **99.4 Specific implementations** 31 32 99.4.1 Compatibility overview 33 34 To provide total compatibility at all levels of the standard, it is required that each network component imple-35 menting the CSMA/CD-MAC sublayer procedure adheres rigidly to these specifications. The information 36 provided in 99.4.2 provides design parameters for specific implementations of this access method. Varia-37 tions from these values result in a system implementation that violates the standard. 38 39 A DTE shall be capable of operating in half duplex mode, full duplex mode, or both. In any given instantia-40 tion of a network conforming to this standard, all stations shall be configured to use the same mode of 41 operation, either half duplex or full duplex. 42 43 All DTEs connected to a repeater or a mixing segment shall be configured to use the half duplex mode of 44 operation. When a pair of DTEs are connected to each other with a link segment, both devices shall be con-45 figured to use the same mode of operation, either half duplex or full duplex. 46 47 99.4.2 Allowable implementations 48 49 The following parameter values shall be used for their corresponding implementations: 50 51 52 53 54

	Values			
Parameters	10 Mb/s 1BASE-5 1 Gb/s 100 Mb/s		10 Gb/s	
slotTime	512 bit times	4096 bit times	not applicable	
interFrameGap	96 bits	96 bits	96 bits	
attemptLimit	16	16	not applicable	
backoffLimit	10	10	not applicable	
jamSize	32 bits	32 bits	not applicable	
maxUntaggedFrameSize	1518 octets	1518 octets	1518 octets	
minFrameSize	512 bits (64 octets)	512 bits (64 octets)	512 bits (64 octets)	
burstLimit	not applicable	65 536 bits	not applicable	
ifsStretchRatio	not applicable	not applicable	104 bits	

	Values			
Parameters	10 Mb/s 1BASE-5 100 Mb/s	1 Gb/s	P2MP	10 Gb/s
interFrameGap	96 bits	96 bits	0 bits	96 bits
maxUntaggedFrameSize	1518 octets	1518 octets	1518 octets	1518 octets
minFrameSize	512 bits (64 octets)	512 bits (64 octets)	512 bits (64 octets)	512 bits (64 octets)
ifsStretchRatio	not applicable	not applicable	not applicable	104 bits

Editors note: To be removed prior to final publication

This P2MP column in the parameter table is option #2 to making the IPG optional for P2MP.

NOTE 1—For 10 Mb/s implementations, the spacing between two successive non-colliding packets, from start of idle at the end of the first packet to start of preamble of the subsequent packet, can have a minimum value of 47 BT (bit times), at the AUI receive line of the DTE. This interFrameGap shrinkage is caused by variable network delays, added preamble bits, and clock skew.

NOTE 2—For 1BASE-5 implementations, see also DTE Deference Delay in 12.9.2.

NOTE 3—For 1 Gb/s implementations, the spacing between two non-colliding packets, from the last bit of the FCS field of the first packet to the first bit of the preamble of the second packet, can have a minimum value of 64 BT (bit times), as

measured at the GMII receive signals at the DTE. This interFrameGap shrinkage may be caused by variable network delays, added preamble bits, and clock tolerances.

NOTE 4—For 10 Gb/s implementations, the spacing between two packets, from the last bit of the FCS field of the first packet to the first bit of the preamble of the second packet, can have a minimum value of 40 BT (bit times), as measured at the XGMII receive signals at the DTE. This interFrameGap shrinkage may be caused by variable network delays and clock tolerances.

NOTE 5—For 10 Gb/s implementations, the value of ifsStretchRatio of 104 bits adapts the average data rate of the MAC sublayer to SONET/SDH STS-192 data rate (with frame granularity), for WAN-compatible applications of this standard.

WARNING

Any deviation from the above specified values may affect proper operation of the network.

4.4.2.1 Parameterized values

See 99.4.2.

4.4.2.2 Parameterized values

See 99.4.2.

4.4.2.3 Parameterized values

See 99.4.2.

4.4.2.4 Parameterized values

See 99.4.2.

4.4.3 Configuration guidelines

The operational mode of the MAC may be determined either by the Auto-Negotiation functions specified in Clause 28 and Clause 37, or through manual configuration. When manual configuration is used, the devices on both ends of a link segment must be configured to matching modes to ensure proper operation. When Auto-Negotiation is used, the MAC must be configured to the mode determined by Auto-Negotiation before assuming normal operation.

NOTE -- Improper configuration of duplex modes may result in improper network behavior.